

PADS4 Installation Manual

Version no. 12102020

TOC

PADS4 Introduction	
Online PADS4 resources website	23
System requirements	23
PADS4 System Configuration	23
Installation of a new PADS4 System	23
Updating an existing PADS4 System	23
Installation of a PADS4 HTML5 Launcher	24
2020.1 is the first release of a new platform	24
Migration period	24
PADS4 online resources website	25
System Requirements	26
PADS4 Windows applications and PADS4 CTRL Center	26
Requirements PADS4 Foundation & CTRL Center	26
Prerequisites PADS4 Foundation	26
Manufactures (sorted)	27
PADS4 Configuration Selection	28
PADS4 Configuration Selection	29
PADS4 Hardware requirements	30
General performance tips	30
PADS4 Foundation hardware requirements	31
PADS4 Viewer hardware requirements	33
PADS4 Network Port Configuration	35
Microsoft Active Directory Configuration	36
To configure the usage of Active Directory in PADS	37
Using Microsoft Windows Group Policies	37
To configure the usage of Group Policies for PADS4 Desktop Viewers	38
Using HTTPS	41

	PADS4 Backup Servers	42
	PADS4 Sub Servers	42
	Global PADS4 installation	43
	PADS4 Server	43
		43
	Desktop PC	. 43
	Sub Server PC	44
What	do I need to do to use Sensor module?	. 46
	Module Sensors	46
	Installing new purchased license	46
What	do I need to do to use FIDS module?	.47
	Module FIDS	47
	Installing new purchased license	47
How t	to install PADS4 Server	. 49
	Download the PADS4 Foundation Setup	49
	Execute the installation file (as an Administrator)	49
	Check the boxes to confirm and press Install to start the installation process.	50
	Error during installation	50
	Installation finished	52
	Once you press the Close button, you will be presented with the PADS4 CTRL Center Configuration tool and/or the PADS4 Clients installation wizard.	53
	Network ports used by PADS4	. 53
	Change Sensor database	. 53
How t	to install PADS4 Sub Server	.54
	Download the PADS4 Foundation Setup	54
	Execute the installation file (as an Administrator)	54
	Installation folders	54
	Accept to start installation	55

	Error during installation	56
	Installation finished	57
	Once you press the Close button, you will be presented with the PADS4 CTRL Center Configuration tool and/or the PADS4 Clients installation wizard.	58
	Configuration of Sub Server	58
	Network ports used by PADS4	58
How	to install PADS4 Backup Server	60
	Download the PADS4 Foundation Setup	60
	Execute the installation file (as an Administrator)	60
	Installation folders	60
	Accept to start installation	61
	Error during installation	62
	Installation finished	63
	Once you press the Close button, you will be presented with the PADS4 CTRL Center Configuration tool and/or the PADS4 Clients installation wizard.	64
	Configuration of Backup Server	64
	Network ports used by PADS4	64
How	to enter the PADS4 Product Key	. 66
	Open PADS4 CTRL Center	66
	Installing PADS4 Product Key from PADS4 CTRL Center	66
PADS	54 Foundation Configuration	. 67
	When all settings are successfully applied after click apply, PADS4 Foundation will resta	
	Sensor database type selection	68
	Check out if the server is running	68
	PADS4 Clients installation help	68
Senso	or database type selection	69
	Change database type from configuration tool	69
	Change database type manually	69

Database types supported	69
How to install PADS4 Viewer	71
Download	71
Start setup	71
User selection	72
Help	73
Installation starts	75
Network ports used by PADS4	75
Install PADS4 HTML5 Launcher on Android devices	76
Download software	76
Install PADS4 HTML5 Launcher from USB stick	76
Update PADS4 HTML5 Launcher from USB stick	76
Install PADS4 HTML5 Viewer on SOC devices	78
Manufactures (sorted)	78
Configuring Aopen AT1032TB	80
Installation of the PADS4 HTML5 Viewer Android Launcher	80
Adjust PADS4 Viewer options	81
Open launcher menu from PADS4 HTML5 Viewer	81
Disable Android navigation bar	81
To perform a factory reset of the device follow the next step	os:81
Required firmware	82
Supported features and limitations	82
PADS4 Viewer on BenQ series SL <xx>02K</xx>	85
1. First time use	86
1.1. Configuring the device	86
1.2. Resetting the device	86
2. Installing PADS4 Viewer	86
2.1. Checking device firmware	87

	2.2. Adjust PADS4 Viewer settings using the options screen	87
	2.3. Accessing Android menu when PADS4 Viewer is running	88
	3. Supported features and limitations SL6502K	88
	4. Troubleshooting	90
PA	DS4 Viewer on Brightsign XD234	91
	1. Prerequisites	92
	1.1. Software version	92
	1.2. Supported software devices	92
	2. Setup Brightsign device	92
	3 Installation of the PADS4 Viewer	93
	3.1 Download the PADS4 Viewer for Brightsign	94
	3.2 Install the PADS4 Viewer for Brightsign	94
	Server change	94
	4. Supported features and limitations for Brightsign	95
	Remarks	98
PA	DS4 Viewer on Brightsign HD224	98
	1. Prerequisites	99
	1.1. Software version	99
	1.2. Supported software devices	99
	2. Setup Brightsign device	99
	3 Installation of the PADS4 Viewer	100
	3.1 Download the PADS4 Viewer for Brightsign	100
	3.2 Install the PADS4 Viewer for Brightsign	101
	Server change	101
	4. Supported features and limitations for Brightsign	102
	Remarks	104
PA	DS4 Viewer on Brightsign LS424	105
	1. Prerequisites	105

	1.1. Software version	105
	1.2. Supported software devices	106
	2. Setup Brightsign device	106
	3 Installation of the PADS4 Viewer	107
	3.1 Download the PADS4 Viewer for Brightsign	107
	3.2 Install the PADS4 Viewer for Brightsign	108
	Server change	108
	4. Supported features and limitations for Brightsign	108
	Remarks	111
Conf	iguring Chrome Browser for testing	113
	Start of Chrome Browser on Microsoft Windows for testing	113
	Required software	113
	Supported features and limitations	113
Configuring ELO I-Series 2		117
	Welcome	117
	Installation of the PADS4 HTML5 Viewer Android Launcher	117
	Upgrading PADS4 Launcher from USB stick	118
	Adjust PADS4 Viewer options	118
	Open launcher menu from PADS4 HTML5 Viewer	118
	Disable Android navigation bar	118
	To perform a factory reset of the device follow the next steps:	119
	Supported features and limitations	119
Conf	iguring Giada DN73	123
	Installation of the PADS4 HTML5 Viewer Android Launcher	123
	Upgrading PADS4 Launcher from USB stick	123
	Adjust PADS4 Viewer options	124
	Open launcher menu from PADS4 HTML5 Viewer	124
	To perform a factory reset of the device follow the next steps:	124

Required firmware	124
Supported features and limitations	124
Configuring Giada DN74	128
Installation of the PADS4 HTML5 Viewer Android Launcher	128
Upgrading PADS4 Launcher	129
Adjust PADS4 Viewer options	129
Open launcher menu from PADS4 HTML5 Viewer	129
To perform a factory reset of the device follow the next steps:	129
Required firmware	129
Supported features and limitations	130
Configuring Giada DM6	134
Installation of the PADS4 Viewer	134
Configuring IAdea XDS-1078	135
Configuring the device for PADS4 HTML5 Viewer Laucher	135
Installation of the PADS4 HTML5 Viewer Android Launcher	135
Adjust PADS4 Viewer options	136
Open launcher menu from PADS4 HTML5 Viewer	136
To perform a factory reset of the device follow the next steps:	136
Required firmware	136
Supported features and limitations	137
Configuring IAdea XDS-1088	141
Installation of the PADS4 HTML5 Viewer Android Launcher	141
Adjust PADS4 Viewer options	141
Open launcher menu from PADS4 HTML5 Viewer	142
To perform a factory reset of the device follow the next steps:	142
Required firmware	142
Supported features and limitations	142
Configuring IAdea XDS-1588A	146

Installation of the PADS4 HTML5 Viewer Android Launcher	146
Adjust PADS4 Viewer options	146
Open launcher menu from PADS4 HTML5 Viewer	147
To perform a factory reset of the device follow the next steps:	147
Required firmware	147
Supported features and limitations	147
Configuring IAdea MBR 1100	151
Installation of the PADS4 HTML5 Viewer Android Launcher	151
Adjust PADS4 Viewer options	151
Open launcher menu from PADS4 HTML5 Viewer	152
To perform a factory reset of the device follow the next steps:	152
Required firmware	152
Supported features and limitations	152
Configuring IAdea XMP-6400 / XMP-7300	
Installation of the PADS4 HTML5 Viewer Android Launcher	156
Adjust PADS4 Viewer options	156
Open launcher menu from PADS4 HTML5 Viewer	157
To perform a factory reset of the device follow the next steps:	157
Required firmware	157
Supported features and limitations	157
Configuring IAdea XMP-6400 / XMP-7300	161
Installation of the PADS4 HTML5 Viewer Android Launcher	161
Adjust PADS4 Viewer options	161
Open launcher menu from PADS4 HTML5 Viewer	162
To perform a factory reset of the device follow the next steps:	162
Required firmware	162
Supported features and limitations	162
Viewer on LG WebOS2	166

	1. First time use	166
	1.1. Configuring the device	166
	1.2. Resetting the device	167
	2. Installing PADS4 Viewer	167
	2.1. Checking device firmware	168
	2.2 Updating firmware	. 168
	2.3. Adjust PADS4 Viewer settings using the options screen	168
	3. Supported features and limitations	168
	4. Troubleshooting	171
Vie	wer on LG WebOS3	172
	1. First time use	172
	1.1. Configuring the device	172
	1.2. Resetting the device	172
	2. Installing PADS4 Viewer	173
	2.1. Checking device firmware	173
	2.2 Updating firmware	. 174
	2.3. Adjust PADS4 Viewer settings using the options screen	174
	3. Supported features and limitations	174
	4. Troubleshooting	177
Vie	wer on LG WebOS3.2	177
	1. First time use	178
	1.1. Configuring the device	178
	1.2. Resetting the device	178
	2. Installing PADS4 Viewer	178
	2.1. Checking device firmware	179
	2.2 Updating firmware	. 179
	2.3. Adjust PADS4 Viewer settings using the options screen	179
	3. Supported features and limitations	180

4. Troubleshooting	182
Viewer on LG WebOS4	183
1. First time use	183
1.1. Configuring the device	183
1.2. Resetting the device	183
2. Installing PADS4 Viewer	184
2.1. Checking device firmware	184
2.2 Updating firmware	185
2.3. Adjust PADS4 Viewer settings using the options screen	185
3. Supported features and limitations	185
4. Troubleshooting	188
Viewer on LG WP400 JP	188
1. First time use	189
1.1. Configuring the device	189
1.2. Resetting the device	189
2. Installing PADS4 Viewer	189
2.1. Checking device firmware	190
2.2 Updating firmware	190
2.3. Adjust PADS4 Viewer settings using the options screen	190
3. Supported features and limitations	191
4. Troubleshooting	193
Configuring Microsoft Windows OS	195
Installation	195
Supported Microsoft Windows versions	195
PADS4 Viewer on Philips series (<size>BDL3050Q)</size>	196
1. First time use	197
1.1. Configuring the device	197
1.2. Resetting the device	197

	2. Installing PADS4 Viewer	.198
	2.1. Checking device firmware	.198
	2.2. Updating device firmware	.198
	2.3. Install PADS4Philips from USB stick	198
	2.4. Configuring the device for PADS4Philips	199
	2.4.1. Validate Date Time configuration	199
	2.4.2. Optional: Shutdown and Wake on LAN support.	200
	2.4.3. Optional: Enable TeamViewer	200
	2.5. Connecting to PADS4 Server	.200
	2.6. Adjust PADS4 Viewer settings using the options screen	.201
	2.7. Updating PADS4 Viewer and PADS4Philips app	201
	2.8. Accessing Android menu when PADS4 Viewer is running	.201
	3. Supported features and limitations xxBDL3050Q	202
	4. Troubleshooting	204
PAC	DS4 Viewer on Philips series (<size>BDL4050D)</size>	206
	1. First time use	206
	1.1. Configuring the device	207
	1.2. Resetting the device	207
	2. Installing PADS4 Viewer	207
	2.1. Checking device firmware	.208
	2.2. Updating device firmware	.208
	2.3. Install PADS4Philips from USB stick	208
	2.4. Configuring the device for PADS4Philips	209
	2.4.1. Validate Date Time configuration	209
	2.4.2. Optional: Shutdown and Wake on LAN support.	209
	2.4.3. Optional: Enable TeamViewer	210
	2.5. Connecting to PADS4 Server	.210
	2.6. Adjust PADS4 Viewer settings using the options screen	.211

	2.7. Updating PADS4 Viewer and PADS4Philips app	. 211
	2.8. Accessing Android menu when PADS4 Viewer is running	211
	3. Supported features and limitations xxBDL4050D	211
	4. Troubleshooting	.214
PAI	OS4 Viewer on Philips series (<size>BDL4150D)</size>	.215
	1. First time use	. 216
	1.1. Configuring the device	. 216
	1.2. Resetting the device	.216
	2. Installing PADS4 Viewer	.217
	2.1. Checking device firmware	.217
	2.2. Updating device firmware	.217
	2.3. Install PADS4Philips from USB stick	. 217
	2.4. Configuring the device for PADS4Philips	. 218
	2.4.1. Validate Date Time configuration	. 218
	2.4.2. Optional: Shutdown and Wake on LAN support.	. 219
	2.4.3. Optional: Enable TeamViewer	. 219
	2.5. Connecting to PADS4 Server	219
	2.6. Adjust PADS4 Viewer settings using the options screen	.220
	2.7. Updating PADS4 Viewer and PADS4Philips app	. 220
	2.8. Accessing Android menu when PADS4 Viewer is running	.220
	3. Supported features and limitations xxBDL4150D	.221
	4. Troubleshooting	.223
PAI	DS4 Viewer on Philips series (<size>BDL505xP)</size>	.225
	1. First time use	. 225
	1.1. Configuring the device	. 226
	1.2. Resetting the device	.226
	2. Installing PADS4 Viewer	.226
	2.1. Checking device firmware	.227

2.2. Updating device firmware	.227
2.3. Install PADS4Philips from USB stick	. 227
2.4. Configuring the device for PADS4Philips	. 228
2.4.1. Validate Date Time configuration	. 228
2.4.2. Optional: Shutdown and Wake on LAN support.	228
2.4.3. Optional: Enable TeamViewer	229
2.5. Connecting to PADS4 Server	.229
2.6. Adjust PADS4 Viewer settings using the options screen	.230
2.7. Updating PADS4 Viewer and PADS4Philips app	230
2.8. Accessing Android menu when PADS4 Viewer is running	.230
3. Supported features and limitations xxBDL505xP	230
4. Troubleshooting	.233
DS4 Viewer on Philips Multi-Touch series (10BDL3051T)	234
1. First time use	. 235
1.1. Configuring the device	. 235
1.2. Resetting the device	.236
2. Installing PADS4 Viewer	.236
2.1. Checking device firmware	.236
2.2. Updating device firmware	.236
2.3. Install PADS4Philips from USB stick	. 237
2.4. Configuring the device for PADS4Philips	. 237
2.4.1. Validate Date Time configuration	. 237
2.4.2. Optional: Enable TeamViewer	238
2.5. Connecting to PADS4 Server	.238
2.6. Adjust PADS4 Viewer settings using the options screen	.239
2.7. Updating PADS4 Viewer and PADS4Philips app	239
2.8. Accessing Android menu when PADS4 Viewer is running	.239
3. Supported features and limitations 10BDL3051T	.239
	2.3. Install PADS4Philips from USB stick 2.4. Configuring the device for PADS4Philips 2.4.1. Validate Date Time configuration 2.4.2. Optional: Shutdown and Wake on LAN support. 2.4.3. Optional: Enable TeamViewer 2.5. Connecting to PADS4 Server 2.6. Adjust PADS4 Viewer settings using the options screen 2.7. Updating PADS4 Viewer and PADS4Philips app 2.8. Accessing Android menu when PADS4 Viewer is running 3. Supported features and limitations xxBDL505xP 4. Troubleshooting 2.54 Viewer on Philips Multi-Touch series (10BDL3051T) 1. First time use 1.1. Configuring the device 1.2. Resetting the device 2. Installing PADS4 Viewer 2.1. Checking device firmware 2.2. Updating device firmware 2.3. Install PADS4Philips from USB stick 2.4. Configuring the device for PADS4Philips 2.4.1. Validate Date Time configuration 2.4.2. Optional: Enable TeamViewer 2.5. Connecting to PADS4 Server 2.6. Adjust PADS4 Viewer settings using the options screen 2.7. Updating PADS4 Viewer and PADS4Philips app 2.8. Accessing Android menu when PADS4 Viewer is running

4. Troubleshooting	242
PADS4 Viewer on Philips Multi-Touch series (24BDL4151T)	243
1. First time use	244
1.1. Configuring the device	244
1.2. Resetting the device	245
2. Installing PADS4 Viewer	245
2.1. Checking device firmware	245
2.2. Updating device firmware	245
2.3. Install PADS4Philips from USB stick	246
2.4. Configuring the device for PADS4Philips	246
2.4.1. Validate Date Time configuration	246
2.4.1. Optional: Enable TeamViewer	247
2.5. Connecting to PADS4 Server	247
2.6. Adjust PADS4 Viewer settings using the options screen	248
2.7. Updating PADS4 Viewer and PADS4Philips app	248
2.8. Accessing Android menu when PADS4 Viewer is running	248
3. Supported features and limitations 24BDL4151T	248
4. Troubleshooting	251
Configuring ProDVX DSK/DSQ Series	254
Configuring the device for PADS4 HTML5 Launcher	254
Installation of the PADS4 HTML5 Viewer Android Launcher	254
Upgrading PADS4 Launcher from USB stick	255
Adjust PADS4 Viewer options	255
Open launcher menu from PADS4 HTML5 Viewer	255
To perform a factory reset of the device follow the next steps:	256
Supported features and limitations	256
Configuring ProDVX DSK/DSQ Series	260
Configuring the device for PADS4 HTML5 Launcher	260

	Installation of the PADS4 HTML5 Viewer Android Launcher	260
	Upgrading PADS4 Launcher from USB stick	. 261
	Adjust PADS4 Viewer options	.261
	Open launcher menu from PADS4 HTML5 Viewer	261
	To perform a factory reset of the device follow the next steps:	262
	Supported features and limitations	. 262
Conf	iguring ProDVX ABPC-543 Series	266
	Configuring the device for PADS4 HTML5 Launcher	.266
	Installation of the PADS4 HTML5 Viewer Android Launcher	266
	Upgrading PADS4 Launcher from USB stick	. 267
	Adjust PADS4 Viewer options	.267
	Open launcher menu from PADS4 HTML5 Viewer	267
	To perform a factory reset of the device follow the next steps:	268
	Required firmware	268
	Supported features and limitations	. 268
Conf	iguring ProDVX ABPC-545 Series	272
	Configuring the device for PADS4 HTML5 Launcher	.272
	Installation of the PADS4 HTML5 Viewer Android Launcher	272
	Adjust PADS4 Viewer options	.273
	Open launcher menu from PADS4 HTML5 Viewer	273
	To perform a factory reset of the device follow the next steps:	273
	Required firmware	273
	Supported features and limitations	. 274
Conf	iguring ProDVX APPC-10SLB Series	278
	Configuring the device for PADS4 HTML5 Launcher	.278
	Installation of the PADS4 HTML5 Viewer Android Launcher	278
	Upgrading PADS4 Launcher from USB stick	. 279
	Adjust PADS4 Viewer options	.279

	Open launcher menu from PADS4 HTML5 Viewer	279
	To perform a factory reset of the device follow the next steps:	.280
	Required firmware	.280
	Supported features and limitations	. 280
Confi	guring Qbic BXP-321	284
	Installation of the PADS4 HTML5 Viewer Android Launcher	.284
	Upgrading PADS4 Launcher from USB stick	. 285
	Adjust PADS4 Viewer options	.285
	Open launcher menu from PADS4 HTML5 Viewer	.285
	Disable Android navigation bar	.286
	To perform a factory reset of the device follow the next steps:	.286
	Required firmware	.286
	Supported features and limitations	. 286
Confi	guring Qbic TD-0350	290
	Installation of the PADS4 HTML5 Viewer Android Launcher	.290
	Upgrading PADS4 Launcher from USB stick	. 291
	Adjust PADS4 Viewer options	.291
	Open launcher menu from PADS4 HTML5 Viewer	.291
	Disable Android navigation bar	.292
	To perform a factory reset of the device follow the next steps:	.292
	Required firmware	.292
	Supported features and limitations	. 292
Confi	guring Qbic TD-1050 PRO	.296
	Installation of the PADS4 HTML5 Viewer Android Launcher	.296
	Upgrading PADS4 Launcher from USB stick	. 297
	Adjust PADS4 Viewer options	.297
	Open launcher menu from PADS4 HTML5 Viewer	.297
	Disable Android navigation bar	.298

	To perform a factory reset of the device follow the next steps:	298
	Required firmware	298
	Supported features and limitations	298
Vie	wer on Samsung SSP2	302
	1. First time use	302
	1.1. Configuring the device	302
	1.2. Resetting the device	303
	2. Installing PADS4 Viewer	303
	2.1. Checking device firmware	304
	2.2 Updating firmware	304
	2.3. Adjust PADS4 Viewer settings using the options screen	304
	3. Supported features and limitations	304
	4. Troubleshooting	308
Vie	wer on Samsung SSP3 (E serie)	308
	1. First time use	309
	1.1. Configuring the device	309
	1.2. Resetting the device	309
	2. Installing PADS4 Viewer	309
	2.1. Checking device firmware	310
	2.2 Updating firmware	310
	2.3. Adjust PADS4 Viewer settings using the options screen	311
	3. Supported features and limitations	311
		314
	Appendix 1 Lynk-DRM streaming	314
	Video streaming on Samsung SSP3	314
	Playing streams from Lynk DRM	315
Vie	wer on Samsung SSP4 (F serie)	315
	1. First time use	316

	1.1. Configuring the device	. 316
	1.2. Resetting the device	.316
	1.3 Uninstall an app	. 316
	2. Installing PADS4 Viewer	.317
	2.1. Checking device firmware	.318
	2.2 Updating firmware	. 318
	2.3. Adjust PADS4 Viewer settings using the options screen	.318
	3. Supported features and limitations	318
	4. Troubleshooting	.321
Vie	wer on Samsung SSP5 (H & J serie, Tizen 3)	. 322
	1. First time use	. 322
	1.1. Configuring the device	. 323
	1.2. Resetting the device	.323
	1.3 Uninstall an app	. 323
	2. Installing PADS4 Viewer	.323
	2.1. Checking device firmware	.324
	2.2 Updating firmware	. 325
	2.3. Adjust PADS4 Viewer settings using the options screen	.325
	3. Supported features and limitations	325
	4. Troubleshooting	.328
Vie	wer on Samsung SSP6 (Tizen 4)	.329
	1. First time use	. 329
	1.1. Configuring the device	. 329
	1.2. Resetting the device	.330
	1.3 Uninstall an app	. 330
	2. Installing PADS4 Viewer	.330
	2.1. Checking device firmware	.331
	2.2 Updating firmware	. 331

2.3. Adjust PADS4 Viewer settings using the options screen	332
3. Supported features and limitations	332
4. Troubleshooting	335
Viewer on Samsung SSP6 SHF stretch (Tizen 4)	336
1. First time use	336
1.1. Configuring the device	336
1.2. Resetting the device	336
1.3 Uninstall an app	337
2. Installing PADS4 Viewer	337
2.1. Checking device firmware	338
2.2 Updating firmware	338
2.3. Adjust PADS4 Viewer settings using the options screen	339
3. Supported features and limitations	339
4. Troubleshooting	342
4. Houbleshooting	
How to install PADS4 Windows Client applications	
	343
How to install PADS4 Windows Client applications	343
How to install PADS4 Windows Client applications Download	343 343
How to install PADS4 Windows Client applications Download Start setup	343 343 344
How to install PADS4 Windows Client applications Download Start setup User selection	343 343 344 344
How to install PADS4 Windows Client applications Download Start setup User selection Component selection	343 343 344 344 345
How to install PADS4 Windows Client applications Download Start setup User selection Component selection Help	343 343 344 344 345 346
How to install PADS4 Windows Client applications Download Start setup User selection Component selection Help Shortcuts	343 343 344 344 345 346
How to install PADS4 Windows Client applications Download Start setup User selection Component selection Help Shortcuts Installation starts	343 343 344 344 345 346
How to install PADS4 Windows Client applications Download Start setup User selection Component selection Help Shortcuts Installation starts Network ports used by PADS4	343 343 344 345 346 346
How to install PADS4 Windows Client applications Download Start setup User selection Component selection Help Shortcuts Installation starts Network ports used by PADS4 How to silent install PADS4 Windows Client applications using commandline para-	343 343 344 345 346 346

Examples	348
How to update PADS4 Server	349
Download the PADS4 Foundation Setup	349
Execute the installation file (as an Administrator)	349
Check the boxes to confirm and press Install to start the installation process.	350
Error during installation	350
Installation finished	352
Once you press the Close button, you will be presented with the PADS4 CTRL Center Configuration tool and/or the PADS4 Clients installation wizard.	353
How to upgrade PADS4 Sub Server	354
Upgrade Sub Server	354
Upgrade Viewers	354
How to upgrade PADS4 Backup Server	355
Upgrade Backup Server	355
Upgrade Viewers	355
PADS4 Foundation Configuration	356
When all settings are successfully applied after click apply, PADS4 Foundation will restart all processes with the new settings.	357
Sensor database type selection	357
Check out if the server is running	357
PADS4 Clients installation help	357
How to upgrade PADS4 Viewer	358
Automatic upgrade	358
To upgrade PADS4 Viewers automatically	359
Manual upgrade	362
How to upgrade PADS4 Windows Client applications	363
Download PADS4 Client setup	363
Start setup	363
PADS4 Active Directory Synchronization Installation	366

Prepare the Active Directory package installation	366
Installing PADS4 Active Directory Synchronization package.	366
Configuring Active Directory Synchronization	367
Troubleshooting	369
PADS4FIDS Introduction	371
Smart FIDS	372
PADS4	373
Beyond FIDS	374
PADS4FIDS Installation	375
Step 1	375
Step 2	375
Step 3	375
Step 4	375
Cton F	375
Step 5	
Start PADS4FIDS Operator (with your PADS4 account)	
	376
Start PADS4FIDS Operator (with your PADS4 account)	3 76
Start PADS4FIDS Operator (with your PADS4 account) To connect to your PADS4FIDS Operator	376 376
Start PADS4FIDS Operator (with your PADS4 account) To connect to your PADS4FIDS Operator To Sign In	376 376 376
Start PADS4FIDS Operator (with your PADS4 account) To connect to your PADS4FIDS Operator To Sign In No credentials?	376 376 376 377
Start PADS4FIDS Operator (with your PADS4 account) To connect to your PADS4FIDS Operator To Sign In No credentials? No web page found?	376 376 377 377
Start PADS4FIDS Operator (with your PADS4 account) To connect to your PADS4FIDS Operator To Sign In No credentials? No web page found? PADS4 Server settings for PADS4FIDS	376 376 377 377 378
Start PADS4FIDS Operator (with your PADS4 account) To connect to your PADS4FIDS Operator To Sign In No credentials? No web page found? PADS4 Server settings for PADS4FIDS Microsoft SQL Server	376376376377377378379
Start PADS4FIDS Operator (with your PADS4 account) To connect to your PADS4FIDS Operator To Sign In No credentials? No web page found? PADS4 Server settings for PADS4FIDS Microsoft SQL Server Flight Remover Settings	376376377377378379379
Start PADS4FIDS Operator (with your PADS4 account) To connect to your PADS4FIDS Operator To Sign In No credentials? No web page found? PADS4 Server settings for PADS4FIDS Microsoft SQL Server Flight Remover Settings Setup a SQL Fail over installation	376376376377378379379380380
Start PADS4FIDS Operator (with your PADS4 account) To connect to your PADS4FIDS Operator To Sign In No credentials? No web page found? PADS4 Server settings for PADS4FIDS Microsoft SQL Server Flight Remover Settings Setup a SQL Fail over installation Step 1	376376376377377378379380380
Start PADS4FIDS Operator (with your PADS4 account) To connect to your PADS4FIDS Operator To Sign In No credentials? No web page found? PADS4 Server settings for PADS4FIDS Microsoft SQL Server Flight Remover Settings Setup a SQL Fail over installation Step 1 Step 2	376376376377377378379380380380

Step 1	382
Step 2	383
Step 3	384
Step 4	385
Step 5	386
Step 6	387
Create the database manually with Powershell	388
Execute the following PowerShell commands (on the system which has SQL Server installed) with a user account which has system admin permissions on SQL.	388
Create the database manually with SQL statements	389
Execute the following SQL statements with the preferred SQL client	389
Glossary	390



PADS4 Installation Manual

PADS4 Introduction

PADS4 Installation Manual describes how to install PADS4.

The documentation is divided in chapters which describe the steps to take for installing or updating a PADS4 System.

Online PADS4 resources website

Checkout the online PADS4 resources website https://pads4.com/resources.

Here you can find useful resources to make sure you always have the most recent software and documentation.

System requirements

What are the system requirements

PADS4 System Configuration

PADS4 Configuration Selection

Installation of a new PADS4 System

How to install PADS4 Server

How to install PADS4 Windows Client applications

How to install PADS4 Viewer

How to install PADS4 Sub Server

PADS4 Foundation Configuration

PADS4 Configuration selection

Updating an existing PADS4 System

How to update PADS4 Server

How to update PADS4 Windows Client applications

How to update PADS4 Viewer

How to update PADS4 Sub Server

Installation of a PADS4 HTML5 Launcher

How to install PADS4 HTML5 Launcher on Android devices

How to install PADS4 HTML5 Viewer on SOC devices

2020.1 is the first release of a new platform

Until version 2020.1 PADS4 contained a PADS4 web setup and full cd setup. All components both server and client were available in this setup.

With the new PADS4 2020.1 we introduce a new web based version of PADS4. When installing PADS4, you can have both a web based portal and Windows Client Applications such as PADS4 Designer, PADS4 Scheduler, PADS4 Viewer, PADS4 Messenger, PADS4 Desktop Viewer, PADS4 Content Library Manager.

Migration period

In the upcoming year we will add new functionality so that eventually we have all the windows based functionality available in the PADS4 CTRL Center web portal.

2020.1 contains a first new web based version of PADS4 and needs a different approach. Because we also want to support the current windows based applications for our customers, the installation process is splitted into 2 separate installations. 1 for the Server side and 1 for the Clients.



PADS4 Installation Manual

PADS4 online resources website

Checkout the online PADS4 resources website https://pads4.com/resources.

Here you can find useful resources to make sure you always have the most recent software and documentation.



PADS4 Installation Manual

System Requirements

PADS4 CTRL Center is a web based management portal on top of PADS4 Foundation and is able to control a PADS4 system via the web browser. Most common browsers are supported.

For now the PADS4 Clients setup co-exists with the PADS4 Foundation setup. Do note that a valid SMA is required to the use new functionality.

PADS4 Windows applications and PADS4 CTRL Center

PADS4 CTRL Center can be used together with the PADS4 Windows based applications such as the PADS4 Scheduler, PADS4 System Management, PADS4 Agent and all other Windows based applications.

The user is able to start one or more Windows based PADS4 applications (depending on the licenses assigned), and at the same time open the PADS4 CTRL Center portal using the same user credentials.

Requirements PADS4 Foundation & CTRL Center

- PADS4 version 4.12 or higher must be installed before installing PADS4 CTRL Center
- Minimum 4 GB, 2 cores
- Recommended 8 GB, 4 cores
- Full installation size 819Mb
- OS: Windows 7 SP1, Windows 8.1, Windows 10, Windows Server 2012 R2, Windows Server 2016, Windows Server 2019. Note: 64-bit OS is supported

Prerequisites PADS4 Foundation

PADS4 Foundation will install all prerequisites.

- NDS Package Manager
 Small installation tool made by NDS, which is used to install, update or remove the PADS4 CTRL Center. When this tool is uninstalled, you won't be able to uninstall PADS4 CTRL Center.
- Microsoft .NET Core Runtime 2.2.6 & Microsoft ASP.NET Core 2.2.6 Shared Framework
 The new PADS4 middleware services used by the PADS4 CTRL Center, make use of the .NET Core
 frameworks
- Erlang OTP 2.0 (9.3) & RabbitMQ Server 3.7.8

 When uninstalling manually make sure that, you first uninstall RabbitMQ and then Erlang
- NGINX webserver

Prerequisites that require internet connection for downloading

- Microsoft .NET Framework 4.6.2 (needs internet connection to download)
 Framework component is most likely to be available on all systems. If on a certain old system this component is missing, PADS4 will try to download it from the internet.
- Powershell 3.0 which is available on all windows operation systems except Windows 7 for which PADS4 will try to download it from the internet..

All prerequisites are available in the setup except for .Net framework 4.6.2 & Powershell 3.0.



PADS4 certified Viewer devices

This section contains all certified PADS4 Viewer devices available (alphabetical sorted).

These devices are tested with every new release of PADS4.

Manufactures (sorted) AOpen BenQ Brightsign Chrome Web Browser (testing purposes) ELO Giada ladea LG

Philips

Microsoft Windows

ProDVX

Qbic



PADS4 Installation Manual

PADS4 Configuration Selection

PADS4 allows you to fully integrate a new setup for your digital signage solution. With a standardized overview of your schedules, Content Library & viewer operation (PADS4 CTRL Center), you can create a multitude of narrowcasting implementations for you & your clients.

For more information about initial setup & configuration, you can look at the PADS4 instructional manual http://go.pads4.com/?fwlink=1100.

NOTE: Currently we are working on upgrading this manual.

You can choose from different configurations:

Standalone

(Page 13) Explains a standalone configuration where all PADS4 applications will be installed on one single PC.

Network

(Page 14) Explains a network configuration where PADS4 applications will be installed on multiple PCs to form one installation.

Global (large) Network

(Page 16) Explains a worldwide network configuration which is global or has a large configuration (read has a lot of viewers connected) where the content library bandwidth is limited.

Contact your local supplier / business representative for a licensed PADS4 product-key, and we will inform you further with a manual, the Foundation & Clients installation files.



PADS4 Installation Manual

PADS4 Configuration Selection

PADS4 allows you to fully integrate a new setup for your digital signage solution. With a standardized overview of your schedules, Content Library & viewer operation (PADS4 CTRL Center), you can create a multitude of narrowcasting implementations for you & your clients.

For more information about initial setup & configuration, you can look at the PADS4 instructional manual http://go.pads4.com/?fwlink=1100.

NOTE: Currently we are working on upgrading this manual.

You can choose from different configurations:

Standalone

(Page 13) Explains a standalone configuration where all PADS4 applications will be installed on one single PC.

Network

(Page 14) Explains a network configuration where PADS4 applications will be installed on multiple PCs to form one installation.

Global (large) Network

(Page 16) Explains a worldwide network configuration which is global or has a large configuration (read has a lot of viewers connected) where the content library bandwidth is limited.

Contact your local supplier / business representative for a licensed PADS4 product-key, and we will inform you further with a manual, the Foundation & Clients installation files.



PADS4 Installation Manual

PADS4 Hardware requirements

General performance tips

Synchronisation of content is one of the processes that has a big performance impact

on the server Disk

Usage of Solid State Disks (SSD) significantly improves server performance

Be aware that virus scanners can have a big impact on the performance related to synchronization of content and processes.

Each content file will be scanned by virus scanners each time it has to be synchronized to Viewers or sub/backup servers.

ners

Virus scan- Data send towards Viewers will be scanned and could cause a performance drop and/or Server cpu load.

- * Exclude the PADS4 content folders from scanning (c:\programdata\pads4) to improve the synchronization process and lower the cpu usage.
- * Exclude PADS4 processes from scanning

Virtual Server	When using a virtual network, make sure you use a static Mac address. A dynamic MAC address will negatively impact the PADS4 License mechanism during a PADS4 Server restart which may result in a required reactivation.
Network	Best performance will be reached when the network is stable, 100Mbps or faster, 1Gbit network preferred
Content storage space	Content storage size depends on customer's requirement and will have impact on bandwidth used. Usage of SSD storage devices can increase performance dramatically for both server and Viewer.
Content	Please convert 4K Videos and 4K images which are shown on Full HD displays back to the specs of the displays to improve performance on both network and visualization.
Content per- missions	Use content permissions to limit the synchronization of content send to certain Viewer groups and/or User groups. This prevents content from being synched with devices which will never show the content. Try to limit the amount of data retrieved using data providers for both memory usage and performance drops.
Data Server	Only retrieve the information from the data source that is going to be used to prevent high bandwidth usage. Limit the number of rows, or the columns used to only get what is used by the presentation.
	Do not specify small Data Provider read intervals when the data is not updated real-

Do not specify small Data Provider read intervals when the data is not updated real-time

Prevent small read intervals that will increase cpu usage when there is no need to read the information continuously.

PADS4 Foundation hardware requirements

Be aware that hardware requirements depend on the purpose of the system. Situations where static information is shown requires less resources than full multimedia solutions.

PADS4 System with <100 Viewers	CPU	2 cores
	Memory	4Gb, Static dedicated RAM with VM
	Application storage	2Gb
	Content storage	16Gb. depends on customer requirements
	Minimum OS	Windows 10, 64bit

Recommended OS Windows Server 2016, 64bit

maximum of 25 Data Pro-

viders

Disk performance has a big

Disk impact on the overal PADS4

system performance

PADS4 System with 100-500 Viewers CPU

Memory 6Gb, Static dedicated RAM

4 cores

with VM

Application storage 2Gb

Data Server

Content storage 32Gb. depends on customer

requirements

Minimum OS Windows 10, 64bit

Recommended OS Windows Server 2016, 64bit

Data Server maximum of 25 Data Pro-

viders

Disk performance has a big

impact on the overal PADS4

system performance

PADS4 System with 500 Viewers CPU 4 cores

Disk

Memory 8Gb, Static dedicated RAM

with VM

Application storage 2Gb

Content storage 64Gb. depends on customer

requirements

Minimum OS Windows 10, 64bit

Recommended OS Windows Server 2016, 64bit maximum of 100 Data Pro-

Data Server

viders

Disk performance has a big

Disk impact on the overal PADS4

system performance

PADS4 System with 1000 Viewers CPU 4 cores

12Gb, Static dedicated RAM Memory

with VM

2Gb Application storage

256Gb. depends on customer Content storage

requirements

Minimum OS Windows 10, 64bit

Recommended OS Windows Server 2016, 64bit maximum of 200 Data Pro-Data Server

viders

Disk

Disk performance has a big impact on the overal PADS4

system performance

When using more than 1000 Viewers, check the possibility to use PADS4 Backup servers and PADS4 Sub Servers for load balancing which can improve the performance of the total system, especially when you have more physical locations this can improve the content synchronization to use less bandwidth.

More information about system configuration can be found here.

PADS4 System with 1000+ Viewers

PADS4 Viewer hardware requirements

PADS4 Microsoft Windows Viewer

Minimum specs

CPU 2 cores Memory 2Gb Application storage 2Gb

16Gb. depends on customer Content storage

requirements

Recommended OS Windows 7 SP1

maximum of 25 active local **Data Providers**

Data Providers

Disk

Disk performance has a big impact on the overal PADS4 system performance

PADS4 Microsoft Windows Viewer

Recommended specs

CPU 4 cores
Memory 4Gb

Memory 4Gb Application storage 2Gb

Content storage 128Gb. depends on customer

requirements

Recommended OS Windows 10, 64bit

Data Providers maximum of 50 active loc-

alData Providers

Disk performance has a big impact on the overal PADS4

system performance

PADS4 Microsoft Windows Viewer

CPU

Disk

4 cores. Viewer that is running a full multi media presentation including videos and a lot of

page/element effects

Full Multi-Media specs

Memory
Application storage

6Gb 2Gb

Content storage

256Gb. depends on customer

requirements

Recommended OS

Windows 10, 64bit

Data Providers

maximum of 50 active local

Data Providers

Disk performance has a big impact on the overal PADS4

system performance

PADS4 Android Viewer

Recommended

OS

Disk

Android 5.01 or higher

Memory

4Gb

Content storage

4Gb

Data Providers

Data Providers are running on

the PADS4 Server

NDS assumes no responsibility or liability for any errors or omissions in the content of this doc-

The information contained in this document is provided on an "as is" basis with no guarantees of completeness, accuracy, usefulness or timeliness..."



PADS4 Installation Manual

PADS4 Network Port Configuration

This page explains the usage of network ports by PADS4. Be aware that the port numbers mentioned are the default settings. Some ports can be adjusted.

The network communication between the components of the PADS4 system uses TCP/IP. PADS4 now uses one port number to communicate and by default it's 7237.

If you are using a firewall on the PADS4 [[[Undefined variable NDSVariables.ProductNameServer]]] PC this means that one or more of the above port numbers will have to be opened in order for PADS4 to communicate. On the client side (for instance the PADS4 [[[Undefined variable NDSVariables.ProductNameViewer]]] PC) it's not necessary to open any port numbers in the firewall.



NOTE

PADS4 has built-in features to automatically detect a PADS4 Server in your network. However a PADS4 Server can only be automatically detected when the UDP port number 3702 is not blocked by a firewall on the server PC or somewhere else in the network.



PADS4 Installation Manual

Microsoft Active Directory Configuration

Many organizations use Microsoft Active Directory to centrally manage the user accounts of their employees. With the Active Directory connection of PADS4 you can make optimal use of this information.

NOTE

PADS4 can work with your existing Active Directory structure 'as it is' and doesn't require any adjustments to organizational units or user groups in Active Directory.

After setting up a connection with Active Directory, you can beside 'normal' PADS4 users create so-called LDAP users in PADS4. These users are automatically linked to user accounts in active directory. When a user logs on with an LDAP user name, then the PADS4 system will automatically use the credentials stored inActive Directory. When the user name or password of the user is changed in Active Directory this is automatically taken over by the PADS4 system. If a user account is disabled in Active Directory then the user can no longer logon to the PADS4 applications. When the user is removed from Active Directory it will also automatically be removed from the PADS4 system. If the credentials that you have specified for PADS4 server to access Active Directory have limited permissions, then the updates in Active Directory might not be taken over by PADS4 instantly, but will only become effective after a restart of the PADS4 Server.

Memberships of user groups, permissions and, license assignment are all done in PADS4 for all users, including LDAP users.

If an LDAP user is removed from PADS4, it will NOT be removed from Active Directory.

When the connection with Active Directory is disabled in PADS4, then the existing LDAP users that have been defined in PADS4 remain exist. This way, you can reuse them when you decide to enable Active Directory again at a later time.

To configure the usage of Active Directory in PADS

- Specify the Active Directory connection settings in the server settings window of PADS4 System Management.
- 2. Reboot the PADS4 Server to make the Active Directory connection settings effective.
- 3. Go to the Users window in PADS4 System Management and create one or more LDAP users. Make sure that the users are assigned to a user group and that you assign the right licenses.

After this the Active Directory connection is ready-to-use and users can logon with one of the specified LDAP user accounts.



PADS4 Installation Manual

Using Microsoft Windows Group Policies

Many organizations use Microsoft Group Policies to centrally manage settings for the users. With the Group Policies of Microsoft you can centrally manage the Desktop Viewer settings.

PADS4 has implemented group policies for the Desktop Viewer application to allow the administrator to specify the settings from a central location and push these settings towards 1 or more users or user groups. The policies set by the administrator are automatically detected by the Desktop Viewer options window and those options are disabled in the user interface. This way it is possible to push a set of predefined settings towards users, and still give them the opportunity to change some settings locally.

The pushed settings are stored in the registry under:

HKEY_CURRENT_USER\SOFTWARE\Policies\Net Display Systems\PADS4

The 'normal settings' are stored in the registry under:

HKEY_CURRENT_USER\SOFTWARE\Net Display Systems\PADS4

To configure the usage of Group Policies for PADS4 Desktop Viewers

Installation PADS4 Server

First Install PADS4 Server (or more components, but the policy files are installed along with the Server installation).

Install Group Policy Template file

Copy PADS4.admx from C:\Program Files\Net Display Systems\PADS4\PolicyDefinitions to the Domain Policy Definitions directory on the domain server (usually: \\<FQDN>\SYSVOL\<FQDN>\Policies\PolicyDefinitions)

Policy Translation File

Copy PADS4.adml from C:\Program Files\Net Display Systems\PADS4\PolicyDefinitions to the Domain Policy Definitions Language directory on the domain server (usually: \\<FQDN>\SYSVOL\<FQDN>\Policies\PolicyDefinitions\en-US)

Microsoft Group Policy Management Console (GPMC)

Open the Group Policy Management Console application and next open the Group Policy Editor. Select User configuration / Policies / Administrative Templates: Policy definition / Net Display Systems / PADS4 / Desktop Viewer

PADS4 Property Table for the Desktop Viewer:

Setting	Options	Туре	Description
PADS4 Backup Server	Backup Server Address	String	Name/IP address of the Backup PADS4 Server.
	Port Number	Number	Portnumber on which the PADS4 Server listens for incoming calls
			(default is 7237). Custom Domain
PADS4 Domain	Domain	String	(default is PADS).
			liseconds after which the
Enable PADS4 Screensaver on startup	Screensaver timeout	Number	screensaver is star- ted when the user did not hit the key- board or mouse.
	Show logon screen on	Boolean	After the

	resume		screensaver is active and the user moves the mouse or hits the keyboard, the logon screen can be shown.
PADS4 Hostpath	Hostpath	String	The hostpath as specified in the PADS4 Server settings (default PADS4) which is used for the http synchronisation.
Http portnumber	HTTP port number	Number	Portnumber used for synchronisation and specified in the PADS4 Server settings (default is 8080).
Identification mode	Identification mode	Selection	Identification mode when connecting to the PADS4 Server.
User permissions	User can view messages	Boolean	User can open the messages window.
	User can open options win dow	Boolean	User can open the options window to change settings (not recommended with group policies).
	User can exit application	Boolean	User can exit the application.
	User can check for soft- ware updates	Boolean	User can check for software updates (not recommended with group policies).
	User can start screensaver	Boolean	User can change the screen saver settings.
Scale presentations to fit into the destination window	Scale presentations to fit into the destination window	Boolean	Resize the content to the window size.

	Maintain aspect ratio	Boolean	Preserve the aspect ratio. Configures how the
PADS4 Server	Server Connection	Selection	clients connect to the Server. When set to automatic the Server Address must be left empty.
	Server Address	String	Name/IP address of the PADS4 Server.
	Port Number	Number	Portnumber on which the PADS4 Server listens for incoming calls (default is 7237).
Content Library Synchronization	Synchronization Mode	Selection	When automatic is selected, the content is synchronized.
Content Library storage folder	Mode	Selection	When set to Manual specify the destination. Use variables like %APPDATA% to change the location to user specific folders.
	Content library folder	String	folder location where the PADS4 content library is loc- ated.
Tray icon appearance	Appearance	Selection	The way the Desktop Viewer is visible in the windows tray.
Use local timezone for scheduled presentations	Use local timezone for scheduled presentations	Boolean	Use the timezone of the local system for determining when to show a message.

NOTE

This allows the administrator to specify the settings from a central location and push these settings towards users. The users are not able to override these settings using the Options Window. The options that are set/pushed by the administrator are disabled in the Desktop Viewer Options Window.



PADS4 Installation Manual

Using HTTPS

When secure network communication must be used, follow the steps to enable the HTTPS protocol.

Click here to show the detailed HTTPS Installation upgrade document (PDF)

First install PADS4 Foundation.

After installation, you can specify the required HTTPS settings.

The process of installing a trusted certificate requires that you purchase a trusted certificate from a certificate authority.



PADS4 Installation Manual

PADS4 Backup Servers



PADS4 Installation Manual

PADS4 Sub Servers



Global PADS4 installation

If there are situations where you want to limit the bandwidth, lower your PADS4 Server CPU usage or create local sub systems, this can be achieved by using the PADS4 Sub Server.

The PADS4 Sub Server is a special Server which will be connected to a PADS4 Main Server. The Sub Server will synchronize the database and control library with the PADS4 Main Server.

Global Usage of PADS4

For instance when you have a head office in Europe, but have a lot of Viewers elsewhere, it is possible to setup a PADS4 Sub Server that will synchronize with the Main Server in Europe. Each PADS4 Server will synchronize with the (local) Sub Server instead of going directly to the Main Server. This will save a lot of traffic.

Hardware limit

A second reason of using a PADS4Sub Server is for situations where the PADS4 Server hardware reaches it's limit.

Backup system

A third reason can be to have a backup facility in case of system failure.

PADS4 Server

Usually the following component is installed on the PADS4 Server PC of the PADS4 system:

• PADS4 Foundation

Optionally one ore more client applications can be installed using PADS4 Clients installation

Desktop PC

Usually the following components are used/installed on a desktop PC:

- PADS4 CTRL Center.
 This is the web based PADS4 solution. No installation of software is required to run this web app.
- PADS4 Designer (installation by using PADS4 Clients)

- PADS4 System Management (installation by using PADS4 Clients)
- PADS4 Agent (installation by using PADS4 Clients)
- PADS4 Scheduler (installation by using PADS4 Clients)
- PADS4 Messenger (installation by using PADS4 Clients)
- PADS4 Viewer (installation by using PADS4 Clients)
- PADS4 Desktop Viewer (installation by using PADS4 Clients)

Sub Server PC

Usually the following components are installed on a Sub Server PC:

• PADS4 Foundation

The Sub Server is connected to the Main Server (or another Sub Server) and will synchronize the PADS4 database and content library. This way all the content will be transferred over the network from the headoffice to the sub location once. This will prevent the Viewers from synchronizing all the data directly over the network from the head office directly. There are options to synchronize only a subset of the content for each Sub Server using permissions.

NOTES

As a user you may connect to the PADS4 system through a Main Server or a Sub Server. From that Server you are able to watch the whole system as where you connected to the local Server.



What do I need to do to use Sensor module?

Module Sensors

PADS4 contains a module Sensors which allows you to connect to Sensors using PADS4.

Licenses are required to enable this module which is already installed by default.

Please contact your dealer for Sensor Module & Sensor User license(s).

Installing new purchased license

When licenses have been added to your current Product Key, or you retrieved a new Product Key, please follow the steps to activate the new licenses

Please check out the How to enter PADS4 product key page for more information about adding licenses.



What do I need to do to use FIDS module?

Module FIDS

PADS4 contains a module FIDS which allows you to use the FIDS Operator using PADS4.

Licenses are required to enable this module which is already installed by default.

Please contact your dealer for FIDS Module & User license(s).

Installing new purchased license

When licenses have been added to your current Product Key, or you retrieved a new Product Key, please follow the steps to activate the new licenses

Please check out the How to enter PADS4 product key page for more information about adding licenses.



Install PADS4 System

This section explains how to install (parts of) the PADS4 System.




How to install PADS4 Server

Download the PADS4 Foundation Setup

Download PADS4 Foundation from http://go.pads4.com/?fwlink=1010

Execute the installation file (as an Administrator)

Right click with the mouse on the installation file and select run as administrator.



Make sure to read the installation document and license agreement before checking the boxes and installing the software.

Installation folders

Change the installation folders if required.

PADS4 Foundation contains all the files required to run PADS4 on the Server.

NDS Package Manager is required and is used to maintain the components of PADS4 which have


been divided into so called packages.

If the NDS Package Manager is not yet available on you PC, it will also be installed. You may change the installation folder.

If the NDS Package Manager is already installed, the installation folder destination folder option will be hidden.

Optionally change the installation folder if required.

Check the boxes to confirm and press Install to start the installation process.




The installation process will start and show the progress as in the picture above.

Error during installation


In case an error occurs a pop up window will occur. This pop up contains a click HERE link to the log file created.

If you encounter any problems this log file can be of help to investigate the cause of the problem. Every step of the installation process is written to this log.

Error information:



Installation finished



When the installation is finished, you should see the PADS4 Foundation installed successfully message as in the picture above.

Start PADS4 Foundation configuration tool

Check the box if you would like to specify configurations settings. If you start the PADS4 Foundation setup the first time, please check the settings.

Check out the "PADS4 Foundation Configuration" on page 356 page which contains details about the settings

Start PADS4 Clients setup

If you would like to install additional Windows based PADS4 programs on this PC such as PADS4 Scheduler, PADS4 Designer etc. check the box to start the setup after the PADS4 Foundation installation has been completed. This setup allows you to select which Windows based client components need to be installed.

Check out the "How to install PADS4 Windows Client applications" on page 343 page which contains details about the settings

Once you press the Close button, you will be presented with the PADS4 CTRL Center Configuration tool and/or the PADS4 Clients installation wizard.

Network ports used by PADS4

Check out the Network Ports Configurations page for more information about network ports used by PADS4.

Change Sensor database

Option to change the type of database used for storage of sensor data. Click here to show more information.

Important

It is of vital importance that you do not install the PADS4 Foundation on a workstation / Viewer PC (that is only configured for Designer/Scheduler/Content Organizer/Messenger etc.). This will install PADS4 Server functionality on your workstation / Viewer PC, as this would result in setting up the configuration as a Server PC. It is however possible to install the PADS4 Clients software after installing the PADS4 Foundation installation as the machine is then already classified as a Server PC.




How to install PADS4 Sub Server

Download the PADS4 Foundation Setup

Download PADS4 Foundation from http://go.pads4.com/?fwlink=1010

Execute the installation file (as an Administrator)

Right click with the mouse on the installation file and select run as administrator.



Make sure to read the installation document and license agreement before checking the boxes and installing the software.

Installation folders

Change the installation folders if required.

PADS4 Foundation

PADS4 Foundation contains all the files required to run PADS4 on the Server.

NDS Package Manager


NDS Package Manager manages the installed packages.

If the NDS Package Manager is not yet available on you PC, it will also be installed.

If the NDS Package Manager is already installed, the installation folder option will be hidden.

Accept to start installation

Check the boxes to confirm and press Install to start the installation process.




The installation process will start and show the progress as in the picture above.

Error during installation


In case an error occurs a pop up window will occur. This pop up contains a click HERE link to the log file created.

If you encounter any problems this log file can be of help to investigate the cause of the problem. Every step of the installation process is written to this log.

Error information:



Installation finished



When the installation is finished, you should see the PADS4 Foundation installed successfully message as in the picture above.

Start PADS4 Foundation configuration tool

Check the box if you would like to specify configurations settings. If you start the PADS4 Foundation setup the first time, please check the settings.

Check out the "PADS4 Foundation Configuration" on page 356 page which contains details about the settings

Start PADS4 Clients setup

If you would like to install additional Windows based PADS4 programs on this PC such as PADS4 Scheduler, PADS4 Designer etc. check the box to start the setup after the PADS4 Foundation installation has been completed. This setup allows you to select which Windows based client components need to be installed.

Check out the "How to install PADS4 Windows Client applications" on page 343 page which contains details about the settings

Once you press the Close button, you will be presented with the PADS4 CTRL Center Configuration tool and/or the PADS4 Clients installation wizard.

Configuration of Sub Server

Start PADS4 System Management application on the PADS4 Main Server to configure the installed Sub Server.

- Select Servers from the left menu
- Click on Add Sub Server in the ribbonbar on top
- Fill in a name to be displayed in the Agent for this Sub Server
- Specify network settings for the Main Server to connect to the Sub Server
- · Do not forget to add a license for this Server

For additional information please check the manual of the PADS4 Scheduler which can be installed during Windows Clients installation.

Network ports used by PADS4

Check out the Network Ports Configurations page for more information about network ports used by PADS4.

Important

It is of vital importance that you do not install the PADS4 Foundation on a workstation / Viewer PC (that is only configured for Designer/Scheduler/Content Organizer/Messenger etc.). This will install PADS4 Server functionality on your workstation / Viewer PC, as this would result in setting up the configuration as a Server PC. It is however possible to install the PADS4 Clients software after installing the PADS4 Foundation installation as the machine is then already classified as a Server PC.




How to install PADS4 Backup Server

Download the PADS4 Foundation Setup

Download PADS4 Foundation from http://go.pads4.com/?fwlink=1010

Execute the installation file (as an Administrator)

Right click with the mouse on the installation file and select run as administrator.



Make sure to read the installation document and license agreement before checking the boxes and installing the software.

Installation folders

Change the installation folders if required.

PADS4 Foundation

PADS4 Foundation contains all the files required to run PADS4 on the Server.

NDS Package Manager


NDS Package Manager manages the installed packages.

If the NDS Package Manager is not yet available on you PC, it will also be installed.

If the NDS Package Manager is already installed, the installation folder option will be hidden.

Accept to start installation

Check the boxes to confirm and press Install to start the installation process.




The installation process will start and show the progress as in the picture above.

Error during installation


In case an error occurs a pop up window will occur. This pop up contains a click HERE link to the log file created.

If you encounter any problems this log file can be of help to investigate the cause of the problem. Every step of the installation process is written to this log.

Error information:



Installation finished



When the installation is finished, you should see the PADS4 Foundation installed successfully message as in the picture above.

Start PADS4 Foundation configuration tool

Check the box if you would like to specify configurations settings. If you start the PADS4 Foundation setup the first time, please check the settings.

Check out the "PADS4 Foundation Configuration" on page 356 page which contains details about the settings

Start PADS4 Clients setup

If you would like to install additional Windows based PADS4 programs on this PC such as PADS4 Scheduler, PADS4 Designer etc. check the box to start the setup after the PADS4 Foundation installation has been completed. This setup allows you to select which Windows based client components need to be installed.

Check out the "How to install PADS4 Windows Client applications" on page 343 page which contains details about the settings

Once you press the Close button, you will be presented with the PADS4 CTRL Center Configuration tool and/or the PADS4 Clients installation wizard.

Configuration of Backup Server

Start PADS4 System Management application on the PADS4 Main Server to configure the installed Backup Server.

- Select Servers from the left menu
- Click on Add Backup Server in the ribbonbar on top
- Fill in a name to be displayed in the Agent for this Backup Server
- Specify network settings for the Main Server to connect to the Backup Server
- · Do not forget to add a license for this Server

For additional information please check the manual of PADS4 System Management which can be installed during Windows Clients installation.

Network ports used by PADS4

Check out the Network Ports Configurations page for more information about network ports used by PADS4.

Important

It is of vital importance that you do not install the PADS4 Foundation on a workstation / Viewer PC (that is only configured for Designer/Scheduler/Content Organizer/Messenger etc.). This will install PADS4 Server functionality on your workstation / Viewer PC, as this would result in setting up the configuration as a Server PC. It is however possible to install the PADS4 Clients software after installing the PADS4 Foundation installation as the machine is then already classified as a Server PC.



How to enter the PADS4 Product Key

Please follow the following steps to activate the PADS4 product with the provided PADS4 Product Key.

Open PADS4 CTRL Center

After PADS4 has been installed, start PADS4 CTRL Center. PADS4 CTRL Center help can be found here.

Installing PADS4 Product Key from PADS4 CTRL Center

- Open Licenses from the menu on the left.
- Fill in the Product Key provided by your partner or continue the process using the current key when additional licenses have been added to your current Product Key.
- Press the **Activate** button on top to Activate or Reactivate

If there is no internet connection available, an offline reactivation method will become visible. Please follow the steps.


After a License File is send to you, please click on the Upload License file button on top of this page and select the License File.

• Follow the wizard to complete the process.



PADS4 Foundation Configuration

PADS4 Foundation Configuration allows you to specify configuration settings.



Here you are able to specify the ports that PADS4 should be operating on and the IP address of your PADS4 Server PC and press apply when configuration is as desired.

PADS4 Server

- HTTP Port
 - The port used to communicate with the PADS4 Server (default is 9005)
- IP adress
 - By default the IP address of PADS4 Server is localhost (127.0.0.1). Normally PADS4 Foundation and PADS4 Server are located on the same PC.

PADS4 Foundation

- HTTP Port
 - The HTTP port used to host the PADS4 CTRL Center (default is 80)
- HTTPS Port (SSL)

The security certificate for using the PADS4 CTRL Center with SSL

- DNS Host Name Domain which is registered
- · Certificate file .certificate file
- Private Key file .private file

When all settings are successfully applied after click apply, PADS4 Foundation will restart all processes with the new settings.

Tip: Default username and password after installation is for both "user1"

Please change this after the first logon using the account icon on the right top of the webportal.

Be aware that it may take up to 30 seconds based on your hardware specs to restart all processes.

Sensor database type selection

Click here to show the Sensor database type selection page.

Check out if the server is running

If you want to verify that the PADS4 server is running, perform the following check.

Open a webbrowser and specify "http(s)://localhost:<port>. Use https or http based on you settings. Specify the right port number as specified.

The logon page of PADS4 CTRL Center should occur.

PADS4 Clients installation help

Check out the "How to upgrade PADS4 Windows Client applications" on page 363 page for installation instructions on.



Sensor database type selection

By default SQLite is used as database for storage of Sensor data.

Be aware that changing database type will erase all existing data.

Change database type from configuration tool

Select Sensor database from configuration tool window.

Change database type manually

start NDS.DataStorage.ConfigurationTool.exe from PADS4 installation program files folder (default C:\Program Files\NDS\PADS4 Foundation\NDS.DataStorage.ConfigurationTool)

Database types supported

Supported database types are:

- SQLite
- SQL Server
- ProgreSQL
- MongoDB

The databases are open for export of data if required by third party software.



Install PADS4 Viewer

This section explains how to install PADS4 Viewer(s).



How to install PADS4 Viewer


Download

Download PADS4 Clients from http://go.pads4.com/?fwlink=1011

Start setup

Execute the PADS4 Clients.exe installation file as an Administrator and choose one of the available languages.

Check and verify that **PADS4 Version 2020.1** is being installed.




Make sure to read the License Agreement before accepting the terms. Once read, check the check box and press Next.

User selection

Determine for which users PADS4 Clients needs to be installed and press Next.


Select Viewer Installation from the drop down menu and press Next.



Help

Determine whether you wish to install the online help file, reachable by pressing F1 in any of the applications. It will take you directly to the section you are currently working in and we highly recommend installing it.

Specify the Viewer Name and Server Location and press Next.



Determine whether you wish to start PADS4 Clients in **Desktop mode** and if you wish to disable **UAC** (**User Account Control**),we recommend to disable UAC so that PADS4 Clients can run with Administrative Privileges without being prompted.

Optional: If the user itself is not member of the local Administrator group. You can specify to Run Viewer as User that is member of the local Administrator group.

Determine what shortcuts you would like have and in which Destination Folder PADS4 Clients should be installed. Press Install to start the installation of PADS4 Clients.

Installation starts

PADS4 Clients is now installing.

When successfully installed, PADS4 Clients should show the "PADS4 Clients has been successfully installed" message.

Network ports used by PADS4

Check out the Network Ports Configurations page for more information about network ports used by PADS4.



PADS4 Installation Manual

Install PADS4 HTML5 Launcher on Android devices

This page explains how to install the PADS4 HTML5 Launcher to start the PADS4 Viewer on Android based hardware that has been certified by NDS.

Download software

Download the latest PADS4 HTML5 Launcher from: http://go.pads4.com/?fwlink=1004

Install PADS4 HTML5 Launcher from USB stick

- 1. Store the PADS4 HTML5 Launcher APK on a USB stick
- 2. Insert the USB stick into the device
- 3. Select APK Installer
- 4. Select install and browse the USB for the APK
- 5. The message "Do you want to install this application" is displayed. Press the next button until the button "install" appears.
- 6. Press the install button
- 7. After installation press the open button
- 8. The PADS4 HTML5 Launcher app will be started. Enter the location of the PADS4 Server, by specifying a domain name, IP address or pc name of the server where the PADS4 Server is running.
- 9. (Optional) If you changed the default server html server settings of the PADS4 Server, open the advanced settings and specify the correct port number and host/root path.
- 10. Press start, the first time the app will prompt to select your home app. Select PADS4 HTML5 Launcher and select always, if you don't it will prompt the message again.

Be aware that there must be a valid connection to the PADS4 Server after the PADS4 HTML Launcher is started for the first time to allow the device to download and start PADS4 HTML5 Viewer. After the first download PADS4 HTML5 Viewer is able to run offline.

Update PADS4 HTML5 Launcher from USB stick

- 1. Store a new version of the PADS4 HTML5 Launcher APK on a USB stick
- 2. Insert the USB stick into the device
- 3. Open Viewer settings


- 4. Select Launcher settings menu
- 5. Click on the folder icon in the right bottom corner
- 6. Select the mnt folder -> usb_storage
- 7. Select the APK
- 8. The message "Do you want to install an update to this existing application" is displayed.
- 9. Press the install button. The PADS4 HTML5 Launcher automatically starts after installation is finished.



PADS4 Installation Manual

Install PADS4 HTML5 Viewer on SOC devices

Check out the Certified PADS4 HTML5 Viewer section which contains all the supported hardware devices and additional information about how to install and start the device.



PADS4 certified Viewer devices

This section contains all certified PADS4 Viewer devices available (alphabetical sorted).

These devices are tested with every new release of PADS4.

Manufactures (sorted) AOpen BenQ Brightsign Chrome Web Browser (testing purposes) ELO Giada Iadea LG Microsoft Windows Philips ProDVX

Qbic

Samsung



Certified Viewer devices

This section shows the certified Viewer devices from AOpen.



PADS4 Installation Manual

Configuring Aopen AT1032TB

This page explains how to configure the SOC player to run the PADS4 HTML5 Viewer.

When you turn the device on for the first time it will open a configuration wizard. Follow the steps and specify the settings, as mentioned below.

Installation of the PADS4 HTML5 Viewer Android Launcher

PADS4 requires an Android Launcher to be installed.

This launcher can be downloaded from http://go.pads4.com/?fwlink=1004.

Step	Description
01	Start device
02	Start Google chrome app and type in the URL: http://go.pads4.com/?fwlink=1004
03	Click on download
04	Chrome needs storage access to download files -> Click on continue
05	Question: "Allow Chrome to access photos, media and files on your device?" -> Click on Allow
06	Open notifications in the left upper corner of the display
07	Question: "This type of file can harm your device, do you want to keep NDS.DroidLauncher- Signed.apk anyway?" -> Click on OK
08	Open notifications in the left upper corner of the display (again)
09	Click on the NDS.DroidLauncher.apk
10	Message: "For your security your tablet is not allowed to install unknown apps from this source" -> Click on Settings
11	Enable on Allow from this source
12	Click on the Android back button
13	Click on Install
14	After installation is finished, click on Open
15	Viewing full screen message appears. Click on Got it
16	In the HTML5 Viewer enter the IP address of the PADS4 server
17	Select the PADS4 HTML5 Viewer as Home app -> Click on Always
18	Click on Start
19	Please allow the PADS4 HTML5Launcher to modify the system settings. Click on Allow
20	Enable Allow to modify system settings
21	Click on the Android back button
22	Click on Start
23	Question: "Allow PADS4 HTML5Launcher to access photos, media, and files on your device?". Click on Allow

24 Click on Start

When finished the launcher will download the PADS4 HTML5 Viewer software and start. At the left bottom location a connection indicator icon will appear. It will turn green if a valid connection is made to the Server.

If a problem occurs open the viewer settings and have a look at the log which may contain important (error) information.

The first time the device is configured, a valid server connection is required to download the PADS4 HTML5 Viewer software.

Adjust PADS4 Viewer options

PADS4 Viewer options can be changed directly on the device using a mouse.

Click on the left button of the mouse and hold this down until the menu appears. It is also possible to change options remotely using PADS4 CTRL Center or PADS4 Agent.

Open launcher menu from PADS4 HTML5 Viewer

- Open Viewer menu
- Click on the Launcher Settings button
- Click on the gear icon in right bottom corner
- The Android settings open
 If the Hide Status Bar option is turned on, the only way to leave the Android setting is to restart
 the device, by disconnecting the power.

Disable Android navigation bar

Optionally you can disable the navigation bar of the device, it can be used to change the volume on the device. To disable it, follow the next steps:

- Open the Viewer options
- Click on Launcher Settings
- Click on the gear icon in right bottom corner
- Select System Tools
- Click on Disable in the Navigation Bar section
- The only way to leave the Android setting is to restart the device, by disconnecting the power

To perform a factory reset of the device follow the next steps:

Step Description

- Open the settings on Android
- Select Backup & Reset
- Select Factory data reset
- (Optional) Select Erase SD card
- Select Reset tablet
- Select Erase everything

Required firmware

PADS4 requires version kernel 4.4.132

Supported features and limitations

Support	Category	Description	
\subseteq	Automatic PADS4 Software updates	Supported. HTML5 Viewer is automatically	y updated.
Ĭ	Offline mode of device	While offline from the network, the device will still continue to play PADS4 presentations and change planned schedules for 7 days. Scheduled presentations, content and data is cached local.	
	Device		
\subseteq	Portrait mode	Supported. Device will adjust to matically.	the rotation auto-
\subseteq	Block remote control	Option to prevent usage of re operate the screen	mote control to
\subseteq	Transfer protocols	HTTP, HTTPS	
	Turn off display	Not supported	
\subseteq	Cluster Viewer	This device is able to be used	as Cluster Viewer
\subseteq	LED light bar	Supported. Red, Green, Blue, 6 Magenta and White	Cyan, Yellow,
	Elements		
\square	Video element	Maximum number of videos Video rotation	1 video Check out the supplier documentation for more info Not supported

		Seamless videos	Not supported
		Reflection, skew, flip	Not supported
		Streaming	HTTP
	lmage element	Support for JPG, PNG, BMP, G	
	inage element	Supportion Fra, Fina, bivir, c)II
$\underline{\underline{M}}$	Text element	Supported	
\subseteq	Line element	Supported	
\subseteq	Shape element	Supported	
\subseteq	Scrolling text element	Supported	
\subseteq	Formatted text element	Supported	
	Flash element	Not supported	
\subseteq	Table element	Supported	
\subseteq	Interactive button element	Supported	
\subseteq	Web element	Usage of the interactive Addr ported	ess Bar not sup-
	Data connections	Data connections make it pos ation from external sources ir	
Ĭ	Data providers	More than 70 PADS4 data pro of (realtime) data from extern possibility to change and join purpose	nal sources and the
Ĭ	Viewer Variables	Usage of Viewer Variables ca presentations and data conne It also gives the opportunity to the content without changing data providers.	ections. o centrally manage
\square	Property bindings	Apply element properties by sources	using external data
	Rules	Rules will make it possible to situations like realtime data a vior of a presentation automa	nd change the beha-
\subseteq	Presentation rules	Supported	
\subseteq	Page rules	Supported	

\subseteq	Element rules	Supported	
	Device Management	Device manageme	ent which can be performed ation
		Connection state	Device connection state information
		Alerts	Automatically send out alerts when network failures occur for this device
		Reboot	Not supported
		Restart Viewer	Restart PADS4 Viewer
		Shutdown	Not supported
		Wake On Lan	Not supported
	Remote device management Web based and Windows	Screenshot	Retrieve screenshots for what is actually displayed
		Logs	Viewer log, synchronization log, system info
		Viewer Settings	Edit Viewer Settings
		Fonts	Install Fonts on device
		Proof of play	Show Proof of play information
		Blackbox	If help from NDS Support is required, the blackbox contains important information for investigation purposes
	Remarks		
	Colors	Texture and patter	n colors are not supported
口	Transition effects	Horizontal and vertical blinds not supported Splitters, increased circle and sliced circle not supported	
	Content file integrity	PADS4 Content Library file integrity is checked dur- ing synchronization using MD5	
Ç	Proof of play	Local storage limitation of max. 50.000 records on the HTML5 Viewer during offline period. When the 50.000 is hit, the oldest value will be removed first.	



Certified Viewer devices

This section shows the certified Viewer devices from BenQ.



PADS4 Installation Manual

PADS4 Viewer on BenQ series SL<xx>02K

Contents

- 1. First time use
- 1.1. Configuring the device
- 1.2. Resetting the device
- 2. Installing PADS4 Viewer
- 2.1. Checking device firmware
- 2.2. Adjust PADS4 Viewer settings using the options screen

- 2.3. Accessing Android menu when PADS4 Viewer is running
- 3. Supported features & limitations
- 4. Troubleshooting

1. First time use

This document is related to the SL4302K, SL5502K, SL6502K, SL7502K & SL8502K.

During the installation, you will need to configure the PADS4 Server location. Best approach is to complete the installation of the PADS4 Server first, before continuing the configuration of the device.

When you turn the device on for the first time, it will open a configuration wizard. Follow the steps and specify the settings, as mentioned below. (If the configuration wizard does not start, then please first factory reset your device, as described in '1.2 resetting the device'.)

1.1. Configuring the device

Please read the installing section to setup the Viewer. There are no changes that need to be performed before installing the Viewer.

1.2. Resetting the device

If your device was used before, we recommend that you factory reset your device, so that all storage is freed and no other software interferes with the PADS4 Viewer software.

Step	Description
01	Select Settings / System from the android menu
02	Open the settings.
03	Select Factory data reset.
04	Click on Reset phone.
05	Select erase everything.

The device will factory reset and afterwards you will see the welcome screen, please follow the steps as described in '1.1 configuring the device'.

2. Installing PADS4 Viewer

Step	Description

01	In the Welcome screen select Settings.
02	Select All Apps
03	Start the Google Chrome app and type in the URL: http://go.pads4.com/?fwlink=1004
04	Select download
05	Click on Open
06	Click on Settings to change the security settings (Enable the allow option). Press the right mouse button to go back to the all apps menu
07	Click on File Manager
08	Click on Download
09	Select NDS.Droid apk launcher
10	Click on Install
11	After installation turn the display off and on again
12	Select PADS4 HTML5 Launcher as home app and select Always option
13	PADS4 launcher will start. Type in the location of the PADS4 Server, port number and viewername
14	Click on Start
15	Click Allow to modify system settings.
16	Press the right mousebutton to return to the settings
17	Click again on Start
18	the Viewer will start and connect to the server

2.1. Checking device firmware

To run the PADS4 viewer properly on the SL6502K and make sure that all functionality works, you need to have firmware version kernel 4.9.44_s5 installed on the device. Please check using the following steps.

Step	Description
01	Open Settings on Android (or settings in the PADS4 Launcher from the PADS4 options menu)
02	Select System.
03	Select about phone.
04	The build number should match kernel 4.9.44_s5

2.2. Adjust PADS4 Viewer settings using the options screen

You can adjust the PADS4 Viewer settings directly on the display. To enter the options screen on the device itself, hold the left mouse button down or touch the screen for 3 seconds. In the options screen you can also return to the Android app by pressing the Launcher Settings button.

2.3. Accessing Android menu when PADS4 Viewer is running

Open the PADS4 HTML5 Viewer options menu by pressing the left mousebutton for 10 seconds. In the menu there is a Launcher settings button.

3. Supported features and limitations SL6502K

Support	Category	Description		
	Automatic PADS4 Software updates	Supported.		
	э энгэн энгий энги	HTML5 Viewer is automatically updated.		
		While offline from the network, the device will still		
$\overline{\nabla}$	Offline mode of device	continue to play PADS4 presentations and change planned schedules for 7 days.		
	offine filode of device	Scheduled presentations, con-	tent and data is	
		cached local.		
	Device			
\subseteq	Portrait mode	Supported. Device will adjust t matically.	he rotation auto-	
$\overline{\mathbf{Y}}$	Block remote control	Option to prevent usage of re	mote control to	
		operate the screen		
$\mathbf{\Sigma}$	Transfer protocols	HTTP, HTTPS		
Ļ	Turn off display	Not supported		
\subseteq	Cluster Viewer	This device is able to be used	as Cluster Viewer	
	Elements			
			1 video on each	
			page.	
		Maximum number of videos	Check out the supplier doc-	
			umentation for	
\leq	Video element		more info	
		Video rotation	Not supported	
		Seamless videos	Not supported	
		Reflection, skew, flip	Not supported	
		Streaming	HTTP	
\subseteq	Image element	Support for JPG, PNG, BMP, G	IF	

		possibility to change and join the data to fit your purpose Usage of Viewer Variables can simplify your
\square	Data providers	of (realtime) data from external sources and the possibility to change and join the data to fit your purpose
	Data providers	More than 70 PADS4 data providers for retrieval of (realtime) data from external sources and the
	Data connections	ation from external sources inside presentations
		Data connections make it possible to show inform-
\mathbf{M}	Web element	ported
N.	Web element	Usage of the interactive Address Bar not sup-
		supported
\mathbf{M}	Interactive button element	Interactive Data filter & sort dialog window not
		Supported Mouse cursor options not supported
$\overline{\subseteq}$	Table element	Supported
	Flash element	Not supported
\subseteq	Formatted text element	Supported
	-	
\subseteq	Scrolling text element	Supported
\subseteq	Shape element	Supported
Y	Line element	Supported
E	Text element	Supported

		from a remote location	
		Connection state	Device connection state information
		Alerts	Automatically send out alerts when network failures occur for this device
		Reboot	Not supported
		Restart Viewer	Restart PADS4 Viewer
		Shutdown	Not supported
		Wake On Lan	Not supported
\subseteq	Remote device management	Screenshot	Retrieve screenshots for what is actually displayed
	Web based and Windows	Logs	Viewer log, synchronization log, system info
		Viewer Settings	Edit Viewer Settings
		Fonts	Install Fonts on device
		Proof of play	Show Proof of play information
		Blackbox	If help from NDS Support is required, the blackbox con- tains important information for investigation purposes
	Remarks		
	Colors	Texture and patter	n colors are not supported
口	Transition effects		tical blinds not supported d circle and sliced circle not sup-
	Content file integrity	PADS4 Content Lib ing synchronizatio	rary file integrity is checked dur- n using MD5
Ģ	Proof of play	the HTML5 Viewer	ation of max. 50.000 records on during offline period. s hit, the oldest value will be

4. Troubleshooting

Problem	Solution
After install nothing happens	Turn off the display

	and turn it back on after installation is finished
When playing videos after a certain time the Viewer stops working	Please update to the right firmware. Older firmware might have a memory leak issue related to videos



Certified Viewer devices

This section shows the certified Viewer devices from Brightsign.



PADS4 Installation Manual

PADS4 Viewer on Brightsign XD234

Contents

1. Prerequisites

- 1.1. Software version
- 1.2. Supported software devices
- 2. Installing device
- 3 Installation of the PADS4 Viewer
- 3.1 Download the PADS4 Viewer for Brightsign
- 3.2 Install the PADS4 Viewer for Brightsign
- 4. Supported features & limitations

1. Prerequisites

1.1. Software version

The minimum PADS4 Server version required for Brightsign is version 2020.4

Required BrightSign XD234 Operating System (OS) version 8.0.146

- To check the current BrightSign OS version turn on the device without a storage device inserted. It will be displayed as soon as the BrightSign device has started.
- The BrightSign XD234 OS 8.0.146 can be download from https://brightsignbiz.s3.amazonaws.com/firmware/xd4/8.0/8.0.146/brightsign-xd4-update-8.0.146.zip
- You will also find a link with installation instructions on above address to download the OS

1.2. Supported software devices

Currently the only supported storage device is a microSD card.

2. Setup Brightsign device

The setup of the BrightSign device has to be done before the first time use of the device or after a factory reset.

It is not required to perform a factory reset of the BrightSign before installing the PADS4 Viewer. Nevertheless, should you still want to do a factory reset, instructions can be found here: https://brightsign.zendesk.com/hc/en-us/articles/218065977-Performing-a-factory-reset

Step	Description	
01	Insert an empty storage device into the BrightSign	
02	Turn on the BrightSign device	
03	Open http:// <brightsign ip="">/Setup in a browser window to start the manual setup</brightsign>	
04	Click the Next button on the introduction screen of the manual setup	
05	In the network setup screen click on the Ethernet button	
06	Click on the Use current settings button If the settings displayed in the ethernet settings screen are correct. Otherwise click on Change settings and make the necessary adjustments.	
07	Wait until the network diagnostics test finish and click on button Next – BrightAuthor application	
08	Select the BrightAuthor radio button and click on Next Please note PADS4 does not require BrightAuthor, but this is a mandatory step in the BrightSign setup.	
09	In the publishing options screen please select either Local file networking or Standalone. Just as the previous step, this is a mandatory step in the BrightSign setup. No matter which of the two options you select, it will be possible to connect to PADS4 servers in the LAN, WAN or cloud.	
10	Enter or select following for the input fields of the device info: • Device name: can be empty • Customization: Append device serial should be selected • Device description: can be empty • Time zone: select the correct time zone for the device • Firmware: should be the already installed firmware version Click on Finish after checking all the input fields.	
11	The device may reboot a couple of times. Wait until it shows the message your BrightSign player has been set up.	

3 Installation of the PADS4 Viewer

After setup of the BrightSign device, the PADS4 Viewer for BrightSign can downloaded and installed.

3.1 Download the PADS4 Viewer for Brightsign


The PADS4 Viewer for BrightSign can be downloaded from a PADS4 server with following address:

- Protocol: should be either HTTP or HTTPS, depending if you are hosting with a valid public signed SSL certificate
 - Host: DNS name or IP address of the PADS4 Server
- Port: is optional, if the PADS4 server not using the default ports for HTTP or HTTPS, you should specify the port number.
 - The configured hostpath in system management, the default value is PADS4.

Example: http://localhost/pads4/apps/brightsign

Step	Description
01	Enter the address for downloading the PADS4 Viewer for BrightSign in a browser window
02	You will then see a wizard to download a zip file with the PADS4 Viewer for BrightSign
03	Follow the instructions of the wizard

After completing the wizard, you should have following directory and files in the root of the storage device:



3.2 Install the PADS4 Viewer for Brightsign

To install the PADS4 Viewer on BrightSign the only thing left to do is insert the storage device into the BrightSign. If the BrightSign is already running and does not automatically start the PADS4 Viewer after inserting the storage device, you can press the Reset button. The BrightSign will reboot and the PADS4 Viewer will start once it has been rebooted.

Server change

It is possible to change the server of the PADS4 Viewer on BrightSign via the viewer settings. This can be done in the PADS4 Foundation or the PADS4 Agent.

Step	Description	
01	Go to the Server Connection tab of the Viewer Settings in either PADS4 Foundation or PADS4 Agent	
02	Change the server address of the PADS4 server you would like the PADS4 Viewer for BrightSign to connect to. Keep in mind the correct format for the PADS4 server address: <pre><pre>tocol>://<host>:<port>/<hostpath></hostpath></port></host></pre></pre>	
	• Protocol: should be either HTTP or HTTPS, depending if you are hosting with a valid public signed SSL certificate	
	Host: DNS name or IP address of the PADS4 Server	
	• Port: is optional, if the PADS4 server not using the default ports for HTTP or HTTPS, you should specify the port number.	
	• The configured hostpath in system management, the default value is PADS4.	
03	Save the change	
04	The PADS4 Viewer will then disconnect from the previous server and connect to the new server.	

4. Supported features and limitations for Brightsign

Support	Category	Description
\subseteq	Automatic PADS4 Software updates	Supported. HTML5 Viewer is automatically updated.
\boxtimes	Offline mode of device	While offline from the network, the device will still continue to play PADS4 presentations and change planned schedules for 7 days. Scheduled presentations, content and data is cached local.
	Device	
\subseteq	Portrait mode	Supported. Device will adjust the rotation automatically.
\subseteq	Transfer protocols	HTTP, HTTPS
\subseteq	Turn off display	Not supported
\subseteq	Cluster Viewer	This device is able to be used as Cluster Viewer
	Elements	
\square	Video element	Maximum number of videos page.

			Check out the sup- plier doc- umentation for more info
		Video rotation	Not supported
		Seamless videos	Not supported
		Reflection, skew, flip	Not supported
		Streaming	Not supported
	Image element	Support for JPG, PNG, BMP, 0	GIF
M	Text element	Supported	
M	Line element	Supported	
	Shape element	Supported	
	Scrolling text element	Supported	
\subseteq	Formatted text element	Supported	
	Flash element	Not supported	
\subseteq	Table element	Supported	
	Interactive button element	Not Supported	
\subseteq	Web element	Usage of the interactive Addi ported	ress Bar not sup-
	Data connections	Data connections make it pos ation from external sources i	
Ĭ	Data providers	More than 70 PADS4 data providers for retrieval of (realtime) data from external sources and the possibility to change and join the data to fit your purpose	
	Viewer Variables	Usage of Viewer Variables can simplify your presentations and data connections. It also gives the opportunity to centrally manage the content without changing presentations or data providers.	
\square	Property bindings	Apply element properties by sources	using external data
	Rules	Rules will make it possible to situations like realtime data a vior of a presentation autom	nd change the beha-

\subseteq	Presentation rules	Supported	
\subseteq	Page rules	Supported	
\subseteq	Element rules	Supported	
	Device Management	Device management from a remote loca	nt which can be performed ation
		Connection state	Device connection state information
		Alerts	Automatically send out alerts when network failures occur for this device
		Reboot	Reboot device
		Restart Viewer	Restart PADS4 Viewer
		Shutdown	Not supported
	Remote device management Web based and Windows	Wake On Lan	Not supported
\subseteq		Screenshot	Retrieve screenshots for what is actually displayed
		Logs	Viewer log, synchronization log, system info
		Viewer Settings	Edit Viewer Settings
		Fonts	Install Fonts on device
		Proof of play	Show Proof of play information
		Blackbox	If help from NDS Support is required, the blackbox con- tains important information for investigation purposes
	Remarks		
L	Colors	Texture and patter	n colors are not supported
\Box	Transition effects	Horizontal and vertical blinds not supported Splitters, increased circle and sliced circle not supported	
	Content file integrity	PADS4 Content Library file integrity is checked dur- ing synchronization using MD5	
Image: section of the content of the	Proof of play	the HTML5 Viewer	ation of max. 50.000 records on during offline period. hit, the oldest value will be

	union and finat
	removed first.
	removed mad

Remarks

Problem	Solution
A video doesn't play and shows a error loading video file message in the logs	Convert the video so it adheres to a format and codec supported by BrightSign. For more information, see: https://bright-sign.zendesk.com/hc/en-us/articles/218065137-Supported-video-formats-and-codecs
When using a system font (e.g. Arial), the font size on BrightSign is bigger than defined in the presentation	Install fonts using PADS4 System management and use these fonts instead inside presentations. Non-system fonts do not have this issue.



PADS4 Installation Manual

PADS4 Viewer on Brightsign HD224

Contents

- 1. Prerequisites
- 1.1. Software version
- 1.2. Supported software devices
- 2. Installing device
- 3 Installation of the PADS4 Viewer
- 3.1 Download the PADS4 Viewer for Brightsign
- 3.2 Install the PADS4 Viewer for Brightsign

4. Supported features & limitations

1. Prerequisites

1.1. Software version

The minimum PADS4 Server version required for Brightsign is version 2020.4

Required BrightSign HD224 Operating System (OS) version 8.0.146

- To check the current BrightSign OS version turn on the device without a storage device inserted. It will be displayed as soon as the BrightSign device has started.
- The BrightSign HD224 OS 8.0.146 can be download from https://brightsignbiz.s3.amazonaws.com/firmware/hd4/8.0/8.0.146/brightsign-hd4-update-8.0.146.zip
- You will also find a link with installation instructions on above address to download the OS

1.2. Supported software devices

Currently the only supported storage device is a microSD card.

2. Setup Brightsign device

The setup of the BrightSign device has to be done before the first time use of the device or after a factory reset.

It is not required to perform a factory reset of the BrightSign before installing the PADS4 Viewer. Nevertheless, should you still want to do a factory reset, instructions can be found here: https://brightsign.zendesk.com/hc/en-us/articles/218065977-Performing-a-factory-reset

Step	Description
01	Insert an empty storage device into the BrightSign
02	Turn on the BrightSign device
03	Open http:// <brightsign ip="">/Setup in a browser window to start the manual setup</brightsign>
04	Click the Next button on the introduction screen of the manual setup

05	In the network setup screen click on the Ethernet button		
06	Click on the Use current settings button If the settings displayed in the ethernet settings screen are correct.		
	Otherwise click on Change settings and make the necessary adjustments.		
07	Wait until the network diagnostics test finish and click on button Next – BrightAuthor application		
	Select the BrightAuthor radio button and click on Next		
80	Please note PADS4 does not require BrightAuthor, but this is a mandatory step in the BrightSign setup.		
	In the publishing options screen please select either Local file networking or Standalone.		
09	Just as the previous step, this is a mandatory step in the BrightSign setup. No matter which of the two options you select, it will be possible to connect to PADS4 servers in the LAN, WAN or cloud.		
	Enter or select following for the input fields of the device info:		
	• Device name: can be empty		
	Customization: Append device serial should be selected		
10	Device description: can be empty		
	• Time zone: select the correct time zone for the device		
	• Firmware: should be the already installed firmware version Click on Finish after checking all the input fields.		
11	The device may reboot a couple of times. Wait until it shows the message your BrightSign player has been set up.		

3 Installation of the PADS4 Viewer

After setup of the BrightSign device, the PADS4 Viewer for BrightSign can downloaded and installed.


3.1 Download the PADS4 Viewer for Brightsign

- Protocol: should be either HTTP or HTTPS, depending if you are hosting with a valid public signed SSL certificate
 - Host: DNS name or IP address of the PADS4 Server
- Port: is optional, if the PADS4 server not using the default ports for HTTP or HTTPS, you should specify the port number.
 - The configured hostpath in system management, the default value is PADS4.

Example: http://localhost/pads4/apps/brightsign

Step	Description
01	Enter the address for downloading the PADS4 Viewer for BrightSign in a browser window
02	You will then see a wizard to download a zip file with the PADS4 Viewer for BrightSign
03	Follow the instructions of the wizard

After completing the wizard, you should have following directory and files in the root of the storage device:



3.2 Install the PADS4 Viewer for Brightsign

To install the PADS4 Viewer on BrightSign the only thing left to do is insert the storage device into the BrightSign. If the BrightSign is already running and does not automatically start the PADS4 Viewer after inserting the storage device, you can press the Reset button. The BrightSign will reboot and the PADS4 Viewer will start once it has been rebooted.

Server change

It is possible to change the server of the PADS4 Viewer on BrightSign via the viewer settings. This can be done in the PADS4 Foundation or the PADS4 Agent.

Step	Description	
01	Go to the Server Connection tab of the Viewer Settings in either PADS4 Foundation or PADS4 Agent	
	Change the server address of the PADS4 server you would like the PADS4 Viewer for BrightSign to connect to. Keep in mind the correct format for the PADS4 server address: <pre><pre>tocol>://<host>:<port>/<hostpath></hostpath></port></host></pre></pre>	
02	• Protocol: should be either HTTP or HTTPS, depending if you are hosting with a valid public signed SSL certificate	
	Host: DNS name or IP address of the PADS4 Server	
	• Port: is optional, if the PADS4 server not using the default ports for HTTP or HTTPS, you should specify the port number.	

	• The configured hostpath in system management, the default value is PADS4.
03	Save the change
04	The PADS4 Viewer will then disconnect from the previous server and connect to the new server.

4. Supported features and limitations for Brightsign


Support	Category	Description	
\subseteq	Automatic PADS4 Software updates	Supported. HTML5 Viewer is automatically updated.	
\square	Offline mode of device	While offline from the network, the device will still continue to play PADS4 presentations and change planned schedules for 7 days. Scheduled presentations, content and data is cached local.	
	Device		
\subseteq	Portrait mode	Supported. Device will adjust t matically.	he rotation auto-
\subseteq	Transfer protocols	HTTP, HTTPS	
\subseteq	Turn off display	Not supported	
\subseteq	Cluster Viewer	This device is able to be used	as Cluster Viewer
	Elements		
\square	Video element	Maximum number of videos Video rotation	1 video on each page. Check out the supplier documentation for more info Not supported
		Seamless videos Reflection, skew, flip Streaming	Not supported Not supported Not supported
\subseteq	Image element	Support for JPG, PNG, BMP, G	IF
\subseteq	Text element	Supported	
\subseteq	Line element	Supported	

\subseteq	Shape element	Supported	
\subseteq	Scrolling text element	Supported	
\subseteq	Formatted text element	Supported	
	Flash element	Not supported	
\subseteq	Table element	Supported	
	Interactive button element	Not Supported	
\subseteq	Web element	Usage of the interactive Address Bar not supported	
	Data connections	Data connections make it possible to show information from external sources inside presentations	
\subseteq	Data providers	More than 70 PADS4 data providers for retrieval of (realtime) data from external sources and the possibility to change and join the data to fit your purpose	
\subseteq	Viewer Variables	Usage of Viewer Variables can simplify your presentations and data connections. It also gives the opportunity to centrally manage the content without changing presentations or data providers.	
\subseteq	Property bindings	Apply element properties by using external data sources	
	Rules	Rules will make it possible to interact on certain situations like realtime data and change the behavior of a presentation automatically	
\subseteq	Presentation rules	Supported	
\subseteq	Page rules	Supported	
\subseteq	Element rules	Supported	
	Device Management	Device management which can be performed from a remote location	
\subseteq	Remote device management Web based and Windows	Connection state Device connection state information Automatically send out alerts	
	IVVED Dased and Willidows	Alerts when network failures occur for this device	

		Reboot	Reboot device
		Restart Viewer	Restart PADS4 Viewer
		Shutdown	Not supported
		Wake On Lan	Not supported
		Screenshot	Retrieve screenshots for what is actually displayed
		Logs	Viewer log, synchronization log, system info
		Viewer Settings	Edit Viewer Settings
		Fonts	Install Fonts on device
		Proof of play	Show Proof of play information
		Blackbox	If help from NDS Support is required, the blackbox con- tains important information for investigation purposes
	Remarks		
_	Colors	Texture and patter	n colors are not supported
Image: Control of the	Transition effects		tical blinds not supported I circle and sliced circle not sup-
	Content file integrity	PADS4 Content Lib ing synchronization	rary file integrity is checked dur- n using MD5
Image: control of the	Proof of play	the HTML5 Viewer	ation of max. 50.000 records on during offline period. hit, the oldest value will be

Remarks

Problem	Solution
A video doesn't play and shows a error loading video file message in the logs	Convert the video so it adheres to a format and codec supported by BrightSign. For more information, see: https://brightsign.zendesk.com/hc/en-us/articles/218065137-Supported-videoformats-and-codecs
When using a system font (e.g. Arial), the font size on BrightSign is bigger than defined in the	Install fonts using PADS4 System management and use these fonts instead inside presentations. Non-system fonts do not have this issue.



PADS4 Installation Manual

PADS4 Viewer on Brightsign LS424

Contents

- 1. Prerequisites
- 1.1. Software version
- 1.2. Supported software devices
- 2. Installing device
- 3 Installation of the PADS4 Viewer
- 3.1 Download the PADS4 Viewer for Brightsign
- 3.2 Install the PADS4 Viewer for Brightsign
- 4. Supported features & limitations

1. Prerequisites

1.1. Software version

The minimum PADS4 Server version required for Brightsign is version 2020.4

Required BrightSign LS424 Operating System (OS) version 8.0.146

- To check the current BrightSign OS version turn on the device without a storage device inserted. It will be displayed as soon as the BrightSign device has started.
- The BrightSign LS424 OS 8.0.146 can be download from https://brightsignbiz.s3.amazonaws.com/firmware/ls4/8.0/8.0.146/brightsign-ls4-update-8.0.146.zip
- You will also find a link with installation instructions on above address to download the OS

1.2. Supported software devices

Currently the only supported storage device is a microSD card.

2. Setup Brightsign device

The setup of the BrightSign device has to be done before the first time use of the device or after a factory reset.

It is not required to perform a factory reset of the BrightSign before installing the PADS4 Viewer. Nevertheless, should you still want to do a factory reset, instructions can be found here: https://brightsign.zendesk.com/hc/en-us/articles/218065977-Performing-a-factory-reset

Step	Description	
01	Insert an empty storage device into the BrightSign	
02	Turn on the BrightSign device	
03	Open http:// <brightsign ip="">/Setup in a browser window to start the manual setup</brightsign>	
04	Click the Next button on the introduction screen of the manual setup	
05	In the network setup screen click on the Ethernet button	
06	Click on the Use current settings button If the settings displayed in the ethernet settings screen are correct. Otherwise click on Change settings and make the necessary adjustments.	
07	Wait until the network diagnostics test finish and click on button Next – BrightAuthor application	
08	Select the BrightAuthor radio button and click on Next Please note PADS4 does not require BrightAuthor, but this is a mandatory step in the BrightSign setup.	
09	In the publishing options screen please select either Local file networking or Standalone. Just as the previous step, this is a mandatory step in the BrightSign setup. No matter which of the two options you select, it will be possible to connect to PADS4 servers in the LAN, WAN or cloud.	

	Enter or select following for the input fields of the device info:
10	• Device name: can be empty
	Customization: Append device serial should be selected
	Device description: can be empty
	Time zone: select the correct time zone for the device
	• Firmware: should be the already installed firmware version Click on Finish after checking all the input fields.
11	The device may reboot a couple of times. Wait until it shows the message your BrightSign player
	has been set up.

3 Installation of the PADS4 Viewer

After setup of the BrightSign device, the PADS4 Viewer for BrightSign can downloaded and installed.

3.1 Download the PADS4 Viewer for Brightsign

The PADS4 Viewer for BrightSign can be downloaded from a PADS4 server with following address:


col>://<host>:<port>/<hostpath>/Apps/BrightSign

- Protocol: should be either HTTP or HTTPS, depending if you are hosting with a valid public signed SSL certificate
 - Host: DNS name or IP address of the PADS4 Server
- Port: is optional, if the PADS4 server not using the default ports for HTTP or HTTPS, you should specify the port number.
 - The configured hostpath in system management, the default value is PADS4.

Example: http://localhost/pads4/apps/brightsign

Step	Description
01	Enter the address for downloading the PADS4 Viewer for BrightSign in a browser window
02	You will then see a wizard to download a zip file with the PADS4 Viewer for BrightSign
03	Follow the instructions of the wizard

After completing the wizard, you should have following directory and files in the root of the storage device:



3.2 Install the PADS4 Viewer for Brightsign

To install the PADS4 Viewer on BrightSign the only thing left to do is insert the storage device into the BrightSign. If the BrightSign is already running and does not automatically start the PADS4 Viewer after inserting the storage device, you can press the Reset button. The BrightSign will reboot and the PADS4 Viewer will start once it has been rebooted.

Server change

It is possible to change the server of the PADS4 Viewer on BrightSign via the viewer settings. This can be done in the PADS4 Foundation or the PADS4 Agent.

Step	Description
01	Go to the Server Connection tab of the Viewer Settings in either PADS4 Foundation or PADS4 Agent
	Change the server address of the PADS4 server you would like the PADS4 Viewer for BrightSign to connect to. Keep in mind the correct format for the PADS4 server address: <pre><pre><pre>tocol>://<host>:<port>/<hostpath></hostpath></port></host></pre></pre></pre>
02	• Protocol: should be either HTTP or HTTPS, depending if you are hosting with a valid public signed SSL certificate
	Host: DNS name or IP address of the PADS4 Server
	• Port: is optional, if the PADS4 server not using the default ports for HTTP or HTTPS, you should specify the port number.
	• The configured hostpath in system management, the default value is PADS4.
03	Save the change
04	The PADS4 Viewer will then disconnect from the previous server and connect to the new server.

4. Supported features and limitations for Brightsign

Support	Category	Description
\subseteq	Automatic PADS4 Software updates	Supported.


		HTML5 Viewer is automaticall	y updated.
	Offline mode of device	While offline from the network continue to play PADS4 prese planned schedules for 7 days. Scheduled presentations, concached local.	c, the device will still ntations and change
	Device		
\square	Portrait mode	Supported. Device will adjust matically.	the rotation auto-
\triangle	Transfer protocols	HTTP, HTTPS	
\subseteq	Turn off display	Not supported	
\subseteq	Cluster Viewer	This device is able to be used	as Cluster Viewer
	Elements		
¥	Video element	Maximum number of videos Video rotation Seamless videos Reflection, skew, flip Streaming	1 video on each page. Check out the supplier documentation for more info Not supported Not supported Not supported Not supported Not supported
\subseteq	Image element	Support for JPG, PNG, BMP, G	IF
\leq	Text element	Supported	
\leq	Line element	Supported	
\subseteq	Shape element	Supported	
\leq	Scrolling text element	Supported	
\subseteq	Formatted text element	Supported	
	Flash element	Not supported	
\subseteq	Table element	Supported	
	Interactive button element	Not Supported	

\subseteq	Web element	Usage of the intera	active Address Bar not sup-
		Portou	
	Data connections		nake it possible to show inform- I sources inside presentations
\square	Data providers	of (realtime) data f	54 data providers for retrieval rom external sources and the ge and join the data to fit your
M	Viewer Variables	presentations and It also gives the op	ariables can simplify your data connections. portunity to centrally manage t changing presentations or
\subseteq	Property bindings	Apply element pro sources	perties by using external data
	Rules	•	ossible to interact on certain ime data and change the beha-
\subseteq	Presentation rules	Supported	,
\subseteq	Page rules	Supported	
\subseteq	Element rules	Supported	
	Device Management	Device manageme from a remote loca	nt which can be performed ation
		Connection state	Device connection state information
		Alerts	Automatically send out alerts when network failures occur for this device
_	Remote device management	Reboot	Reboot device
\leq		Restart Viewer	Restart PADS4 Viewer
	Web based and Windows	Shutdown	Not supported
		Wake On Lan	Not supported
		Screenshot	Retrieve screenshots for what is actually displayed
		Logs	Viewer log, synchronization log, system info

	T	1	
		Viewer Settings	Edit Viewer Settings
		Fonts	Install Fonts on device
		Proof of play	Show Proof of play information
		Blackbox	If help from NDS Support is required, the blackbox con- tains important information for investigation purposes
	Remarks		
	Colors	Texture and patter	n colors are not supported
Q	Transition effects	Horizontal and vertical blinds not supported Splitters, increased circle and sliced circle not supported	
	Content file integrity	PADS4 Content Lib ing synchronization	rary file integrity is checked dur- n using MD5
Ç	Proof of play	the HTML5 Viewer	ation of max. 50.000 records on during offline period. hit, the oldest value will be

Remarks

Problem	Solution
A video doesn't play and shows a	Convert the video so it adheres to a format and codec supported by BrightSign. For more information, see: https://bright-sign.zendesk.com/hc/en-us/articles/218065137-Supported-video-formats-and-codecs
When using a system font (e.g. Arial), the font size on BrightSign is bigger than defined in the presentation	Install fonts using PADS4 System management and use these fonts instead inside presentations. Non-system fonts do not have this issue.



Configuring Chrome Browser for testing

This page explains how to configure a Windows Chrome Browser to run the PADS4 HTML5 Viewer. This can be of use for some testing purposes. Be aware that this does not contains system related functionality like reboot.

Using a Chrome Web Browser as a 24/7 solution is not recommended. Watch functionality which is available on certified Android systems will check memory consumption and is able to restart when needed to keep the system up and running. This is not working on a Chrome Web Browser.

Start of Chrome Browser on Microsoft Windows for testing

PADS4 requires Chrome to be installed.

Step	Description
01	Start device
02	Start Chrome Browser
03	http:// <server>/PADS4/apps/viewer/</server>

Required software

PADS4 requires Chrome Browser version 70 or higher

Support	Category	Description
	Automatic PADS4 Software updates	Supported.
Ľ	Automatic PAD34 301tware updates	HTML5 Viewer is automatically updated.
	Offline mode of device	While offline from the network, the device will still continue to play PADS4 presentations and change planned schedules for 7 days. Scheduled presentations, content and data is cached local.
	Device	
\subseteq	Portrait mode	Supported. Device will adjust the rotation automatically.
	Block remote control	Option to prevent usage of remote control to operate the screen

$\overline{\mathbf{A}}$	Transfer protocols	HTTP, HTTPS		
$\overline{\Box}$	Turn off display	Not supported	Not supported	
\subseteq	Cluster Viewer	This device is able to be used	This device is able to be used as Cluster Viewer	
\square	LED light bar	Supported. Red, Green, Blue, Magenta and White	Supported. Red, Green, Blue, Cyan, Yellow, Magenta and White	
	Elements			
		Maximum number of videos	16 videos (related to hardware performance)	
\subseteq	Video element	Video rotation	Not supported	
		Seamless videos Reflection, skew, flip Streaming	Not supported Not supported HTTP	
\subseteq	Image element	Support for JPG, PNG, BMP, G	IF	
\subseteq	Text element	Supported		
\subseteq	Line element	Supported		
\subseteq	Shape element	Supported		
\subseteq	Scrolling text element	Supported		
\subseteq	Formatted text element	Supported		
	Flash element	Not supported		
\subseteq	Table element	Supported		
\subseteq	Interactive button element	Supported		
\subseteq	Web element	Usage of the interactive Addre ported	ess Bar not sup-	
		Data connections make it	sible to show inform	
	Data connections	Data connections make it post ation from external sources in		
∑	Data providers	More than 70 PADS4 data pro of (realtime) data from extern possibility to change and join purpose	al sources and the	
\subseteq	Viewer Variables	Usage of Viewer Variables can presentations and data conne		

			pportunity to centrally manage t changing presentations or
Ŋ	Property bindings	· ·	perties by using external data
	Rules		oossible to interact on certain time data and change the beha- iion automatically
Y	Presentation rules	Supported	
\leq	Page rules	Supported	
\subseteq	Element rules	Supported	
	Device Management	Device manageme from a remote local	ent which can be performed ation
		Connection state	Device connection state information
		Alerts	Automatically send out alerts when network failures occur for this device
		Reboot	Not supported
		Restart Viewer	Not supported
		Shutdown	Not supported
		Wake On Lan	Not supported
\subseteq	Remote device management	Screenshot	Retrieve screenshots for what is actually displayed
	Web based and Windows	Logs	Viewer log, synchronization log, system info
		Viewer Settings	Edit Viewer Settings
		Fonts	Install Fonts on device
		Proof of play	Show Proof of play information
		Blackbox	If help from NDS Support is required, the blackbox contains important information for investigation purposes
	Remarks		

	Colors	Texture and pattern colors are not supported
口	Transition effects	Horizontal and vertical blinds not supported Splitters, increased circle and sliced circle not sup- ported
	Content file integrity	PADS4 Content Library file integrity is checked during synchronization using MD5
Q	Proof of play	Local storage limitation of max. 50.000 records on the HTML5 Viewer during offline period. When the 50.000 is hit, the oldest value will be removed first.



Certified Viewer devices

This section shows the certified Viewer devices from ELO.



Configuring ELO I-Series 2

This page explains how to configure the SOC player to run the PADS4 HTML5 Viewer.

Welcome

When you turn the device on for the first time it will automatically open a welcome screen. Continue on this screen by pressing the OK button twice.

Installation of the PADS4 HTML5 Viewer Android Launcher

PADS4 requires an Android Launcher to be installed.

This launcher can be downloaded from http://go.pads4.com/?fwlink=1004.

Step Step Description

- 1 Store the PADS HTML5 Launcher apk on a USB stick
- 2 Insert the USB stick into the device
- 3 On the device select the Apk Installer app
- 4 Select install and browse the USB for the apk
- The message "Do you want to install this application" is displayed. Press the next button until the button "install" appears
- 6 Press the install button
- 7 After installation press the open button
- The PADS4 HTML5 Launcher app will be started. Enter the location of the PADS4 Server, by specifying a domain name, IP address or pc name of the server where the PADS4 Server is running.
- Optional) If you changed the default server html server settings of the PADS server, open the advanced settings and specify the correct port number and host/root path.
- Press start, the first time the app will prompt to select your home app. Select PADS4 HTML5 Launcher and select always, if you don't it will prompt the message again.

When finished the launcher will download the PADS4 HTML5 Viewer software and start. At the left bottom location a connection indicator icon will appear. It will turn green if a valid connection is made to the Server.

If a problem occurs open the viewer settings and have a look at the log which may contain important (error) information.

The first time the device is configured, a valid server connection is required to download the PADS4 HTML5 Viewer software.

Upgrading PADS4 Launcher from USB stick

When a new PADS4 Launcher is available follow the next steps to upgrade.

Step Step Description

- 1 Store the new PADS HTML5 Launcher apk on a USB stick
- 2 Insert the USB stick into the device
- 3 Open the PADS4 Viewer settings
- 4 Select Launcher settings from the menu
- 5 Click on the folder icon in the right bottom corner
- Navigate to the newer apk on the usb stick, by selecting the storage folder and then the usb_storage folder
- 7 Select the apk
- 8 The message "Do you want to install an update to this existing application" is displayed.
- 9 Press the install button. The PADS4 HTML5 Launcher should automatically start when installed.

Adjust PADS4 Viewer options

PADS4 Viewer options can be changed directly on the device using a mouse.

Click on the left button of the mouse and hold this down until the menu appears. It is also possible to change options remotely using PADS4 CTRL Center or PADS4 Agent.

Open launcher menu from PADS4 HTML5 Viewer

- Open Viewer menu
- Click on the Launcher Settings button
- Click on the gear icon in right bottom corner
- The Android settings open
 If the Hide Status Bar option is turned on, the only way to leave the Android setting is to restart
 the device, by disconnecting the power.

Disable Android navigation bar

Optionally you can disable the navigation bar of the device, it can be used to change the volume on the device. To disable it, follow the next steps:

- Open the Viewer options
- Click on Launcher Settings
- Click on the gear icon in right bottom corner
- Select System Tools

- Click on Disable in the Navigation Bar section
- The only way to leave the Android setting is to restart the device, by disconnecting the power

To perform a factory reset of the device follow the next steps:

Step Description

- Open the settings on Android
- Select Backup & Reset
- Select Factory data reset
- (Optional) Select Erase SD card
- Select Reset tablet
- Select Erase everything

Supported features and limitations

*ELO series based on Microsoft Windows are fully compatible with the PADS4 Windows Viewer. Please check the Windows documentation for more info.

Support	Category	Description
\subseteq	Automatic PADS4 Software updates	Supported. HTML5 Viewer is automatically updated.
\subseteq	Offline mode of device	While offline from the network, the device will still continue to play PADS4 presentations and change planned schedules for 7 days. Scheduled presentations, content and data is cached local.
	Device	
\subseteq	Portrait mode	Supported.
\subseteq	Block remote control	Option to prevent usage of remote control to operate the screen
\subseteq	Transfer protocols	HTTP, HTTPS
,	Turn off display	Not supported
\subseteq	Cluster Viewer	This device is able to be used as Cluster Viewer
	Elements	
\square	Video element	Maximum number of videos HD video (30fps)

		Video rotation Seamless videos Playback speed adjustment Reflection, skew, flip	maximum of 2x HD video (60fps) Check out the supplier documentation for more info Supported Supported Supported Supported Supported
	Image element	Supported	Supported
	Image element	Supported	
$\mathbf{\Sigma}$	Text element	Supported	
\square	Line element	Supported	
	Shape element	Supported	
	Scrolling text element	Supported	
\subseteq	Formatted text element	Supported	
	Flash element	Supported	
	Table element	Supported	
\square	Interactive button element	Supported Mouse cursor options not sul Interactive Data filter & sort d supported	•
\subseteq	Web element	Usage of the interactive Addr ported	ess Bar not sup-
	Data connections	Data connections make it pos ation from external sources in	
\subseteq	Data providers	More than 70 PADS4 data proof (realtime) data from extern possibility to change and join purpose	nal sources and the
Ĭ	Viewer Variables	Usage of Viewer Variables ca presentations and data conne It also gives the opportunity to the content without changing data providers.	ections. o centrally manage

\subseteq	Property bindings	Apply element pro	perties by using external data
	Rules	-	possible to interact on certain time data and change the beha- ion automatically
\subseteq	Presentation rules	Supported	
\subseteq	Page rules	Supported	
\subseteq	Element rules	Supported	
	Device Management	Device management which can be performed from a remote location	
		Connection state	Device connection state information
		Alerts	Automatically send out alerts when network failures occur for this device
		Reboot	Supported
		Restart Viewer	Supported
		Shutdown	Supported
	Remote device management	Wake On Lan	Supported
$\overline{\sim}$	Nemote device management	Screenshot	Supported
	Web based and Windows	Logs	Viewer log, synchronization log, system info
		Viewer Settings	Edit Viewer Settings
		Fonts	Install Fonts on device
		Proof of play	Show Proof of play inform- ation
		Blackbox	If help from NDS Support is required, the blackbox contains important information for investigation purposes
	Remarks		
_	Content file integrity	PADS4 Content Lib ing synchronizatio	orary file integrity is checked dur- n using MD5
L		g 5y11c111 01112atio	



Certified Viewer devices

This section shows the certified Viewer devices from Giada.



Configuring Giada DN73

This page explains how to configure the SOC player to run the PADS4 HTML5 Viewer.

When you turn the device on for the first time it will automatically show the configuration wizard. Follow the steps and specify settings.

Installation of the PADS4 HTML5 Viewer Android Launcher

PADS4 requires an Android Launcher to be installed.

This launcher can be downloaded from http://go.pads4.com/?fwlink=1004.

Step Step Description

- 1 Store the PADS HTML5 Launcher apk on a USB stick
- 2 Insert the USB stick into the device
- 3 On the device select the Apk Installer app
- 4 Select install and browse the USB for the apk
- The message "Do you want to install this application" is displayed. Press the next button until the button "install" appears
- 6 Press the install button
- 7 After installation press the open button
- The PADS4 HTML5 Launcher app will be started. Enter the location of the PADS4 Server, by specifying a domain name, IP address or pc name of the server where the PADS4 Server is running.
- (Optional) If you changed the default server html server settings of the PADS server, open the advanced settings and specify the correct port number and host/root path.
- Press start, the first time the app will prompt to select your home app. Select PADS4 HTML5 Launcher and select always, if you don't it will prompt the message again.

When finished the launcher will download the PADS4 HTML5 Viewer software and start. At the left bottom location a connection indicator icon will appear. It will turn green if a valid connection is made to the Server.

If a problem occurs open the viewer settings and have a look at the log which may contain important (error) information.

The first time the device is configured, a valid server connection is required to download the PADS4 HTML5 Viewer software.

Upgrading PADS4 Launcher from USB stick

When a new PADS4 Launcher is available follow the next steps to upgrade.

Step Step Description

- 1 Perform a factory reset
- 2 Follow the steps for the installation of the PADS4 HTML5 Viewer Android Launcher

Adjust PADS4 Viewer options

PADS4 Viewer options can be changed directly on the device using a mouse.

Click on the left button of the mouse and hold this down until the menu appears. It is also possible to change options remotely using PADS4 CTRL Center or PADS4 Agent.

Open launcher menu from PADS4 HTML5 Viewer

- Open Viewer menu
- Click on the Launcher Settings button
- Click on the gear icon in right bottom corner
- The Android settings open
 If the Hide Status Bar option is turned on, the only way to leave the Android setting is to restart
 the device, by disconnecting the power.

To perform a factory reset of the device follow the next steps:

Step Description

- Open the settings on Android
- Select Backup & Reset
- Select Factory data reset
- Select Reset tablet
- Select Erase everything

Required firmware

PADS4 requires version kernel 3.10 Build rk3328-box

Support	Category	Description
\subseteq	IAutomatic PADS4 Software undates	Supported. HTML5 Viewer is automatically updated.
\subseteq	Offline mode of device	While offline from the network, the device will still continue to play PADS4 presentations and change

		planned schedules for 7 days Scheduled presentations, con cached local.	
	Device		
\subseteq	Portrait mode	Supported. Device will adjust matically.	the rotation auto-
\subseteq	Block remote control	Option to prevent usage of remote control to operate the screen	
Y	Transfer protocols	HTTP, HTTPS	
	Turn off display	Not supported	
	Cluster Viewer	This device is able to be used as Cluster Viewer	
	Elements		
⋈	Video element	Maximum number of videos	4 videos Check out the supplier documentation for more info
ت	video element	Video rotation	Supported
		Seamless videos	Not supported
		Reflection, skew, flip	Not supported
		Streaming	HTTP
Y	Image element	Support for JPG, PNG, BMP, G	GIF
\subseteq	Text element	Supported	
	Line element	Supported	
\subseteq	Shape element	Supported	
	Scrolling text element	Supported	
M	Formatted text element	Supported	
	Flash element	Not supported	
\subseteq	Table element	Supported	
Ĭ	Interactive button element	Supported Mouse cursor options not sup Interactive Data filter & sort d supported	-

\subseteq	Web element	Usage of the intera	active Address Bar not sup-	
		p = · · · ·		
	Data connections		make it possible to show inform- Il sources inside presentations	
\subseteq	Data providers	of (realtime) data f	S4 data providers for retrieval from external sources and the ge and join the data to fit your	
Y	Viewer Variables	presentations and It also gives the op	Usage of Viewer Variables can simplify your presentations and data connections. It also gives the opportunity to centrally manage the content without changing presentations or data providers.	
\subseteq	Property bindings	Apply element pro sources	Apply element properties by using external data	
	Rules	•	possible to interact on certain time data and change the beha- tion automatically	
\leq	Presentation rules	Supported		
\subseteq	Page rules	Supported		
\subseteq	Element rules	Supported		
	Device Management	Device manageme	ent which can be performed ation	
		Connection state	Device connection state information	
		Alerts	Automatically send out alerts when network failures occur for this device	
_	Remote device management	Reboot	Not supported	
\leq		Restart Viewer	Restart PADS4 Viewer	
	Web based and Windows	Shutdown	Not supported	
		Wake On Lan	Not supported	
		Screenshot	Retrieve screenshots for what is actually displayed	
		Logs	Viewer log, synchronization log, system info	

	1		
		Viewer Settings	Edit Viewer Settings
		Fonts	Install Fonts on device
		Proof of play	Show Proof of play information
		Blackbox	If help from NDS Support is required, the blackbox con- tains important information for investigation purposes
	Remarks		
	Colors	Texture and patter	n colors are not supported
Image: section of the content of the	Transition effects		tical blinds not supported I circle and sliced circle not sup-
\Box	Content file integrity	PADS4 Content Lib ing synchronization	rary file integrity is checked dur- n using MD5
Image: Control of the	Proof of play	the HTML5 Viewer	ation of max. 50.000 records on during offline period. hit, the oldest value will be



Configuring Giada DN74

This page explains how to configure the SOC player to run the PADS4 HTML5 Viewer.

When you turn the device on for the first time it will automatically show the configuration wizard. Follow the steps and specify settings.

Installation of the PADS4 HTML5 Viewer Android Launcher

PADS4 requires an Android Launcher to be installed.

This launcher can be downloaded from http://go.pads4.com/?fwlink=1004.

Step Step Description

- Run the internet browser app (for example Lightning or Browser) and type in the URL: http://go.pads4.com/?fwlink=1004
- 2 Click on download
- 3 Click on Continue then Allow
- 4 Wait about 1 minute (loading screen will not disappear when finished downloading)
- 5 Go to Android apps and click on files > Downloads
- 6 Double click on the NDS Android HTML5 Launcher
- 7 Allow unknown apps to be installed if prompted click on settings > Allow from this source
- 8 Click on the back arrow and then click on install in the lower right corner
- 9 After installing click on open in the lower right corner
- 10 Type in the location of the PADS4 Server
- 11 Click on start and select the PADS4 HTML5 Viewer as Home app and select 'Always'
- 12 Click on Start again
- 13 Allow to modify system settings
- 14 Click on the back arrow
- 15 Click on Allow to access media files
- 16 You may now start the HTML5 Viewer

When finished the launcher will download the PADS4 HTML5 Viewer software and start. At the left bottom location a connection indicator icon will appear. It will turn green if a valid connection is made to the Server.

If a problem occurs open the viewer settings and have a look at the log which may contain important (error) information.

The first time the device is configured, a valid server connection is required to download the PADS4 HTML5 Viewer software.

Upgrading PADS4 Launcher

When a new PADS4 Launcher is available follow the next steps to upgrade.

Step Step Description

- 1 Perform a factory reset
- 2 Follow the steps for the installation of the PADS4 HTML5 Viewer Android Launcher

Adjust PADS4 Viewer options

PADS4 Viewer options can be changed directly on the device using a mouse.

Click on the left button of the mouse and hold this down until the menu appears. It is also possible to change options remotely using PADS4 CTRL Center or PADS4 Agent.

Open launcher menu from PADS4 HTML5 Viewer

- Open Viewer menu
- Click on the Launcher Settings button
- Click on the gear icon in right bottom corner
- The Android settings open
 If the Hide Status Bar option is turned on, the only way to leave the Android setting is to restart
 the device, by disconnecting the power.

To perform a factory reset of the device follow the next steps:

Step Description

- Open the settings on Android
- Select Backup & Reset
- Select Factory data reset
- Select Reset tablet
- Select Erase everything

Required firmware

PADS4 requires version kernel 4.4.126 Build rk3399-all

Minimum PADS4 Launcher 1.7.0

Support	Category	Description	
\subseteq	Automatic PADS4 Software updates	Supported. HTML5 Viewer is automatically	/ undated
⊠	Offline mode of device	While offline from the network, the device will sti continue to play PADS4 presentations and chang planned schedules for 7 days. Scheduled presentations, content and data is cached local.	
	Device		
\subseteq	Portrait mode	Supported. Device will adjust t matically.	the rotation auto-
\subseteq	Block remote control	Option to prevent usage of remote control to operate the screen	
\subseteq	Transfer protocols	HTTP, HTTPS	
	Turn off display	Not supported	
\subseteq	Cluster Viewer	This device is able to be used	as Cluster Viewer
	Elements		
	Video element	Maximum number of videos Video rotation Seamless videos	2 videos Check out the supplier documentation for more info Supported Not supported
		Reflection, skew, flip Streaming	Not supported HTTP
\subseteq	Image element	Support for JPG, PNG, BMP, G	
\leq	Text element	Supported	
\subseteq	Line element	Supported	
\subseteq	Shape element	Supported	
\subseteq	Scrolling text element	Supported	
\subseteq	Formatted text element	Supported	

	Flash element	Not supported
N	Table element	Supported
\square	Interactive button element	Supported Mouse cursor options not supported Interactive Data filter & sort dialog window not supported
\square	Web element	Usage of the interactive Address Bar not supported
	Data connections	Data connections make it possible to show information from external sources inside presentations
\square	Data providers	More than 70 PADS4 data providers for retrieval of (realtime) data from external sources and the possibility to change and join the data to fit your purpose
M	Viewer Variables	Usage of Viewer Variables can simplify your presentations and data connections. It also gives the opportunity to centrally manage the content without changing presentations or data providers.
\subseteq	Property bindings	Apply element properties by using external data sources
	Rules	Rules will make it possible to interact on certain situations like realtime data and change the behavior of a presentation automatically
\subseteq	Presentation rules	Supported
\subseteq	Page rules	Supported
Ŋ	Element rules	Supported
	Device Management	Device management which can be performed from a remote location
\square	Remote device management Web based and Windows	Connection state Device connection state information Automatically send out alerts when network failures occur for this device Reboot Not supported

		Restart Viewer	Restart PADS4 Viewer
		Shutdown	Not supported
		Wake On Lan	Not supported
		Screenshot	Retrieve screenshots for what is actually displayed
		Logs	Viewer log, synchronization log, system info
		Viewer Settings	Edit Viewer Settings
		Fonts	Install Fonts on device
		Proof of play	Show Proof of play information
		Blackbox	If help from NDS Support is required, the blackbox con- tains important information for investigation purposes
	Remarks		
لــا	Colors	Texture and patter	rn colors are not supported
\Box	Transition effects		rtical blinds not supported d circle and sliced circle not sup-
\Box	Content file integrity	PADS4 Content Lib ing synchronizatio	orary file integrity is checked dur- n using MD5
Q	Proof of play	the HTML5 Viewer	tation of max. 50.000 records on during offline period. s hit, the oldest value will be



Configuring Giada DM6

This page explains how to configure the player to run the PADS4 HTML5 Viewer.

Installation of the PADS4 Viewer

When you turn the device on for the first time, follow the instructions to install a PADS4 Viewer onto a windows device.

How to Install PADS4 Viewer



Certified Viewer devices

This section shows the certified Viewer devices from ladea.



Configuring IAdea XDS-1078

This page explains how to configure the SOC player to run the PADS4 HTML5 Viewer.

When you turn the device on for the first time it will automatically show a welcome screen. Press OK twice. Follow the steps and specify settings, as mentioned in the table below.

Configuring the device for PADS4 HTML5 Viewer Laucher

By default, the network settings are disabled on the device. Also because it is a touch device you want to disable the system status bar, so you cannot close the viewer app. To configure these settings.

- Open the settings on Android
- Make sure that either Wi fi and/or Ethernet is enabled
- To disable the status bar, select Display and check the hide status bar option
- To disable the physical button on the device, select Physical Button Manager and uncheck the Enable Physical Buttons option

Installation of the PADS4 HTML5 Viewer Android Launcher

PADS4 requires an Android Launcher to be installed.

This launcher can be downloaded from http://go.pads4.com/?fwlink=1004.

Step Step Description

- 1 Store the PADS HTML5 Launcher apk on a USB stick
- 2 Insert the USB stick into the device
- 3 On the device select the Apk Installer app
- 4 Select install and browse the USB for the apk
- The message "Do you want to install this application" is displayed. Press the next button until the button "install" appears
- 6 Press the install button
- 7 After installation press the open button
- The PADS4 HTML5 Launcher app will be started. Enter the location of the PADS4 Server, by specifying a domain name, IP address or pc name of the server where the PADS4 Server is running.
- (Optional) If you changed the default server html server settings of the PADS server, open the advanced settings and specify the correct port number and host/root path.
- Press start, the first time the app will prompt to select your home app. Select PADS4 HTML5 Launcher and select always, if you don't it will prompt the message again.

When finished the launcher will download the PADS4 HTML5 Viewer software and start. At the left bottom location a connection indicator icon will appear. It will turn green if a valid connection is made to the Server.

If a problem occurs open the viewer settings and have a look at the log which may contain important (error) information.

The first time the device is configured, a valid server connection is required to download the PADS4 HTML5 Viewer software.

Adjust PADS4 Viewer options

PADS4 Viewer options can be changed directly on the device using a mouse.

Click on the left button of the mouse and hold this down until the menu appears or touch the panel for 3 seconds.

It is also possible to change options remotely using PADS4 CTRL Center or PADS4 Agent.

Open launcher menu from PADS4 HTML5 Viewer

- Open Viewer menu
- Click on the Launcher Settings button
- Click on the gear icon in right bottom corner
- The Android settings open
 If the Hide Status Bar option is turned on, the only way to leave the Android setting is to restart
 the device, by disconnecting the power.

To perform a factory reset of the device follow the next steps:

Step Description

- Open the settings on Android
- Select Backup & Reset
- Select Factory data reset
- (Optional) Select Erase SD card
- Select Reset tablet
- Select Erase everything

Required firmware

PADS4 requires kernel version 2.0.1

Support	Category	Description	
\subseteq	Automatic PADS4 Software updates	Supported. HTML5 Viewer is automatically	y updated.
\square	Offline mode of device	While offline from the network continue to play PADS4 preser planned schedules for 7 days. Scheduled presentations, contached local.	ntations and change
	Device		
\subseteq	Portrait mode	Supported. Device will adjust t matically.	the rotation auto-
\subseteq	Block remote control	Option to prevent usage of re operate the screen	mote control to
\subseteq	Transfer protocols	HTTP, HTTPS	
	Turn off display	Not supported	
\subseteq	Cluster Viewer	This device is able to be used	as Cluster Viewer
M	LED light bar	Supported The alpha color defines the br color. The RGB values specify the co Alpha value of 0: the light is of 255: the light is at its brightest	lor. f. Alpha value of
	Video element	Maximum number of videos Video rotation Seamless videos	1 HD video (max 30fps) Check out the sup- plier doc- umentation for more info Supported Not supported
	lmage element	Reflection, skew, flip Streaming Support for JPG, PNG, BMP, G	Not supported HTTP

		possibility to change and join the data to fit your purpose Usage of Viewer Variables can simplify your
\square	Data providers	of (realtime) data from external sources and the possibility to change and join the data to fit your purpose
	Data providers	More than 70 PADS4 data providers for retrieval of (realtime) data from external sources and the
	Data connections	ation from external sources inside presentations
		Data connections make it possible to show inform-
\mathbf{M}	Web element	ported
N.	Web element	Usage of the interactive Address Bar not sup-
		supported
\mathbf{M}	Interactive button element	Interactive Data filter & sort dialog window not
		Supported Mouse cursor options not supported
$\overline{\subseteq}$	Table element	Supported
	Flash element	Not supported
\subseteq	Formatted text element	Supported
	-	
\subseteq	Scrolling text element	Supported
\subseteq	Shape element	Supported
Y	Line element	Supported
E	Text element	Supported

		from a remote loca	ation
		Connection state	Device connection state information
		Alerts	Automatically send out alerts when network failures occur for this device
		Reboot	Not supported
		Restart Viewer	Restart PADS4 Viewer
		Shutdown	Not supported
\square		Wake On Lan	Not supported
	Remote device management	Screenshot	Retrieve screenshots for what is actually displayed
	Web based and Windows	Logs	Viewer log, synchronization log, system info
		Viewer Settings	Edit Viewer Settings
		Fonts	Install Fonts on device
		Proof of play	Show Proof of play information
		Blackbox	If help from NDS Support is required, the blackbox con- tains important information for investigation purposes
	Remarks		
	Colors	Texture and patter	n colors are not supported
	Transition effects		tical blinds not supported d circle and sliced circle not sup-
	Content file integrity	PADS4 Content Lib ing synchronizatio	rary file integrity is checked dur- n using MD5
\Box	Proof of play	the HTML5 Viewer	ation of max. 50.000 records on during offline period. hit, the oldest value will be



Configuring IAdea XDS-1088

This page explains how to configure the SOC player to run the PADS4 HTML5 Viewer.

When you turn the device on for the first time it will open a configuration wizard. Follow the steps and specify the settings, as mentioned below.

Installation of the PADS4 HTML5 Viewer Android Launcher

PADS4 requires an Android Launcher to be installed.

This launcher can be downloaded from http://go.pads4.com/?fwlink=1004.

Step Step Description

- 1 Store the PADS HTML5 Launcher apk on a USB stick
- 2 Insert the USB stick into the device
- 3 On the device select the Apk Installer app
- 4 Select install and browse the USB for the apk
- The message "Do you want to install this application" is displayed. Press the next button until the button "install" appears
- 6 Press the install button
- 7 After installation press the open button
- The PADS4 HTML5 Launcher app will be started. Enter the location of the PADS4 Server, by specifying a domain name, IP address or pc name of the server where the PADS4 Server is running.
- (Optional) If you changed the default server html server settings of the PADS server, open the advanced settings and specify the correct port number and host/root path.
- Press start, the first time the app will prompt to select your home app. Select PADS4 HTML5 Launcher and select always, if you don't it will prompt the message again.

When finished the launcher will download the PADS4 HTML5 Viewer software and start. At the left bottom location a connection indicator icon will appear. It will turn green if a valid connection is made to the Server.

If a problem occurs open the viewer settings and have a look at the log which may contain important (error) information.

The first time the device is configured, a valid server connection is required to download the PADS4 HTML5 Viewer software.

Adjust PADS4 Viewer options

PADS4 Viewer options can be changed directly on the device using a mouse.

Click on the left button of the mouse and hold this down until the menu appears or touch the panel for 3 seconds.

It is also possible to change options remotely using PADS4 CTRL Center or PADS4 Agent.

Open launcher menu from PADS4 HTML5 Viewer

- Open Viewer menu
- Click on the Launcher Settings button
- Click on the gear icon in right bottom corner
- The Android settings open
 If the Hide Status Bar option is turned on, the only way to leave the Android setting is to restart
 the device, by disconnecting the power.

To perform a factory reset of the device follow the next steps:

Step Description

- Open the settings on Android
- Select Backup & Reset
- Select Factory data reset
- (Optional) Select Erase SD card
- Select Reset tablet
- Select Erase everything

Required firmware

PADS4 requires version 4.4.143 Firmware build number 2.0.1-26

Support	Category	Description
Ý	IAUtomatic PADS4 Software undates	Supported.
		HTML5 Viewer is automatically updated.
\square	Offline mode of device	While offline from the network, the device will still
		continue to play PADS4 presentations and change
		planned schedules for 7 days.
		Scheduled presentations, content and data is
		cached local.
	Device	

\subseteq	Portrait mode	Supported. Device will adjust the rotation automatically.		
\subseteq	Block remote control	Option to prevent usage of remote control to operate the screen		
\subseteq	Transfer protocols	HTTP, HTTPS		
,	Turn off display	Not supported		
\subseteq	Cluster Viewer	This device is able to be used as Cluster Viewer		
	Elements			
M	Video element	Maximum number of videos	4 videos Check out the sup- plier doc- umentation for more info	
		Video rotation	Supported	
		Seamless videos	Not supported	
		Reflection, skew, flip	Not supported	
		Streaming	HTTP	
\triangle	Image element	Support for JPG, PNG, BMP, GIF		
	Text element	Supported		
\subseteq	Line element	Supported		
\subseteq	Shape element	Supported		
\subseteq	Scrolling text element	Supported		
\subseteq	Formatted text element	Supported		
	Flash element	Not supported		
\subseteq	Table element	Supported		
\square	Interactive button element	Supported Mouse cursor options not supported Interactive Data filter & sort dialog window not supported		
\square	Web element	Usage of the interactive Address Bar not supported		
	Data connections	Data connections make it possible to show information from external sources inside presentations		

Ý	Data providers	of (realtime) data f	S4 data providers for retrieval from external sources and the ge and join the data to fit your
	Viewer Variables	presentations and It also gives the op the content withou data providers.	ariables can simplify your data connections. portunity to centrally manage t changing presentations or perties by using external data
	Property bindings	sources	. , ,
	Rules	situations like realt vior of a presentat	ossible to interact on certain ime data and change the beha-ion automatically
\triangle	Presentation rules	Supported	
\subseteq	Page rules	Supported	
\subseteq	Element rules	Supported	
∑	Remote device management Web based and Windows	Device management from a remote local Connection state Alerts Reboot Restart Viewer Shutdown Wake On Lan Screenshot Logs Viewer Settings Fonts	nt which can be performed ation Device connection state information Automatically send out alerts when network failures occur for this device Not supported Restart PADS4 Viewer Not supported Not supported Retrieve screenshots for what is actually displayed Viewer log, synchronization log, system info Edit Viewer Settings Install Fonts on device
		Proof of play	Show Proof of play information

		Blackbox require	from NDS Support is ed, the blackbox con- nportant information estigation purposes
	Remarks		<u> </u>
	Colors	Texture and pattern colors a	are not supported
口	Transition effects	Horizontal and vertical blind Splitters, increased circle ar ported	• •
Q	Content file integrity	PADS4 Content Library file in ing synchronization using M	5 ,
Q	Proof of play	Local storage limitation of r the HTML5 Viewer during o When the 50.000 is hit, the o removed first.	ffline period.



Configuring IAdea XDS-1588A

This page explains how to configure the SOC player to run the PADS4 HTML5 Viewer.

When you turn the device on for the first time it will open a configuration wizard. Follow the steps and specify the settings, as mentioned below.

Installation of the PADS4 HTML5 Viewer Android Launcher

PADS4 requires an Android Launcher to be installed.

This launcher can be downloaded from http://go.pads4.com/?fwlink=1004.

Step Step Description

- 1 Store the PADS HTML5 Launcher apk on a USB stick
- 2 Insert the USB stick into the device
- 3 On the device select the Apk Installer app
- 4 Select install and browse the USB for the apk
- The message "Do you want to install this application" is displayed. Press the next button until the button "install" appears
- 6 Press the install button
- 7 After installation press the open button
- The PADS4 HTML5 Launcher app will be started. Enter the location of the PADS4 Server, by specifying a domain name, IP address or pc name of the server where the PADS4 Server is running.
- (Optional) If you changed the default server html server settings of the PADS server, open the advanced settings and specify the correct port number and host/root path.
- Press start, the first time the app will prompt to select your home app. Select PADS4 HTML5 Launcher and select always, if you don't it will prompt the message again.

When finished the launcher will download the PADS4 HTML5 Viewer software and start. At the left bottom location a connection indicator icon will appear. It will turn green if a valid connection is made to the Server.

If a problem occurs open the viewer settings and have a look at the log which may contain important (error) information.

The first time the device is configured, a valid server connection is required to download the PADS4 HTML5 Viewer software.

Adjust PADS4 Viewer options

PADS4 Viewer options can be changed directly on the device using a mouse.

Click on the left button of the mouse and hold this down until the menu appears or touch the panel for 3 seconds.

It is also possible to change options remotely using PADS4 CTRL Center or PADS4 Agent.

Open launcher menu from PADS4 HTML5 Viewer

- Open Viewer menu
- Click on the Launcher Settings button
- Click on the gear icon in right bottom corner
- The Android settings open
 If the Hide Status Bar option is turned on, the only way to leave the Android setting is to restart
 the device, by disconnecting the power.

To perform a factory reset of the device follow the next steps:

Step Description

- Open the settings on Android
- Select Backup & Reset
- Select Factory data reset
- (Optional) Select Erase SD card
- Select Reset tablet
- Select Erase everything

Required firmware

PADS4 requires version 4.4.143 Firmware build number 2.0.1-26

Supported features and limitations

Support	Category	Description
	Automatic PADS4 Software updates	Supported.
Ľ	Automatic PAD34 Software updates	HTML5 Viewer is automatically updated.
		While offline from the network, the device will still
		continue to play PADS4 presentations and change
\mathbf{M}	Offline mode of device	planned schedules for 7 days.
		Scheduled presentations, content and data is
		cached local.
	Device	

\subseteq	Portrait mode	Supported. Device will adjust matically.	the rotation auto-
\subseteq	Block remote control	Option to prevent usage of remote control to operate the screen	
\subseteq	Transfer protocols	HTTP, HTTPS	
,	Turn off display	Not supported	
\subseteq	Cluster Viewer	This device is able to be used	as Cluster Viewer
	Elements		
M	Video element	Maximum number of videos	4 videos Check out the sup- plier doc- umentation for more info
		Video rotation	Supported
		Seamless videos	Not supported
		Reflection, skew, flip	Not supported
		Streaming	HTTP
\triangle	Image element	Support for JPG, PNG, BMP, G	IF
	Text element	Supported	
\subseteq	Line element	Supported	
\subseteq	Shape element	Supported	
\subseteq	Scrolling text element	Supported	
\subseteq	Formatted text element	Supported	
	Flash element	Not supported	
\subseteq	Table element	Supported	
\square	Interactive button element	Supported Mouse cursor options not sup Interactive Data filter & sort d supported	-
	Web element	Usage of the interactive Addre	ess Bar not sup-
	Data connections	Data connections make it pos ation from external sources in	

Ý	Data providers	of (realtime) data f	S4 data providers for retrieval from external sources and the ge and join the data to fit your
	Viewer Variables	presentations and It also gives the op the content withou data providers.	ariables can simplify your data connections. portunity to centrally manage t changing presentations or perties by using external data
	Property bindings	sources	. , ,
	Rules	situations like realt vior of a presentat	ossible to interact on certain ime data and change the beha-ion automatically
\triangle	Presentation rules	Supported	
\subseteq	Page rules	Supported	
\subseteq	Element rules	Supported	
∑	Remote device management Web based and Windows	Device management from a remote local Connection state Alerts Reboot Restart Viewer Shutdown Wake On Lan Screenshot Logs Viewer Settings Fonts	nt which can be performed ation Device connection state information Automatically send out alerts when network failures occur for this device Not supported Restart PADS4 Viewer Not supported Not supported Retrieve screenshots for what is actually displayed Viewer log, synchronization log, system info Edit Viewer Settings Install Fonts on device
		Proof of play	Show Proof of play information

		Blackbox require	from NDS Support is ed, the blackbox con- nportant information estigation purposes
	Remarks		<u> </u>
	Colors	Texture and pattern colors a	are not supported
口	Transition effects	Horizontal and vertical blind Splitters, increased circle ar ported	• •
Q	Content file integrity	PADS4 Content Library file in ing synchronization using M	5 ,
Q	Proof of play	Local storage limitation of r the HTML5 Viewer during o When the 50.000 is hit, the o removed first.	ffline period.



Configuring IAdea MBR 1100

This page explains how to configure the SOC player to run the PADS4 HTML5 Viewer.

When you turn the device on for the first time it will open a configuration wizard. Follow the steps and specify the settings, as mentioned below.

Installation of the PADS4 HTML5 Viewer Android Launcher

PADS4 requires an Android Launcher to be installed.

This launcher can be downloaded from http://go.pads4.com/?fwlink=1004.

Step Step Description

- 1 Store the PADS HTML5 Launcher apk on a USB stick
- 2 Insert the USB stick into the device
- 3 On the device select the Apk Installer app
- 4 Select install and browse the USB for the apk
- The message "Do you want to install this application" is displayed. Press the next button until the button "install" appears
- 6 Press the install button
- 7 After installation press the open button
- The PADS4 HTML5 Launcher app will be started. Enter the location of the PADS4 Server, by specifying a domain name, IP address or pc name of the server where the PADS4 Server is running.
- (Optional) If you changed the default server html server settings of the PADS server, open the advanced settings and specify the correct port number and host/root path.
- Press start, the first time the app will prompt to select your home app. Select PADS4 HTML5 Launcher and select always, if you don't it will prompt the message again.

When finished the launcher will download the PADS4 HTML5 Viewer software and start. At the left bottom location a connection indicator icon will appear. It will turn green if a valid connection is made to the Server.

If a problem occurs open the viewer settings and have a look at the log which may contain important (error) information.

The first time the device is configured, a valid server connection is required to download the PADS4 HTML5 Viewer software.

Adjust PADS4 Viewer options

PADS4 Viewer options can be changed directly on the device using a mouse.

Click on the left button of the mouse and hold this down until the menu appears or touch the panel for 3 seconds.

It is also possible to change options remotely using PADS4 CTRL Center or PADS4 Agent.

Open launcher menu from PADS4 HTML5 Viewer

- Open Viewer menu
- Click on the Launcher Settings button
- Click on the gear icon in right bottom corner
- The Android settings open
 If the Hide Status Bar option is turned on, the only way to leave the Android setting is to restart
 the device, by disconnecting the power.

To perform a factory reset of the device follow the next steps:

Step Description

- Open the settings on Android
- Select Backup & Reset
- Select Factory data reset
- (Optional) Select Erase SD card
- Select Reset tablet
- Select Erase everything

Required firmware

PADS4 requires version 1

Supported features and limitations

Support	Category	Description
	Automatic PADS4 Software updates	Supported.
Ľ	Automatic PAD34 Software updates	HTML5 Viewer is automatically updated.
		While offline from the network, the device will still
		continue to play PADS4 presentations and change
\mathbf{M}	Offline mode of device	planned schedules for 7 days.
		Scheduled presentations, content and data is
		cached local.
	Device	

\subseteq	Portrait mode	Supported. Device will adjust matically.	the rotation auto-
\subseteq	Block remote control	Option to prevent usage of remote control to operate the screen	
\subseteq	Transfer protocols	HTTP, HTTPS	
	Turn off display	Not supported	
\subseteq	Cluster Viewer	This device is able to be used	as Cluster Viewer
	Elements		
⋈	Video element	Maximum number of videos	2 videos Check out the sup- plier doc- umentation for more info
	video ciement	Video rotation	Supported
		Seamless videos	Not supported
		Reflection, skew, flip	Not supported
		Streaming	HTTP
\subseteq	lmage element	Support for JPG, PNG, BMP, G	IF
\subseteq	Text element	Supported	
\subseteq	Line element	Supported	
\subseteq	Shape element	Supported	
\subseteq	Scrolling text element	Supported	
\subseteq	Formatted text element	Supported	
	Flash element	Not supported	
\subseteq	Table element	Supported	
M	Interactive button element	Supported Mouse cursor options not sup Interactive Data filter & sort d supported	-
\square	Web element	Usage of the interactive Addre	ess Bar not sup-
	Data connections	Data connections make it pos- ation from external sources in	

Ý	Data providers	of (realtime) data f	S4 data providers for retrieval from external sources and the ge and join the data to fit your
	Viewer Variables	presentations and It also gives the op the content withou data providers.	ariables can simplify your data connections. portunity to centrally manage t changing presentations or perties by using external data
	Property bindings	sources	. , ,
	Rules	situations like realt vior of a presentat	ossible to interact on certain ime data and change the beha-ion automatically
\triangle	Presentation rules	Supported	
\subseteq	Page rules	Supported	
\subseteq	Element rules	Supported	
∑	Remote device management Web based and Windows	Device management from a remote local Connection state Alerts Reboot Restart Viewer Shutdown Wake On Lan Screenshot Logs Viewer Settings Fonts	nt which can be performed ation Device connection state information Automatically send out alerts when network failures occur for this device Not supported Restart PADS4 Viewer Not supported Not supported Retrieve screenshots for what is actually displayed Viewer log, synchronization log, system info Edit Viewer Settings Install Fonts on device
		Proof of play	Show Proof of play information

		Blackbox require	from NDS Support is ed, the blackbox con- nportant information estigation purposes
	Remarks		<u> </u>
	Colors	Texture and pattern colors a	are not supported
口	Transition effects	Horizontal and vertical blind Splitters, increased circle ar ported	• •
Q	Content file integrity	PADS4 Content Library file in ing synchronization using M	5 ,
Q	Proof of play	Local storage limitation of r the HTML5 Viewer during o When the 50.000 is hit, the o removed first.	ffline period.



Configuring IAdea XMP-6400 / XMP-7300

This page explains how to configure the SOC player to run the PADS4 HTML5 Viewer.

When you turn the device on for the first time it will open a configuration wizard. Follow the steps and specify the settings, as mentioned below.

Installation of the PADS4 HTML5 Viewer Android Launcher

PADS4 requires an Android Launcher to be installed.

This launcher can be downloaded from http://go.pads4.com/?fwlink=1004.

Step Step Description

- 1 Store the PADS HTML5 Launcher apk on a USB stick
- 2 Insert the USB stick into the device
- 3 On the device select the Apk Installer app
- 4 Select install and browse the USB for the apk
- The message "Do you want to install this application" is displayed. Press the next button until the button "install" appears
- 6 Press the install button
- 7 After installation press the open button
- The PADS4 HTML5 Launcher app will be started. Enter the location of the PADS4 Server, by specifying a domain name, IP address or pc name of the server where the PADS4 Server is running.
- Optional) If you changed the default server html server settings of the PADS server, open the advanced settings and specify the correct port number and host/root path.
- Press start, the first time the app will prompt to select your home app. Select PADS4 HTML5 Launcher and select always, if you don't it will prompt the message again.

When finished the launcher will download the PADS4 HTML5 Viewer software and start. At the left bottom location a connection indicator icon will appear. It will turn green if a valid connection is made to the Server.

If a problem occurs open the viewer settings and have a look at the log which may contain important (error) information.

The first time the device is configured, a valid server connection is required to download the PADS4 HTML5 Viewer software.

Adjust PADS4 Viewer options

PADS4 Viewer options can be changed directly on the device using a mouse.

Click on the left button of the mouse and hold this down until the menu appears or touch the panel for 3 seconds.

It is also possible to change options remotely using PADS4 CTRL Center or PADS4 Agent.

Open launcher menu from PADS4 HTML5 Viewer

- Open Viewer menu
- Click on the Launcher Settings button
- Click on the gear icon in right bottom corner
- The Android settings open
 If the Hide Status Bar option is turned on, the only way to leave the Android setting is to restart
 the device, by disconnecting the power.

To perform a factory reset of the device follow the next steps:

Step Description

- Open the settings on Android
- Select Backup & Reset
- Select Factory data reset
- (Optional) Select Erase SD card
- Select Reset tablet
- Select Erase everything

Required firmware

PADS4 requires version 1

Supported features and limitations

Support	Category	Description
	Automatic PADS4 Software updates	Supported.
Ľ	Automatic PAD34 Software updates	HTML5 Viewer is automatically updated.
		While offline from the network, the device will still
		continue to play PADS4 presentations and change
\mathbf{M}	Offline mode of device	planned schedules for 7 days.
		Scheduled presentations, content and data is
		cached local.
	Device	

\subseteq	Portrait mode	Supported. Device will adjust matically.	Supported. Device will adjust the rotation automatically.	
\subseteq	Block remote control	Option to prevent usage of re operate the screen	Option to prevent usage of remote control to operate the screen	
\subseteq	Transfer protocols	HTTP, HTTPS		
	Turn off display	Not supported		
\subseteq	Cluster Viewer	This device is able to be used	This device is able to be used as Cluster Viewer	
	Elements			
	Video element	Maximum number of videos	1 HD video (max- imum 30fps) Check out the sup- plier doc- umentation for more info	
		Maximum number of videos Check out the supplier documentation for	Supported	
		·	• •	
_		Streaming	HTTP	
\subseteq	Image element	Support for JPG, PNG, BMP, G	IF	
\subseteq	Text element	Supported		
\subseteq	Line element	Supported		
\subseteq	Shape element	Supported		
\subseteq	Scrolling text element	Supported		
\leq	Formatted text element	Supported		
	Flash element	Not supported		
\subseteq	Table element	Supported		
\subseteq	Interactive button element	Not Supported		
\square	Web element	Usage of the interactive Addre	ess Bar not sup-	
	Data connections	Data connections make it pos ation from external sources in		
$\overline{\nabla}$	Data providers	More than 70 PADS4 data pro	•	

		of (realtime) data from external sources and the possibility to change and join the data to fit your purpose		
Ĭ	Viewer Variables	Usage of Viewer Variables can simplify your presentations and data connections. It also gives the opportunity to centrally manage the content without changing presentations or data providers.		
\square	Property bindings	Apply element properties by using external data sources		
	Rules	Rules will make it possible to interact on certain situations like realtime data and change the behavior of a presentation automatically		
\subseteq	Presentation rules	Supported		
\subseteq	Page rules	Supported		
Ŋ	Element rules	Supported		
	Device Management	Device management which can be performed from a remote location		
		Connection state	Device connection state information	
		Alerts	Automatically send out alerts when network failures occur for this device	
		Reboot	Not supported	
		Restart Viewer	Restart PADS4 Viewer	
_	Remote device management	Shutdown Wake On Lan	Not supported Not supported	
M	Web based and Windows	Screenshot	Retrieve screenshots for what is actually displayed	
		Logs	Viewer log, synchronization log, system info	
		Viewer Settings	Edit Viewer Settings	
		Fonts	Install Fonts on device	
		Proof of play	Show Proof of play information	
		Blackbox	If help from NDS Support is	

		required, the blackbox contains important information for investigation purposes
	Remarks	
	Colors	Texture and pattern colors are not supported
\Box	Transition effects	Horizontal and vertical blinds not supported Splitters, increased circle and sliced circle not sup- ported
	Content file integrity	PADS4 Content Library file integrity is checked during synchronization using MD5
Q	Proof of play	Local storage limitation of max. 50.000 records on the HTML5 Viewer during offline period. When the 50.000 is hit, the oldest value will be removed first.



Configuring IAdea XMP-6400 / XMP-7300

This page explains how to configure the SOC player to run the PADS4 HTML5 Viewer.

When you turn the device on for the first time it will open a configuration wizard. Follow the steps and specify the settings, as mentioned below.

Installation of the PADS4 HTML5 Viewer Android Launcher

PADS4 requires an Android Launcher to be installed.

This launcher can be downloaded from http://go.pads4.com/?fwlink=1004.

Step Step Description

- 1 Store the PADS HTML5 Launcher apk on a USB stick
- 2 Insert the USB stick into the device
- 3 On the device select the Apk Installer app
- 4 Select install and browse the USB for the apk
- The message "Do you want to install this application" is displayed. Press the next button until the button "install" appears
- 6 Press the install button
- 7 After installation press the open button
- The PADS4 HTML5 Launcher app will be started. Enter the location of the PADS4 Server, by specifying a domain name, IP address or pc name of the server where the PADS4 Server is running.
- Optional) If you changed the default server html server settings of the PADS server, open the advanced settings and specify the correct port number and host/root path.
- Press start, the first time the app will prompt to select your home app. Select PADS4 HTML5 Launcher and select always, if you don't it will prompt the message again.

When finished the launcher will download the PADS4 HTML5 Viewer software and start. At the left bottom location a connection indicator icon will appear. It will turn green if a valid connection is made to the Server.

If a problem occurs open the viewer settings and have a look at the log which may contain important (error) information.

The first time the device is configured, a valid server connection is required to download the PADS4 HTML5 Viewer software.

Adjust PADS4 Viewer options

PADS4 Viewer options can be changed directly on the device using a mouse.

Click on the left button of the mouse and hold this down until the menu appears or touch the panel for 3 seconds.

It is also possible to change options remotely using PADS4 CTRL Center or PADS4 Agent.

Open launcher menu from PADS4 HTML5 Viewer

- Open Viewer menu
- Click on the Launcher Settings button
- Click on the gear icon in right bottom corner
- The Android settings open
 If the Hide Status Bar option is turned on, the only way to leave the Android setting is to restart
 the device, by disconnecting the power.

To perform a factory reset of the device follow the next steps:

Step Description

- Open the settings on Android
- Select Backup & Reset
- Select Factory data reset
- (Optional) Select Erase SD card
- Select Reset tablet
- Select Erase everything

Required firmware

PADS4 requires version 1

Supported features and limitations

Support	Category	Description
	Automatic PADS4 Software updates	Supported.
Ľ		HTML5 Viewer is automatically updated.
	Offline mode of device	While offline from the network, the device will still
区		continue to play PADS4 presentations and change
		planned schedules for 7 days.
		Scheduled presentations, content and data is
		cached local.
	Device	

\subseteq	Portrait mode	Supported. Device will adjust matically.	the rotation auto-		
\subseteq	Block remote control	Option to prevent usage of re operate the screen	Option to prevent usage of remote control to operate the screen		
\subseteq	Transfer protocols	HTTP, HTTPS	HTTP, HTTPS		
	Turn off display	Not supported			
\subseteq	Cluster Viewer	This device is able to be used	This device is able to be used as Cluster Viewer		
	Elements				
	Video element	Maximum number of videos	1 HD video (max- imum 30fps) Check out the sup- plier doc- umentation for more info		
		Video rotation	Supported		
		Seamless videos	Not supported		
		Reflection, skew, flip	Not supported		
_		Streaming	HTTP		
\subseteq	Image element	Support for JPG, PNG, BMP, G	IF		
\subseteq	Text element	Supported			
\subseteq	Line element	Supported			
\subseteq	Shape element	Supported			
\subseteq	Scrolling text element	Supported			
\leq	Formatted text element	Supported			
	Flash element	Not supported			
\subseteq	Table element	Supported			
\subseteq	Interactive button element	Not Supported			
\square	Web element	Usage of the interactive Addre	Usage of the interactive Address Bar not supported		
	Data connections	Data connections make it pos ation from external sources in			
$\overline{\nabla}$	Data providers	More than 70 PADS4 data pro	•		

		of (realtime) data from external sources and the possibility to change and join the data to fit your purpose		
Ĭ	Viewer Variables	Usage of Viewer Variables can simplify your presentations and data connections. It also gives the opportunity to centrally manage the content without changing presentations or data providers.		
\square	Property bindings	Apply element properties by using external data sources		
	Rules	Rules will make it possible to interact on certain situations like realtime data and change the behavior of a presentation automatically		
\subseteq	Presentation rules	Supported		
\subseteq	Page rules	Supported		
Ŋ	Element rules	Supported		
	Device Management	Device management which can be performed from a remote location		
		Connection state	Device connection state information	
		Alerts	Automatically send out alerts when network failures occur for this device	
		Reboot	Not supported	
		Restart Viewer	Restart PADS4 Viewer	
_	Remote device management	Shutdown Wake On Lan	Not supported Not supported	
M	Web based and Windows	Screenshot	Retrieve screenshots for what is actually displayed	
		Logs	Viewer log, synchronization log, system info	
		Viewer Settings	Edit Viewer Settings	
		Fonts	Install Fonts on device	
		Proof of play	Show Proof of play information	
		Blackbox	If help from NDS Support is	

	T	T
		required, the blackbox con-
		tains important information
		for investigation purposes
	Remarks	
	Colors	Texture and pattern colors are not supported
		Horizontal and vertical blinds not supported
4	Transition effects	Splitters, increased circle and sliced circle not sup-
		ported
	Content file integrity	PADS4 Content Library file integrity is checked dur-
-	Content file integrity	ing synchronization using MD5
		Local storage limitation of max. 50.000 records on
	Proof of play	the HTML5 Viewer during offline period.
~		When the 50.000 is hit, the oldest value will be
		removed first.



Certified Viewer devices

This section shows the certified Viewer devices from LG.



Viewer on LG WebOS2

Contents

- 1. First time use
- 1.1. Configuring the device
- 1.2. Resetting the device
- 2. Installing PADS4 Viewer
- 2.1. Checking device firmware
- 2.2. Updating firmware
- 2.3. Adjust PADS4 Viewer settings using the options screen
- 3. Supported features & limitations
- 4. Troubleshooting

1. First time use

This document is related to the WebOS2.

When you turn the device on for the first time, it will open a configuration wizard. Follow the steps and specify the settings, as mentioned below. (If the configuration wizard does not start, then please first factory reset your device, as described in '1.2 resetting the device'.)

1.1. Configuring the device

Please read the installing section to setup the Viewer. There are no changes that need to be performed before installing the Viewer.

1.2. Resetting the device

If your device was used before, we recommend that you factory reset your device, so that all storage is freed and no other software interferes with the PADS4 Viewer software.

Step	Description
01	Press and hold Settings button until an balloon icon appears at the right top
02	Press keys 0 0 0 0 followed by OK key on remote control
03	Select signage setup menu
04	Select factory reset option (at the bottom of the menu)
05	Confirm to start the factory reset

The device will factory reset and afterwards you will see the welcome screen, please follow the steps as described in '1.1 configuring the device'.

2. Installing PADS4 Viewer

Step	Description
01	Power on button
02	Press and hold Settings button until an balloon icon appears at the right top
03	Press keys 8 0 8 0 followed by OK key on remote control
04	Set Application launch mode to local
05	Set Fully qualified domain name to ON
06	Set the URL for normal or secured connection http:// <server>/pads4/native/lg.zip https://<server>/pads4/native/lg.zip (secured connection using https) Where <server> is the IP address or domain name of your PADS4 Server</server></server></server>
07	Select remote option
80	Confirm to start
80	After download power off/on the device

When finished the device will download the PADS4 HTML5 Viewer software and start. At the left bottom location a connection indicator icon will appear. It will turn green if a valid connection is made to the Server.

If a problem occurs open the viewer settings and have a look at the log which may contain important (error) information.

The first time the device is configured, a valid server connection is required to download the PADS4 HTML5 Viewer software.

2.1. Checking device firmware

To run the PADS4 viewer properly on the WebOS2 and make sure that all functionality works, you need to have firmware as mentioned in step 4 installed on the device. Please check using the following steps.

Step	Description
01	Press Home button on the remote control
02	Select Information Application
	Version 3.90.30 is required by PADS4

2.2 Updating firmware

Step	Description
01	Copy the firmware .epk file into the LG_MONITOR folder of a USB stick
02	Insert the USB Stick with the new firmware into the screen
03	Device will detect the USB stick and start the update automatically

2.3. Adjust PADS4 Viewer settings using the options screen

You can adjust the PADS4 Viewer settings directly on the display. To enter the options screen on the device itself, hold the left mouse button down or touch the screen for 3 seconds.

3. Supported features and limitations

Support	Category	Description
	Automatic PADS4 Software updates	Supported.
Ľ	Automatic PAD34 Software updates	HTML5 Viewer is automatically updated.
		While offline from the network, the device will still
		continue to play PADS4 presentations and change
$\mathbf{\Sigma}$	Offline mode of device	planned schedules for 7 days.
		Scheduled presentations, content and data is
		cached local.
	Device	
\subseteq	Portrait mode	Supported.
	Block remote control	Option to prevent usage of remote control to
ت	BIOCK TETHOLE CONLION	operate the screen

\square	Transfer protocols	HTTP, HTTPS		
	Turn off display	Not supported		
M	Cluster Viewer	This device is able to be used as Cluster Viewer		
	Flowante			
	Elements			
		Maximum number of videos	1 video. Check out the supplier documentation for more info	
		Video rotation	Not supported	
\square	Video element	Automatic size	Not supported uniform in combination with border and alignment not supported	
		Playback speed adjustment	Not supported	
		Reflection, skew, flip	Not supported	
		Streaming	HTTP, HTTPS, HLS V3, UDP	
Ŋ	lmage element	Support for JPG, PNG, BMP, G	IF	
Y	Text element	Supported		
\subseteq	Line element	Supported		
	Shape element	Supported		
\subseteq	Scrolling text element	Supported		
\subseteq	Formatted text element	Supported		
	Flash element	Not supported		
	Table element	Supported		
\subseteq	Interactive button element	Supported Mouse cursor options not supported Interactive Data filter & sort dialog window not supported		
M	Web element	Usage of the interactive Address Bar not supported		

	Data connections		make it possible to show inform- I sources inside presentations
M	Data providers	More than 70 PAD: of (realtime) data f	S4 data providers for retrieval from external sources and the ge and join the data to fit your
M	Viewer Variables	presentations and It also gives the op	ariables can simplify your data connections. portunity to centrally manage t changing presentations or
\square	Property bindings	Apply element pro sources	perties by using external data
	Rules	· ·	ossible to interact on certain ime data and change the behaion automatically
\subseteq	Presentation rules	Supported	
\subseteq	Page rules	Supported	
\subseteq	Element rules	Supported	
	Device Management	Device management which can be performed from a remote location	
		Connection state	Device connection state information
		Alerts	Automatically send out alerts when network failures occur for this device
		Reboot	Supported
	Remote device management	Restart Viewer	Restart PADS4 Viewer
\leq		Shutdown	Not supported
	Web based and Windows	Wake On Lan	Not supported
		Screenshot	Retrieve screenshots for what is actually displayed
		Logs	Viewer log, synchronization log, system info
		Viewer Settings Fonts	Edit Viewer Settings Install Fonts on device

		Proof of play	Show Proof of play information
		Blackbox	If help from NDS Support is required, the blackbox con- tains important information for investigation purposes
	Remarks		
	Colors	Texture and pattern	n colors are not supported
\Box	Transition effects		ical blinds not supported circle and sliced circle not sup-
	Content file integrity	PADS4 Content Libring synchronization	rary file integrity is checked dur- nusing MD5
\Box	Proof of play	the HTML5 Viewer	ation of max. 50.000 records on during offline period. hit, the oldest value will be

4. Troubleshooting

Problem	Solution



Viewer on LG WebOS3

Contents

- 1. First time use
- 1.1. Configuring the device
- 1.2. Resetting the device
- 2. Installing PADS4 Viewer
- 2.1. Checking device firmware
- 2.2. Updating firmware
- 2.3. Adjust PADS4 Viewer settings using the options screen
- 3. Supported features & limitations
- 4. Troubleshooting

1. First time use

This document is related to the WebOS3.

When you turn the device on for the first time, it will open a configuration wizard. Follow the steps and specify the settings, as mentioned below. (If the configuration wizard does not start, then please first factory reset your device, as described in '1.2 resetting the device'.)

1.1. Configuring the device

Please read the installing section to setup the Viewer. There are no changes that need to be performed before installing the Viewer.

1.2. Resetting the device

If your device was used before, we recommend that you factory reset your device, so that all storage is freed and no other software interferes with the PADS4 Viewer software.

Step	Description	
01	Press and hold Settings button until an balloon icon appears at the right top	
02	Press keys 0 0 0 0 followed by OK key on remote control	

03	Select signage setup menu	
04	Select factory reset option (at the bottom of the menu)	
05	O5 Confirm to start the factory reset	

The device will factory reset and afterwards you will see the welcome screen, please follow the steps as described in '1.1 configuring the device'.

2. Installing PADS4 Viewer

Step	Description		
01	Power on button		
02	Press and hold Settings button until an balloon icon appears at the right top		
03	Press keys 8 0 8 0 followed by OK key on remote control		
04	Set Application launch mode to local		
05	Set Fully qualified domain name to ON		
06	Set the URL for normal or secured connection http:// <server>/pads4/native/lg.zip https://<server>/pads4/native/lg.zip (secured connection using https) Where <server> is the IP address or domain name of your PADS4 Server</server></server></server>		
07	Set the desired rotation (0,90,180,270)		
80	Select remote option		
09	Confirm to start		
10	After download power off/on the device		

When finished the device will download the PADS4 HTML5 Viewer software and start. At the left bottom location a connection indicator icon will appear. It will turn green if a valid connection is made to the Server.

If a problem occurs open the viewer settings and have a look at the log which may contain important (error) information.

The first time the device is configured, a valid server connection is required to download the PADS4 HTML5 Viewer software.

2.1. Checking device firmware

To run the PADS4 viewer properly on the WebOS3 and make sure that all functionality works, you need to have firmware as mentioned in step 4 installed on the device. Please check using the following steps.

Step	Description

01	Press Home button on the remote control	
	Select Information Application	
02		
	Version 4.73.60 is required by PADS4	

2.2 Updating firmware

Step	Description	
01	Copy the firmware .epk file into the LG_MONITOR folder of a USB stick	
02	Insert the USB Stick with the new firmware into the screen	
03	Device will detect the USB stick and start the update automatically	

2.3. Adjust PADS4 Viewer settings using the options screen

You can adjust the PADS4 Viewer settings directly on the display. To enter the options screen on the device itself, hold the left mouse button down or touch the screen for 3 seconds.

3. Supported features and limitations

Support	Category	Description	
	Automatic PADS4	Supported.	
Ľ	Software updates	HTML5 Viewer is automatically updated.	
	Offline mode of	While offline from the network, the device will still continue to play PADS4	
\sim	device	presentations and change planned schedules for 7 days.	
	device	Scheduled presentations, content and data is cached local.	
	Device		
\subseteq	Portrait mode	Supported.	
	Block remote con-	Option to prevent usage of remote control to operate the screen	
	trol	option to prevent usage of remote control to operate the serven	
M	Transfer pro-	HTTP, HTTPS	
	tocols		
لـــا	Turn off display	Not supported	
\subseteq	Cluster Viewer	This device is able to be used as Cluster Viewer	
	Elements		
\subseteq	Video element	Maximum number of videos 2 full HD videos.	

			Check out the supplier documentation for more info
		Video rotation	Not supported
		Seamless videos	In landscape orientation only
		Playback speed adjustment	Not supported
		Reflection, skew, flip	Not supported
		Thereederly shew, imp	HTTP, HTTPS, HLS V3, UDP
			*If the stream uses an encoder different
		Streaming	from MP4, it is possible to add the encoder
			in the URI: mp4, mpegts, mp2t Example:rt-
			p://239.0.0.1/?encoding=mpegts
Y	lmage element	Support for JPG, PNG, BMP, G	iIF
\subseteq	Text element	Supported	
\subseteq	Line element	Supported	
Y	Shape element	Supported	
Ŋ	Scrolling text ele- ment	Supported	
\subseteq	Formatted text ele ment	Supported	
	Flash element	Not supported	
\subseteq	Table element	Supported	
	Interactive button	Supported	
$\mathbf{\Sigma}$	element	Mouse cursor options not sup	•
		Interactive Data filter & sort d	ialog window not supported
$\mathbf{\Sigma}$	Web element	Usage of the interactive Addr	ess Bar not supported
	Data can	Data connections make it ass	sible to show information from external
	Data con- nections	Data connections make it possible to show information from external sources inside presentations	
		More than 70 PADS4 data providers for retrieval of (realtime) data from	
	Data providers		sibility to change and join the data to fit your
		purpose	
		_	n simplify your presentations and data con-
M	Viewer Variables	nections.	
It also gives the opportunity to centrally m		o centrally manage the content without chan-	
		ging presentations or data providers.	
ightharpoons	Property bindings	Apply element properties by using external data sources	

	1			
	Rules	Rules will make it possible to interact on certain situations like realtime data and change the behavior of a presentation automatically		
\subseteq	Presentation rules	Supported		
\subseteq	Page rules	Supported		
\subseteq	Element rules	Supported Device management which can be performed from a remote location		
	Device Man- agement			
		Connection state	Device connection state information	
		Alerts	Automatically send out alerts when network failures occur for this device	
		Reboot	Supported	
		Restart Viewer	Restart PADS4 Viewer	
	Remote device	Shutdown	Not supported	
	management	Wake On Lan	Supported	
\leq		Screenshot	Retrieve screenshots for what is actually displayed	
	Web based and	Logs	Viewer log, synchronization log, system info	
	Windows	Viewer Settings	Edit Viewer Settings	
		Fonts	Install Fonts on device	
		Proof of play	Show Proof of play information	
		Blackbox	If help from NDS Support is required, the blackbox contains important information for investigation purposes	
	Remarks			
4	Colors	Texture and pattern colors are not supported		
	Transition effects	Horizontal and vertical blinds not supported Splitters, increased circle and sliced circle not supported		
	Content file integrity	PADS4 Content Library file integrity is checked during synchronization using MD5		
口	Proof of play	Local storage limitation of max. 50.000 records on the HTML5 Viewer during offline period. When the 50.000 is hit, the oldest value will be removed first.		

4. Troubleshooting

Problem	Solution



PADS4 Installation Manual

Viewer on LG WebOS3.2

Contents

- 1. First time use
- 1.1. Configuring the device
- 1.2. Resetting the device
- 2. Installing PADS4 Viewer
- 2.1. Checking device firmware
- 2.2. Updating firmware
- 2.3. Adjust PADS4 Viewer settings using the options screen
- 3. Supported features & limitations
- 4. Troubleshooting

1. First time use

This document is related to the WebOS 3.2.

When you turn the device on for the first time, it will open a configuration wizard. Follow the steps and specify the settings, as mentioned below. (If the configuration wizard does not start, then please first factory reset your device, as described in '1.2 resetting the device'.)

1.1. Configuring the device

Please read the installing section to setup the Viewer. There are no changes that need to be performed before installing the Viewer.

1.2. Resetting the device

If your device was used before, we recommend that you factory reset your device, so that all storage is freed and no other software interferes with the PADS4 Viewer software.

Step	Description
01	Press and hold Settings button until an balloon icon appears at the right top
02	Press keys 0 0 0 0 followed by OK key on remote control
03	Select signage setup menu
04	Select factory reset option (at the bottom of the menu)
05	Confirm to start the factory reset

The device will factory reset and afterwards you will see the welcome screen, please follow the steps as described in '1.1 configuring the device'.

2. Installing PADS4 Viewer

Step	Description
01	Power on button
02	Press and hold Settings button until an balloon icon appears at the right top
03	Press keys 8 0 8 0 followed by OK key on remote control
04	Set Application launch mode to local
05	Set Fully qualified domain name to ON
06	Set the URL for normal or secured connection http:// <server>/pads4/native/lg.zip https://<server>/pads4/native/lg.zip (secured connection using https)</server></server>
	Where <server> is the IP address or domain name of your PADS4 Server</server>

07	Set the desired rotation (0,90,180,270)
80	Select remote option
09	Select Confirm to start the upgrade
10	After download power off/on the device

When finished the device will download the PADS4 HTML5 Viewer software and start. At the left bottom location a connection indicator icon will appear. It will turn green if a valid connection is made to the Server.

If a problem occurs open the viewer settings and have a look at the log which may contain important (error) information.

The first time the device is configured, a valid server connection is required to download the PADS4 HTML5 Viewer software.

2.1. Checking device firmware

To run the PADS4 viewer properly on the WebOS 3.2 and make sure that all functionality works, you need to have firmware as mentioned in step 4 installed on the device. Please check using the following steps.

Step	Description
01	Press Home button on the remote control
	Select Information Application
02	
	Version 04.2.20 is required by PADS4

2.2 Updating firmware

Step	Description
01	Copy the firmware .epk file into the LG_MONITOR folder of a USB stick
02	Insert the USB Stick with the new firmware into the screen
03	Device will detect the USB stick and start the update automatically

2.3. Adjust PADS4 Viewer settings using the options screen

You can adjust the PADS4 Viewer settings directly on the display. To enter the options screen on the device itself, hold the left mouse button down or touch the screen for 3 seconds.

3. Supported features and limitations

Support	Category	Description	
\subseteq		Supported. HTML5 Viewer is automatically updated.	
	Offline mode of device	While offline from the network, the device will still continue to play PADS4 presentations and change planned schedules for 7 days. Scheduled presentations, content and data is cached local.	
	Device		
\subseteq	Portrait mode	Supported.	
\subseteq	Block remote control	Option to prevent usage of re	mote control to operate the screen
	Transfer pro- tocols	HTTP, HTTPS	
	Turn off display	Not supported	
\subseteq	Cluster Viewer	This device is able to be used	as Cluster Viewer
	Elements		
Ý	Video element	Maximum number of videos Video rotation Seamless videos Playback speed adjustment Reflection, skew, flip	2 full HD videos. Check out the supplier documentation for more info Not supported In landscape orientation only Not supported Not supported HTTP, HTTPS, HLS V3, UDP, RTP, RTPS multicast
		Streaming	*If the stream uses an encoder different from MP4, it is possible to add the encoder in the URI: mp4, mpegts, mp2t Example:rt- p://239.0.0.1/?encoding=mpegts
\subseteq	lmage element	Support for JPG, PNG, BMP, GIF	
\subseteq	Text element	Supported	
\subseteq	Line element	Supported	
\subseteq	Shape element	Supported	
\subseteq	Scrolling text ele-	Supported	

	ment		
\subseteq	Formatted text ele- ment	Supported	
	Flash element	Not supported	
Ŋ	Table element	Supported	
\subseteq	Interactive button element	Supported Mouse cursor options not supported Interactive Data filter & sort dialog window not supported	
\subseteq	Web element	Usage of the interac	ctive Address Bar not supported
	Data con- nections	Data connections make it possible to show information from external sources inside presentations	
M	Data providers		4 data providers for retrieval of (realtime) data from d the possibility to change and join the data to fit your
\subseteq	Viewer Variables	Usage of Viewer Variables can simplify your presentations and data connections. It also gives the opportunity to centrally manage the content without changing presentations or data providers.	
Ŋ	Property bindings	Apply element properties by using external data sources	
	Rules	Rules will make it possible to interact on certain situations like realtime data and change the behavior of a presentation automatically	
\subseteq	Presentation rules	Supported	
\subseteq	Page rules	Supported	
M	Element rules	Supported	
	Device Man- agement	Device management which can be performed from a remote location	
		Connection state	Device connection state information
	Remote device management	Alerts	Automatically send out alerts when network failures occur for this device
$\mathbf{\Sigma}$		Reboot	Supported
	Web based and Windows	Restart Viewer	Restart PADS4 Viewer
		Shutdown	Not supported
		Wake On Lan	Supported

	ı	ı	
		Screenshot	Retrieve screenshots for what is actually displayed
		Logs	Viewer log, synchronization log, system info
		Viewer Settings	Edit Viewer Settings
		Fonts	Install Fonts on device
		Proof of play	Show Proof of play information
		Blackbox	If help from NDS Support is required, the blackbox contains important information for investigation pur-
			poses
	Remarks		
	Colors	Texture and pattern colors are not supported	
	Transition effects	Horizontal and vertical blinds not supported	
	Transition effects	Splitters, increased circle and sliced circle not supported	
	Content file integ-	p- PADS4 Content Library file integrity is checked during synchronization us	
~	rity	MD5	
		Local storage limita	ation of max. 50.000 records on the HTML5 Viewer dur-
4	Proof of play	ing offline period.	
		When the 50.000 is hit, the oldest value will be removed first.	

4. Troubleshooting

Problem	Solution



PADS4 Installation Manual

Viewer on LG WebOS4

Contents

- 1. First time use
- 1.1. Configuring the device
- 1.2. Resetting the device
- 2. Installing PADS4 Viewer
- 2.1. Checking device firmware
- 2.2. Updating firmware
- 2.3. Adjust PADS4 Viewer settings using the options screen
- 3. Supported features & limitations
- 4. Troubleshooting

1. First time use

This document is related to the WebOS4.

When you turn the device on for the first time, it will open a configuration wizard. Follow the steps and specify the settings, as mentioned below. (If the configuration wizard does not start, then please first factory reset your device, as described in '1.2 resetting the device'.)

1.1. Configuring the device

Please read the installing section to setup the Viewer. There are no changes that need to be performed before installing the Viewer.

1.2. Resetting the device

If your device was used before, we recommend that you factory reset your device, so that all storage is freed and no other software interferes with the PADS4 Viewer software.

Step	Description	
01	Press Settings button (cog icon on remote control)	
02	Select Admin	

03	Select Turn On	
04	Press keys 0 0 0 0 which is the default pin code	
05	Confirm to start the factory reset	

The device will factory reset and afterwards you will see the welcome screen, please follow the steps as described in '1.1 configuring the device'.

2. Installing PADS4 Viewer

Step	Description		
01	Power on button		
02	Press Settings button (cog icon on remote control)		
03	Select EZ Settings		
04	Select SI Server settings from right menu and press OK		
05	Set Fully qualified domain name to ON		
06	Set the URL for normal or secured connection http:// <server>/pads4/native/lg.zip https://<server>/pads4/native/lg.zip (secured connection using https) Where <server> is the IP address or domain name of your PADS4 Server</server></server></server>		
07	Set the desired rotation (0,90,180,270)		
80	Set application launch mode to local		
09	Installation type must be set to zip!		
10	Select local application upgrade Remote		
11	Select Confirm to start the upgrade		
12	After download power off/on the device		

When finished the device will download the PADS4 HTML5 Viewer software and start. At the left bottom location a connection indicator icon will appear. It will turn green if a valid connection is made to the Server.

If a problem occurs open the viewer settings and have a look at the log which may contain important (error) information.

The first time the device is configured, a valid server connection is required to download the PADS4 HTML5 Viewer software.

2.1. Checking device firmware

To run the PADS4 viewer properly on the WebOS4 and make sure that all functionality works, you need to have firmware as mentioned in step 4 installed on the device. Please check using the

following steps.

Step	Description	
01	Press Home button on the remote control	
	Select Information Application	
02		
	Version 04.03.40 is required by PADS4	

2.2 Updating firmware

Step	Description	
01	Copy the firmware .epk file into the LG_MONITOR folder of a USB stick	
02	Insert the USB Stick with the new firmware into the screen	
03	Device will detect the USB stick and start the update automatically	

2.3. Adjust PADS4 Viewer settings using the options screen

You can adjust the PADS4 Viewer settings directly on the display. To enter the options screen on the device itself, hold the left mouse button down or touch the screen for 3 seconds.

3. Supported features and limitations

Support	Category	Description	
	Automatic PADS4	Supported.	
Ŭ	Software updates	HTML5 Viewer is automatically updated.	
_	Offline mode of	While offline from the network, the device will still continue to play PADS4	
$\mathbf{\Sigma}$	device	presentations and change planned schedules for 7 days.	
	device	Scheduled presentations, content and data is cached local.	
	Device		
\subseteq	Portrait mode	Supported.	
\subseteq	Block remote control	Option to prevent usage of remote control to operate the screen	
Ň	Transfer pro- tocols	HTTP, HTTPS	
	Turn off display	Not supported	
\subseteq	Cluster Viewer	This device is able to be used as Cluster Viewer	

	Elements		
		Maximum number of videos	2 full HD videos. Check out the supplier documentation for more info
		Video rotation	Not supported
		Seamless videos	In landscape orientation only
		Playback speed adjustment	Not supported
\leq	Video element	Reflection, skew, flip	Not supported
		Streaming	HTTP, HTTPS, HLS V3, UDP, RTP, RTPS multicast *If the stream uses an encoder different from MP4, it is possible to add the encoder in the URI: mp4, mpegts, mp2t Example:rt- p://239.0.0.1/?encoding=mpegts
\subseteq	lmage element	Support for JPG, PNG, BMP, G	IF
Ŋ	Text element	Supported	
N	Line element	Supported	
Ŋ	Shape element	Supported	
Ŋ	Scrolling text ele- ment	Supported	
Ŋ	Formatted text ele- ment	Supported	
	Flash element	Not supported	
\mathbf{N}	Table element	Supported	
\mathbf{N}	Interactive button element	Supported Mouse cursor options not supported Interactive Data filter & sort dialog window not supported	
K	Web element	Usage of the interactive Address Bar not supported	
	Data con-	Data connections make it possible to show information from external	
	nections	sources inside presentations	
\subseteq	Data providers	More than 70 PADS4 data providers for retrieval of (realtime) data from external sources and the possibility to change and join the data to fit your purpose	
\subseteq	Viewer Variables	Usage of Viewer Variables can simplify your presentations and data connections.	

		It also gives the opportunity to centrally manage the content without changing presentations or data providers.	
\subseteq	Property bindings	Apply element properties by using external data sources	
	Rules	Rules will make it possible to interact on certain situations like realtime data and change the behavior of a presentation automatically	
\subseteq	Presentation rules	Supported	
Ŋ	Page rules	Supported	
\subseteq	Element rules	Supported	
	Device Man- agement	Device manageme	nt which can be performed from a remote location
		Connection state	Device connection state information
		Alerts	Automatically send out alerts when network failures occur for this device
	Remote device management Web based and	Reboot	Supported
		Restart Viewer	Restart PADS4 Viewer
		Shutdown	Not supported
		Wake On Lan	Supported
$\mathbf{\Sigma}$		Screenshot	Retrieve screenshots for what is actually displayed
		Logs	Viewer log, synchronization log, system info
	Windows	Viewer Settings	Edit Viewer Settings
		Fonts	Install Fonts on device
		Proof of play	Show Proof of play information
		Blackbox	If help from NDS Support is required, the blackbox contains important information for investigation purposes
	Remarks		
	Colors	Texture and patter	n colors are not supported
	Transition effects	Horizontal and vertical blinds not supported Splitters, increased circle and sliced circle not supported	
	Content file integrity	PADS4 Content Library file integrity is checked during synchronization using MD5	
口	Proof of play	Local storage limitation of max. 50.000 records on the HTML5 Viewer during offline period. When the 50.000 is hit, the oldest value will be removed first.	

4. Troubleshooting

Problem	Solution



PADS4 Installation Manual

Viewer on LG WP400 JP

Contents

- 1. First time use
- 1.1. Configuring the device
- 1.2. Resetting the device
- 2. Installing PADS4 Viewer
- 2.1. Checking device firmware
- 2.2. Updating firmware
- 2.3. Adjust PADS4 Viewer settings using the options screen
- 3. Supported features & limitations
- 4. Troubleshooting

1. First time use

This document is related to the LG WP400 JP.

When you turn the device on for the first time, it will open a configuration wizard. Follow the steps and specify the settings, as mentioned below. (If the configuration wizard does not start, then please first factory reset your device, as described in '1.2 resetting the device'.)

1.1. Configuring the device

Please read the installing section to setup the Viewer. There are no changes that need to be performed before installing the Viewer.

1.2. Resetting the device

If your device was used before, we recommend that you factory reset your device, so that all storage is freed and no other software interferes with the PADS4 Viewer software.

Step	Description
01	Press Settings button (cog icon on remote control)
02	Select Admin
03	Select Turn On
04	Press keys 0 0 0 0 0 which is the default pin code
05	Select Factory Reset and confirm to start the factory reset

The device will factory reset and afterwards you will see the welcome screen, please follow the steps as described in '1.1 configuring the device'.

2. Installing PADS4 Viewer

Step	Description			
01	Power on button			
02	Press Settings button on remote control			
03	elect EZ Settings			
04	Select SI Server settings (2x)			
05	Activate "Fully Qualified Domain Name"			
06	Set the URL for normal or secured connection http:// <server>/pads4/native/lg.zip https://<server>/pads4/native/lg.zip (secured connection using https)</server></server>			
	Where <server> is the IP address or domain name of your PADS4 Server</server>			

07	Put Application Launch mode on "Local"
80	Make sure that Application Type is "ZIP"
09	Go to Local Application Upgrade and select "Remote"
10	Restart device

When finished the device will download the PADS4 HTML5 Viewer software and start. At the left bottom location a connection indicator icon will appear. It will turn green if a valid connection is made to the Server.

If a problem occurs open the viewer settings and have a look at the log which may contain important (error) information.

The first time the device is configured, a valid server connection is required to download the PADS4 HTML5 Viewer software.

2.1. Checking device firmware

To run the PADS4 viewer properly on the WP400 JP and make sure that all functionality works, you need to have firmware as mentioned in step 4 installed on the device. Please check using the following steps.

Step	Description
01	Press Home button on the remote control
	In the Dashboard look at the S/W version
02	
	Version 4.04.90 is required by PADS4

2.2 Updating firmware

Step	Description
01	Copy the firmware .epk file into the LG_MONITOR folder of a USB stick
02	Insert the USB Stick with the new firmware into the screen
03	Device will detect the USB stick and start the update automatically

2.3. Adjust PADS4 Viewer settings using the options screen

You can adjust the PADS4 Viewer settings directly on the display. To enter the options screen on the device itself, hold the left mouse button down or touch the screen for 3 seconds.

3. Supported features and limitations

Support	Category	Description	
Ŋ	Automatic PADS4 Software updates	Supported. HTML5 Viewer is automatically updated.	
	Offline mode of device	While offline from the network, the device will still continue to play PADS4 presentations and change planned schedules for 7 days. Scheduled presentations, content and data is cached local.	
	Device		
\subseteq	Portrait mode	Supported.	
\square	Block remote control	Option to prevent usage of re operate the screen	mote control to
\subseteq	Transfer protocols	HTTP, HTTPS	
_	Turn off display	Not supported	
\subseteq	Cluster Viewer	This device is able to be used	as Cluster Viewer
	Elements		
		Maximum number of videos	2 videos. Check out the supplier documentation for more info
	Video element	Video rotation	Not supported
\triangle		Seamless videos	In landscape ori- entation only
		Playback speed adjustment	Not supported
		Reflection, skew, flip	Not supported
		Streaming	HTTP, RTPS mul- ticast
\subseteq	Image element	Support for JPG, PNG, BMP, G	IF
\subseteq	Text element	Supported	
\subseteq	Line element	Supported	
\subseteq	Shape element	Supported	

\subseteq	Scrolling text element	Supported	
\subseteq	Formatted text element	Supported	
	Flash element	Not supported	
\subseteq	Table element	Supported	
Ý	Interactive button element	Supported Mouse cursor options not supported Interactive Data filter & sort dialog window not supported	
\square	Web element	Usage of the interactive Address Bar not supported	
	Data connections	Data connections make it possible to show information from external sources inside presentations	
\square	Data providers	More than 70 PADS4 data providers for retrieval of (realtime) data from external sources and the possibility to change and join the data to fit your purpose	
\square	Viewer Variables	Usage of Viewer Variables can simplify your presentations and data connections. It also gives the opportunity to centrally manage the content without changing presentations or data providers.	
\subseteq	Property bindings	Apply element properties by using external data sources	
	Rules	Rules will make it possible to interact on certain situations like realtime data and change the behavior of a presentation automatically	
\subseteq	Presentation rules	Supported	
\subseteq	Page rules	Supported	
\subseteq	Element rules	Supported	
	Device Management	Device management which can be performed from a remote location	
M	Remote device management	Connection state information	
	Web based and Windows	Alerts Automatically send out alerts	

1	1	1	,
			when network failures occur for this device
		Reboot	Supported
		Restart Viewer	Restart PADS4 Viewer
		Shutdown	Not supported
		Wake On Lan	Supported
		Screenshot	Retrieve screenshots for what is actually displayed
		Logs	Viewer log, synchronization log, system info
		Viewer Settings	Edit Viewer Settings
		Fonts	Install Fonts on device
		Proof of play	Show Proof of play information
		Blackbox	If help from NDS Support is required, the blackbox con- tains important information for investigation purposes
			101 Investigation purposes
	Remarks		
	Colors	Texture and patter	n colors are not supported
Image: section of the content of the	Transition effects	Horizontal and vertical blinds not supported Splitters, increased circle and sliced circle not supported	
	Content file integrity	PADS4 Content Lib ing synchronization	rary file integrity is checked dur- n using MD5
\Box	Proof of play	the HTML5 Viewer	ation of max. 50.000 records on during offline period. hit, the oldest value will be

4. Troubleshooting

Problem	Solution



Certified Viewer devices

This section shows the certified Viewer devices from Microsoft Windows.



PADS4 Installation Manual

Configuring Microsoft Windows OS

This page explains how to configure the player to run the PADS4 Viewer on Microsoft Windows based devices.

Installation

During the first installation of PADS4 Viewer on a Microsoft Windows system, you will need the PADS4 Clients setup and select Viewer installation.

Please check out the How to Install PADS4 Viewer page for detailed information about installing the required software on Windows platforms.

Supported Microsoft Windows versions

Serie	Version	Minimum PADS4 version required	Latest PADS4 version allowed
Windows Server	2019	4.0	
	2016	4.0	
	2012 R2	4.0	
	2012	4.0	
	2008 R2	4.0	
	2008	4.0	
Windows	10	4.0	
	10 LTSC/LTSB	4.0	
	10 IOT Enterprise	4.0	
	8.1	4.0	
	8	4.0	4.9
	7 SP1	4.0	



Certified Viewer devices

This section shows the certified Viewer devices from Philips.



PADS4 Installation Manual

PADS4 Viewer on Philips series (<size>BDL3050Q)

Contents

- 1. First time use
- 1.1. Configuring the device
- 1.2. Resetting the device
- 2. Installing PADS4 Viewer
- 2.1. Checking device firmware
- 2.2. Updating device firmware
- 2.3. Install PADS4Philips from USB stick
- 2.4. Configuring the device for PADS4Philips
- 2.4.1. Validate Date Time configuration
- 2.4.2. Optional: Shutdown and Wake on LAN support
- 2.4.3. Optional: Enable TeamViewer
- 2.5. Connecting to PADS4 Server
- 2.6. Adjust PADS4 Viewer settings using the options screen

- 2.7. Updating PADS4 Viewer and PADS4Philips app
- 2.8. Accessing Android menu when PADS4 Viewer is running
- 3. Supported features & limitations
- 4. Troubleshooting

1. First time use

During the installation, you will need to configure the PADS4 Server location. Best approach is to complete the installation of the PADS4 Server first, before continuing the configuration of the device.

The minimum PADS4 Server version required for the PADS4Philips app is version PADS4 Foundation 2020.3.

When you turn the device on for the first time, it will open a configuration wizard. Follow the steps and specify the settings, as mentioned below. (If the configuration wizard does not start, then please first factory reset your device, as described in '1.2 resetting the device'.)

1.1. Configuring the device

Step	Description	
01	In the Welcome screen select your preferred language and click start.	
02	On the Security Setting screen, make sure that 'SICP Network Port' is enabled. Optionally you can enable or disable the other settings. Press next to continue.	
03	On the Network Setting screen, select your preferred network type, press next and configure this accordingly.	
04	On the Signage Display Settings screen, press the skip button.	
05	On the Clone Media Files screen, also press the skip button.	
06	Setup Complete press the finish button.	

The device will show CMND & Deploy, an app supplied by Philips, you do not need to configure this app.

1.2. Resetting the device

If your device was used before, we recommend that you factory reset your device, so that all storage is freed and no other software interferes with the PADS4 Viewer software.

Step	Description
01	Enter the android menu by pressing the Home button followed by the numbers 1888 on the

	remote control.
02	Open the settings.
03	Select System Tools -> Factory Reset.
04	Click on Factory Reset and confirm by pressing OK.

The device will factory reset and afterwards you will see the welcome screen, please follow the steps as described in '1.1 configuring the device'.

2. Installing PADS4 Viewer



1888

To install the PADS4 Viewer on the Philips display, you first need to get in the android menu of this device. To open the android menu, press the home button followed by numbers 1888 on the Philips remote control.

2.1. Checking device firmware

To run the PADS4 viewer properly on the xxBDL3050Q and make sure that all functionality works, you need to have firmware version FB05.06T_Cromium installed on the device. Please check using the following steps.

Step	Description
01	Enter the android menu by pressing home 1 8 8 8.
02	Open the settings.
03	Select about.
04	The build number should match FB05.06T_Chromium

2.2. Updating device firmware

To update the firmware please follow the instructions in the document provided by Philips: https://www.dropbox.com/s/rimwgkylxwvoycr/xxBDL3050Q%20%28QL3%2905.06T.pptx?dl=0

2.3. Install PADS4Philips from USB stick

The PADS4Philips.apk can be found on the PADS4 Server in the apps folder of the PADS4 installation directory. The default PADS4 installation directory is 'C:\Program Files\Net Display Systems\PADS4'.

You can also download the latest version of PADS4Philips from http://go.pads4.com/?fwlink=1006. If you download the latest version, make sure that you will also place it in the apps directory

on the PADS4 Server, because if the server is containing a different version, it will install that version of the PADS4Philips app, once connected to the PADS4 Server.

Step	Description
01	Copy the PADS4Philips.apk on a USB stick.
02	Insert the USB stick into the device.
03	Enter the android menu by pressing home 1 8 8 8.
04	Select Storage -> your USB drive and open the PADS4Philips.apk.
05	Select install and after installation open the app.

2.4. Configuring the device for PADS4Philips

Next we are going to change the device setting to make sure it automatically start the PADS4 Viewer on device startup.

Step	Description			
01	In the PADS4Philips app open Android settings by clicking on System Settings.			
02	Select Signage Display -> Custom App.			
03	Click Select App, then select PADS4Philips and press save.			
04	Press 3x back until you reached PADS4Philips app.			
05	Then open the Philips OSD Menu pressing the home button.			
06	Open the configuration 1 sub menu and select Boot on source.			
07	Select input custom and press back.			
08	Close OSD menu.			

2.4.1. Validate Date Time configuration

Validate if the date and time are setup correctly on the device, otherwise it is possible that you will get certificate errors or other connection issues.

Step	Description	
01	IOpen the Philips OSD menu by pressing the Home button on the remote.	
02	Go to Advanced option sub menu and select date and time.	
I() \	In the date and time menu configure the date $\&$ time correctly and if the network allows it you can enable auto sync date and time.	
04	Go back to the PADS4Philips app.	

2.4.2. Optional: Shutdown and Wake on LAN support.

If you want to be able to power off and start the device with the PADS4 Agent. You need to change power state to last status and enable Wake on LAN (WOL). The default power option Force On, mean the device will always be turned on when connected to a power socket.

Step	Description
01	Open the Philips OSD menu by pressing the Home button on the remote.
02	Open the configuration 1 sub menu.
03	Select Switch on state and change to Last status.
04	Select WOL and turn On.
05	Close OSD menu.

2.4.3. Optional: Enable TeamViewer

If you have a TeamViewer account, you can connect your Philips device to TeamViewer to manage the device remotely.

Step	Description
01	Enter the android menu by pressing home 1 8 8 8.
02	Select Settings and go to Signage Display.
03	Enable TeamViewer Support, if not already enabled.
04	Go back to the android menu.
05	Select Apps and open the Host app. (TeamViewer Host)
06	Specify your TeamViewer account, click assign device.
07	Follow the instructions from the email that you will receive from TeamViewer.
08	Click on assign again.
09	Go back to the PADS4Philips App.

2.5. Connecting to PADS4 Server

Now the device is ready to run the PADS4 Viewer and we only need to connect to the PADS4 Server. To do this, you only need to specify the PADS4 Server Address and press the start button. The PADS4 Server Address format looks like this:

/<hostpath>/

- Protocol: should either be http or https, depending if you are hosting with a valid public signed ssl certificate
- Host: DNS name or ip address of the PADS4 Server

- Port: is optional, if the PADS4 server not using the default ports for http or https, you should specify the port number.
- The configured hostpath in system management, the default value is PADS4.

Example: http://localhost/pads4

Connecting to the PADS4 Server:

Step	Description
01	Specify the correct PADS4 Server Location.
02	Optionally specify a viewer name, if not specified the PADS4 Server will generate one.
03	Press the start button.
04	Wait until the viewer download is finished, then the viewer will start.
05	The first time it will ask for the permission to permanently store content on the device, grant this permission.

Now the viewer should start and connect to the PADS4 Server. After that, you can configure the other settings like screen orientation or block remote control with the PADS4 Agent or in the Viewer Settings.

2.6. Adjust PADS4 Viewer settings using the options screen

You can adjust the PADS4 Viewer settings directly on the display. To enter the options screen on the device itself, hold the left mouse button down or touch the screen for 3 seconds. In the options screen you can also return to the PADS4Philips app by pressing the Launcher Settings button.

2.7. Updating PADS4 Viewer and PADS4Philips app

After the initial installation of the PADS4 Viewer and PADS4Philips app, if you update the PADS4 Server the PADS4 Viewer and PADS4Philips app will automatically update to the version available on the PADS4 Server.

2.8. Accessing Android menu when PADS4 Viewer is running

If you open the Android menu by pressing home 1 8 8 8, on the remote control, when the PADS4 Viewer is running, it will probably restart the device in about 30 seconds. This is because the viewer monitor service detects that the viewer is no longer running and because of this the device will reboot. To access the menu properly, you first need to open the PADS4Philips App as described in '2.6 Adjust PADS4 Viewer settings using the options screen'. Then you can press home 1 8 8 8 without the device rebooting.

3. Supported features and limitations xxBDL3050Q

Support	Category	Description		
M	Automatic PADS4 Software updates	After the initial installation of the PADS4 Viewer and PADS4Philips app, if you update the PADS4 Server the PADS4 Viewer and PADS4Philips app will automatically update to the version available on the PADS4 Server.		
\square	Offline mode of device	While offline from the network, the device will still continue to play PADS4 presentations and change planned schedules for 7 days. Scheduled presentations, content and data is cached local.		
	Device			
\square	Portrait mode	Supported. Device will adjust the rotation automatically.		
\subseteq	Block remote control	Option to prevent usage of re operate the screen	mote control to	
\subseteq	Transfer protocols	HTTP, HTTPS		
\subseteq	Turn off display	Turn off display when no presentation scheduled. Device still active but backlight is turned off for less power consumption		
\subseteq	Cluster Viewer	This device is able to be used	as Cluster Viewer	
	Elements			
	Video element	Maximum number of videos	1 video on each page. Check out the supplier documentation for more info	
	video element	Video rotation	Not supported	
		Seamless videos	In landscape mode only	
		Reflection, skew, flip	Not supported	
		Streaming	HTTP	
\subseteq	lmage element	Support for JPG, PNG, BMP, GIF		
\subseteq	Text element	Supported		

√ i	Line element	Supported	
	Shape element	Supported	
	Scrolling text element	Supported	
\triangle	Formatted text element	Supported	
	Flash element	Not supported	
\leq	Table element	Supported	
	Interactive button element	Supported Mouse cursor options not supported Interactive Data filter & sort dialog window not supported	
\square	Web element	Usage of the interactive Address Bar not supported	
	Data connections	Data connections make it possible to show information from external sources inside presentations	
\subseteq	Data providers	More than 70 PADS4 data providers for retrieval of (realtime) data from external sources and the possibility to change and join the data to fit your purpose	
\leq	Viewer Variables	Usage of Viewer Variables can simplify your presentations and data connections. It also gives the opportunity to centrally manage the content without changing presentations or data providers.	
\subseteq	Property bindings	Apply element properties by using external data sources	
	Rules	Rules will make it possible to interact on certain situations like realtime data and change the behavior of a presentation automatically	
\subseteq	Presentation rules	Supported	
\subseteq	Page rules	Supported	
\subseteq	Element rules	Supported	
	Device Management	Device management which can be performed from a remote location	

		Connection state	Device connection state information
		Alerts	Automatically send out alerts when network failures occur for this device
		Reboot	Reboot device
		Restart Viewer	Restart PADS4 Viewer
		Shutdown	Shutdown device
		Wake On Lan	Remotely start device
\subseteq	Remote device management Web based and Windows	Screenshot	Retrieve screenshots for what is actually displayed
		Logs	Viewer log, synchronization log, system info
		Viewer Settings	Edit Viewer Settings
		Fonts	Install Fonts on device
		Proof of play	Show Proof of play information
		Blackbox	If help from NDS Support is required, the blackbox con- tains important information for investigation purposes
	Remarks		
	Colors	Texture and patter	n colors are not supported
Ģ	Transition effects	Horizontal and vertical blinds not supported Splitters, increased circle and sliced circle not supported	
	Content file integrity	PADS4 Content Library file integrity is checked dur- ing synchronization using MD5	
口	Proof of play	Local storage limitation of max. 50.000 records on the HTML5 Viewer during offline period. When the 50.000 is hit, the oldest value will be removed first.	

4. Troubleshooting

Problem	Solution
Block remote control, turn off display, shutdown command and other native com-	Make sure sicp over
mand on Philips device are not working.	network is enabled

	and hosted on port 5000.
When the viewer is starting, the browser is not running full screen.	Check your firmware version, probably an incompatible version of the firmware is installed.
Device fails to connect to the network over Ethernet.	Updating the firm- ware might solve this problem.
The navigation bar is visible on the device.	Updating the firm- ware should solve this problem.
Every time the viewer starts, it asks for the permission to permanently store cortent on the device.	Check your firmware version, probably an incompatible version of the firmware is installed.
Device not starting on WOL command.	Check if the WOL is enabled on the device and that a power save mode is selected, that allows WOL.
Used valid certificate is not accepted by the PADS4Philips app.	Check if the date and time are configured correctly on the device.



PADS4 Installation Manual

PADS4 Viewer on Philips series (<size>BDL4050D)

Contents

- 1. First time use
- 1.1. Configuring the device
- 1.2. Resetting the device
- 2. Installing PADS4 Viewer
- 2.1. Checking device firmware
- 2.2. Updating device firmware
- 2.3. Install PADS4Philips from USB stick
- 2.4. Configuring the device for PADS4Philips
- 2.4.1. Validate Date Time configuration
- 2.4.2. Optional: Shutdown and Wake on LAN support
- 2.4.3. Optional: Enable TeamViewer
- 2.5. Connecting to PADS4 Server
- 2.6. Adjust PADS4 Viewer settings using the options screen
- 2.7. Updating PADS4 Viewer and PADS4Philips app
- 2.8. Accessing Android menu when PADS4 Viewer is running
- 3. Supported features & limitations
- 4. Troubleshooting

1. First time use

During the installation, you will need to configure the PADS4 Server location. Best approach is to complete the installation of the PADS4 Server first, before continuing the configuration of the device.

The minimum PADS4 Server version required for the PADS4Philips app is version PADS4 Foundation 2020.3.

When you turn the device on for the first time, it will open a configuration wizard. Follow the steps and specify the settings, as mentioned below. (If the configuration wizard does not start, then please first factory reset your device, as described in '1.2 resetting the device'.)

1.1. Configuring the device

Step	Description	
01	In the Welcome screen select your preferred language and click start.	
02	On the Security Setting screen, make sure that 'SICP Network Port' is enabled. Optionally you can enable or disable the other settings. Press next to continue.	
03	On the Network Setting screen, select your preferred network type, press next and configure this accordingly.	
04	On the Signage Display Settings screen, press the skip button.	
05	On the Clone Media Files screen, also press the skip button.	
05	Setup Complete press the finish button.	

The device will show CMND & Deploy, an app supplied by Philips, you do not need to configure this app.


1.2. Resetting the device

If your device was used before, we recommend that you factory reset your device, so that all storage is freed and no other software interferes with the PADS4 Viewer software.

Step	Description	
01	Enter the android menu by pressing the Home button followed by the numbers 1 8 8 8 on the remote control.	
02	Open the settings.	
03	Select System Tools -> Factory Reset.	
04	Click on Factory Reset and confirm by pressing OK.	

The device will factory reset and afterwards you will see the welcome screen, please follow the steps as described in '1.1 configuring the device'.

2. Installing PADS4 Viewer



To install the PADS4 Viewer on the Philips display, you first need to get in the android menu of this

device. To open the android menu, press the home button followed by numbers 1 8 8 8 on the Philips remote control.

2.1. Checking device firmware

To run the PADS4 viewer properly on the xxBDL4050D and make sure that all functionality works, you need to have firmware version FB11.04 installed on the device. Please check using the following steps.

Step	Description
01	Enter the android menu by pressing home 1 8 8 8.
02	Open the settings.
03	Select about.
04	The build number should match FB11.4

2.2. Updating device firmware

To update the firmware please follow the instructions in the document provided by Philips: https://www.dropbox.com/s/xi0oh0ktytp0fp1/XXBDL4050D_Android%2011_04.pdf?dl=0

2.3. Install PADS4Philips from USB stick

The PADS4Philips.apk can be found on the PADS4 Server in the apps folder of the PADS4 installation directory. The default PADS4 installation directory is 'C:\Program Files\Net Display Systems\PADS4'.

You can also download the latest version of PADS4Philips from http://go.pads4.com/?fwlink=1006. If you download the latest version, make sure that you will also place it in the apps directory on the PADS4 Server, because if the server is containing a different version, it will install that version of the PADS4Philips app, once connected to the PADS4 Server.

Step	Description	
01	Copy the PADS4Philips.apk on a USB stick.	
02	Insert the USB stick into the device.	
03	Enter the android menu by pressing home 1 8 8 8.	
04	Select Apps and open the File Manager app.	
05	Open folders mnt -> usb_storage and open the PADS4Philips.apk.	
06	Select install and after installation open the app.	

2.4. Configuring the device for PADS4Philips

Next we are going to change the device setting to make sure it automatically start the PADS4 Viewer on device startup.

Step	Description	
01	In the PADS4Philips app open Android settings by clicking on System Settings.	
02	Select Signage Display -> Custom app.	
03	Click Select App, then select PADS4Philips and press save.	
04	Enable force restart custom app.	
05	Press 3x back until you reached PADS4Philips app.	
06	Then open the Philips OSD Menu pressing the home button.	
07	Open the configuration 1 sub menu and select Boot on source.	
08	Select input custom and press back.	
09	Close OSD menu.	

2.4.1. Validate Date Time configuration

Validate if the date and time are setup correctly on the device, otherwise it is possible that you will get certificate errors or other connection issues.

Step	Description	
01	IOpen the Philips OSD menu by pressing the Home button on the remote.	
02	Go to Advanced option sub menu and select date and time.	
03	In the date and time menu configure the date & time correctly and if the network allows it you can enable auto sync date and time.	
04	Go back to the PADS4Philips app.	

2.4.2. Optional: Shutdown and Wake on LAN support.

If you want to be able to power off and start the device with the PADS4 Agent. You need to change power state to last status and enable Wake on LAN (WOL). The default power option Force On, mean the device will always be turned on when connected to a power socket.

Step	Description	
01	Open the Philips OSD menu by pressing the Home button on the remote.	
02	Open the configuration 1 sub menu.	
03	Select Switch on state and change to Last status.	
04	Select WOL and turn On.	
05	Close OSD menu.	

2.4.3. Optional: Enable TeamViewer

If you have a TeamViewer account, you can connect your Philips device to TeamViewer to manage the device remotely.

Step	Description	
01	Enter the android menu by pressing home 1 8 8 8.	
02	Select Settings and go to Signage Display.	
03	Enable TeamViewer Support, if not already enabled.	
04	Go back to the android menu.	
05	Select Apps and open the Host app. (TeamViewer Host)	
06	Specify your TeamViewer account, click assign device.	
07	Follow the instructions from the email that you will receive from TeamViewer.	
80	Click on assign again.	
09	Go back to the PADS4Philips App.	

2.5. Connecting to PADS4 Server

Now the device is ready to run the PADS4 Viewer and we only need to connect to the PADS4 Server. To do this, you only need to specify the PADS4 Server Address and press the start button. The PADS4 Server Address format looks like this:

/<hostpath>/

- Protocol: should either be http or https, depending if you are hosting with a valid public signed ssl certificate
- Host: DNS name or ip address of the PADS4 Server
- Port: is optional, if the PADS4 server not using the default ports for http or https, you should specify the port number.
- The configured hostpath in system management, the default value is PADS4.

Example: http://localhost/pads4

Connecting to the PADS4 Server:

Step	Description	
01	Specify the correct PADS4 Server Location.	
02	Optionally specify a viewer name, if not specified the PADS4 Server will generate one.	
03	Press the start button.	
04	Wait until the viewer download is finished, then the viewer will start.	
05	The first time it will ask for the permission to permanently store content on the device, grant this permission.	

Now the viewer should start and connect to the PADS4 Server. After that, you can configure the other settings like screen orientation or block remote control with the PADS4 Agent or in the Viewer Settings.

2.6. Adjust PADS4 Viewer settings using the options screen

You can adjust the PADS4 Viewer settings directly on the display. To enter the options screen on the device itself, hold the left mouse button down or touch the screen for 3 seconds. In the options screen you can also return to the PADS4Philips app by pressing the Launcher Settings button.

2.7. Updating PADS4 Viewer and PADS4Philips app

After the initial installation of the PADS4 Viewer and PADS4Philips app, if you update the PADS4 Server the PADS4 Viewer and PADS4Philips app will automatically update to the version available on the PADS4 Server.

2.8. Accessing Android menu when PADS4 Viewer is running

If you open the Android menu by pressing home 1 8 8 8, on the remote control, when the PADS4 Viewer is running, it will probably restart the device in about 30 seconds. This is because the viewer monitor service detects that the viewer is no longer running and because of this the device will reboot. To access the menu properly, you first need to open the PADS4Philips App as described in '2.6 Adjust PADS4 Viewer settings using the options screen'. Then you can press home 1 8 8 8 without the device rebooting.

3. Supported features and limitations xxBDL4050D

Support	Category	Description
		After the initial installation of the PADS4 Viewer
		and PADS4Philips app, if you update the PADS4
\mathbf{M}	Automatic PADS4 Software updates	Server the PADS4 Viewer and PADS4Philips app
		will automatically update to the version available
		on the PADS4 Server.
		While offline from the network, the device will still
		continue to play PADS4 presentations and change
\triangle	Offline mode of device	planned schedules for 7 days.
		Scheduled presentations, content and data is
		cached local.
	Device	

\subseteq	Portrait mode	Supported. Device will adjust the rotation automatically.		
\subseteq	Block remote control	Option to prevent usage of remote control to operate the screen		
\subseteq	Transfer protocols	HTTP, HTTPS		
\square	Turn off display	Turn off display when no presentation scheduled. Device still active but backlight is turned off for less power consumption		
\subseteq	Cluster Viewer	This device is able to be used as Cluster Viewer		
	Elements			
M	Video element	Maximum number of videos	1 video on each page. Check out the supplier documentation for more info	
	Video ciement	Video rotation	Not supported	
		Seamless videos	In landscape mode only	
		Reflection, skew, flip Streaming	Not supported HTTP	
\subseteq	lmage element	Support for JPG, PNG, BMP, GIF		
\subseteq	Text element	Supported		
M	Line element	Supported		
\subseteq	Shape element	Supported		
\subseteq	Scrolling text element	Supported		
\subseteq	Formatted text element	Supported		
	Flash element	Not supported		
\subseteq	Table element	Supported		
M	Interactive button element	Supported Mouse cursor options not supported Interactive Data filter & sort dialog window not supported		
\subseteq	Web element	Usage of the interactive Addre ported	ess Bar not sup-	


	Data connections		nake it possible to show inform- I sources inside presentations
\subseteq	Data providers	More than 70 PADS4 data providers for retrieval of (realtime) data from external sources and the possibility to change and join the data to fit your purpose	
	Viewer Variables	Usage of Viewer Variables can simplify your presentations and data connections. It also gives the opportunity to centrally manage the content without changing presentations or data providers.	
\subseteq	Property bindings	Apply element properties by using external data sources	
	Rules	Rules will make it possible to interact on certain situations like realtime data and change the behavior of a presentation automatically	
\subseteq	Presentation rules	Supported	
\subseteq	Page rules	Supported	
\subseteq	Element rules	Supported	
	Device Management	Device management which can be performed from a remote location	
		Connection state	Device connection state information
		Alerts	Automatically send out alerts when network failures occur for this device
	Remote device management	Reboot	Reboot device
∑		Restart Viewer	Restart PADS4 Viewer
	Web based and Windows	Shutdown	Shutdown device
	web based and willdows	Wake On Lan	Remotely start device
		Screenshot	Retrieve screenshots for what is actually displayed
		Logs	Viewer log, synchronization log, system info
		Viewer Settings	Edit Viewer Settings

	•		
		Fonts	Install Fonts on device
		Proof of play	Show Proof of play information
		Blackbox	If help from NDS Support is required, the blackbox con- tains important information for investigation purposes
	Remarks		
	Remarks		
	Colors	Texture and pattern colors are not supported	
Q	Transition effects	Horizontal and vertical blinds not supported Splitters, increased circle and sliced circle not supported	
	Content file integrity	PADS4 Content Library file integrity is checked dur- ing synchronization using MD5	
Image: Control of the	Proof of play	Local storage limitation of max. 50.000 records on the HTML5 Viewer during offline period. When the 50.000 is hit, the oldest value will be removed first.	

4. Troubleshooting

Problem	Solution
Block remote control, turn off display, shutdown command and other native command on Philips device are not working.	Make sure sicp over network is enabled and hosted on port 5000.
When the viewer is starting, the browser is not running full screen.	Check your firmware version, probably an incompatible version of the firmware is installed.
Device fails to connect to the network over Ethernet.	Updating the firm- ware might solve this problem.
The navigation bar is visible on the device.	Updating the firm- ware should solve this problem.
Every time the viewer starts, it asks for the permission to permanently store content on the device.	Check your firmware version, probably an

incompatible version of the firmware is installed.



PADS4 Installation Manual

PADS4 Viewer on Philips series (<size>BDL4150D)

Contents

- 1. First time use
- 1.1. Configuring the device
- 1.2. Resetting the device
- 2. Installing PADS4 Viewer
- 2.1. Checking device firmware
- 2.2. Updating device firmware
- 2.3. Install PADS4Philips from USB stick
- 2.4. Configuring the device for PADS4Philips
- 2.4.1. Validate Date Time configuration
- 2.4.2. Optional: Shutdown and Wake on LAN support
- 2.4.3. Optional: Enable TeamViewer
- 2.5. Connecting to PADS4 Server
- 2.6. Adjust PADS4 Viewer settings using the options screen
- 2.7. Updating PADS4 Viewer and PADS4Philips app

- 2.8. Accessing Android menu when PADS4 Viewer is running
- 3. Supported features & limitations
- 4. Troubleshooting

1. First time use

During the installation, you will need to configure the PADS4 Server location. Best approach is to complete the installation of the PADS4 Server first, before continuing the configuration of the device.

The minimum PADS4 Server version required for the PADS4Philips app is version PADS4 Foundation 2020.3.

When you turn the device on for the first time, it will open a configuration wizard. Follow the steps and specify the settings, as mentioned below. (If the configuration wizard does not start, then please first factory reset your device, as described in '1.2 resetting the device'.)

1.1. Configuring the device

Step	Description	
01	In the Welcome screen select your preferred language and click start.	
02	On the Security Setting screen, make sure that 'SICP Network Port' is enabled. Optionally you can enable or disable the other settings. Press next to continue.	
03	On the Signage Display Settings screen, press the skip button.	
04	On the Network Setting screen, select your preferred network type, press next and configure this accordingly.	
05	On the Clone Media Files screen, also press the skip button.	
05	Setup Complete press the finish button.	

The device will show CMND & Deploy, an app supplied by Philips, you do not need to configure this app.

1.2. Resetting the device


If your device was used before, we recommend that you factory reset your device, so that all storage is freed and no other software interferes with the PADS4 Viewer software.

Step	Description
101	Enter the android menu by pressing the Home button followed by the numbers 1888 on the
	remote control.

02	Open the settings.	
03	Select Signage Display -> System Tools -> Factory Reset.	
04	Click on Factory Reset and confirm by pressing OK.	

The device will factory reset and afterwards you will see the welcome screen, please follow the steps as described in '1.1 configuring the device'.

2. Installing PADS4 Viewer



To install the PADS4 Viewer on the Philips display, you first need to get in the android menu of this device. To open the android menu, press the home button followed by numbers 1888 on the Philips remote control.

2.1. Checking device firmware

To run the PADS4 viewer properly on the xxBDL4150D and make sure that all functionality works, you need to have firmware version FB04.7 installed on the device. Please check using the following steps.

Step	Description
01	Enter the android menu by pressing home 1 8 8 8.
02	Open the settings.
03	Select about.
04	The build number should match FB04.7

2.2. Updating device firmware

To update the firmware please follow the instructions in the document provided by Philips: https://www.dropbox.com/s/3xuahr7rinmtvqw/FB04.07%20%26%201.130.pdf?dl=0

2.3. Install PADS4Philips from USB stick

The PADS4Philips.apk can be found on the PADS4 Server in the apps folder of the PADS4 installation directory. The default PADS4 installation directory is 'C:\Program Files\Net Display Systems\PADS4'.

You can also download the latest version of PADS4Philips from http://go.pads4.com/?fwlink=1006. If you download the latest version, make sure that you will also place it in the apps directory

on the PADS4 Server, because if the server is containing a different version, it will install that version of the PADS4Philips app, once connected to the PADS4 Server.

Step	Description	
01	Copy the PADS4Philips.apk on a USB stick.	
02	Insert the USB stick into the device.	
03	Enter the android menu by pressing home 1 8 8 8.	
04	Select Storage -> your USB drive and open the PADS4Philips.apk.	
05	Select install and after installation open the app.	

2.4. Configuring the device for PADS4Philips

Next we are going to change the device setting to make sure it automatically start the PADS4 Viewer on device startup.

Step	Description	
01	In the PADS4Philips app open Android settings by clicking on System Settings.	
02	Select Signage Display -> Source settings -> Custom App.	
03	Click Select App, then select PADS4Philips and press save.	
04	Enable force restart custom app.	
05	Press 4x back until you reached PADS4Philips app.	
06	Then open the Philips OSD Menu pressing the home button.	
07	Open the configuration 1 sub menu and select Boot on source.	
80	Select input custom and press back.	
09	Close OSD menu.	

2.4.1. Validate Date Time configuration

Validate if the date and time are setup correctly on the device, otherwise it is possible that you will get certificate errors or other connection issues.

Step	Description	
01	IOpen the Philips OSD menu by pressing the Home button on the remote.	
02	Go to Advanced option sub menu and select date and time.	
()3	In the date and time menu configure the date & time correctly and if the network allows it you can enable auto sync date and time.	
04	Go back to the PADS4Philips app.	

2.4.2. Optional: Shutdown and Wake on LAN support.

If you want to be able to power off and start the device with the PADS4 Agent. You need to change power state to last status and enable Wake on LAN (WOL). The default power option Force On, mean the device will always be turned on when connected to a power socket.

Step	Description	
01	Open the Philips OSD menu by pressing the Home button on the remote.	
02	Open the configuration 1 sub menu.	
03	Select Switch on state and change to Last status.	
04	Press back and open the advanced option sub menu.	
05	Scroll down to the APM (Advanced Power Management) option and select mode1 (TCP off, WOL on).	
06	Close OSD menu.	

2.4.3. Optional: Enable TeamViewer

If you have a TeamViewer account, you can connect your Philips device to TeamViewer to manage the device remotely.

Step	Description	
01	Enter the android menu by pressing home 1 8 8 8.	
02	Select Settings and go to Signage Display -> Misc.	
03	Enable TeamViewer Support, if not already enabled.	
04	Go back to the android menu.	
05	Select Apps and open the Host app. (TeamViewer Host)	
06	Specify your TeamViewer account, click assign device.	
07	Follow the instructions from the email that you will receive from TeamViewer.	
08	Click on assign again.	
09	Go back to the PADS4Philips App.	

2.5. Connecting to PADS4 Server

Now the device is ready to run the PADS4 Viewer and we only need to connect to the PADS4 Server. To do this, you only need to specify the PADS4 Server Address and press the start button. The PADS4 Server Address format looks like this:

/<hostpath>/

• Protocol: should either be http or https, depending if you are hosting with a valid public signed ssl certificate

- Host: DNS name or ip address of the PADS4 Server
- Port: is optional, if the PADS4 server not using the default ports for http or https, you should specify the port number.
- The configured hostpath in system management, the default value is PADS4.

Example: http://localhost/pads4

Connecting to the PADS4 Server:

Step	Description	
01	Specify the correct PADS4 Server Location.	
02	Optionally specify a viewer name, if not specified the PADS4 Server will generate one.	
03	Press the start button.	
04	Wait until the viewer download is finished, then the viewer will start.	
05	The first time it will ask for the permission to permanently store content on the device, grant this permission.	

Now the viewer should start and connect to the PADS4 Server. After that, you can configure the other settings like screen orientation or block remote control with the PADS4 Agent or in the Viewer Settings.

2.6. Adjust PADS4 Viewer settings using the options screen

You can adjust the PADS4 Viewer settings directly on the display. To enter the options screen on the device itself, hold the left mouse button down or touch the screen for 3 seconds. In the options screen you can also return to the PADS4Philips app by pressing the Launcher Settings button.

2.7. Updating PADS4 Viewer and PADS4Philips app

After the initial installation of the PADS4 Viewer and PADS4Philips app, if you update the PADS4 Server the PADS4 Viewer and PADS4Philips app will automatically update to the version available on the PADS4 Server.

2.8. Accessing Android menu when PADS4 Viewer is running

If you open the Android menu by pressing home 1 8 8 8, on the remote control, when the PADS4 Viewer is running, it will probably restart the device in about 30 seconds. This is because the viewer monitor service detects that the viewer is no longer running and because of this the device will reboot. To access the menu properly, you first need to open the PADS4Philips App as described in '2.6 Adjust PADS4 Viewer settings using the options screen'. Then you can press home 1 8 8 8 without the device rebooting.

3. Supported features and limitations xxBDL4150D

Support	Category	Description	
M	Automatic PADS4 Software updates	After the initial installation of the and PADS4Philips app, if you userver the PADS4 Viewer and will automatically update to the on the PADS4 Server.	pdate the PADS4 PADS4Philips app
\square	Offline mode of device	While offline from the network continue to play PADS4 preser planned schedules for 7 days. Scheduled presentations, contached local.	ntations and change
	Device		
\square	Portrait mode	Supported. Device will adjust t matically.	he rotation auto-
\square	Block remote control	Option to prevent usage of re operate the screen	mote control to
\subseteq	Transfer protocols	HTTP, HTTPS	
\subseteq	Turn off display	Turn off display when no preso Device still active but backlight less power consumption	
\subseteq	Cluster Viewer	This device is able to be used	as Cluster Viewer
	Elements		
	Video element	Maximum number of videos	4 videos on each page. Check out the supplier documentation for more info
	video element	Video rotation	Not supported
		Seamless videos	In landscape mode only
		Reflection, skew, flip	Not supported
		Streaming	HTTP
\subseteq	lmage element	Support for JPG, PNG, BMP, G	IF
\subseteq	Text element	Supported	

√ i	Line element	Supported
	Shape element	Supported
	Scrolling text element	Supported
\triangle	Formatted text element	Supported
	Flash element	Not supported
\leq	Table element	Supported
	Interactive button element	Supported Mouse cursor options not supported Interactive Data filter & sort dialog window not supported
\square	Web element	Usage of the interactive Address Bar not supported
	Data connections	Data connections make it possible to show information from external sources inside presentations
\subseteq	Data providers	More than 70 PADS4 data providers for retrieval of (realtime) data from external sources and the possibility to change and join the data to fit your purpose
\leq	Viewer Variables	Usage of Viewer Variables can simplify your presentations and data connections. It also gives the opportunity to centrally manage the content without changing presentations or data providers.
\subseteq	Property bindings	Apply element properties by using external data sources
	Rules	Rules will make it possible to interact on certain situations like realtime data and change the behavior of a presentation automatically
\subseteq	Presentation rules	Supported
\subseteq	Page rules	Supported
\subseteq	Element rules	Supported
	Device Management	Device management which can be performed from a remote location

		Connection state	Device connection state information
		Alerts	Automatically send out alerts when network failures occur for this device
		Reboot	Reboot device
		Restart Viewer	Restart PADS4 Viewer
		Shutdown	Shutdown device
		Wake On Lan	Remotely start device
\subseteq	Remote device management Web based and Windows	Screenshot	Retrieve screenshots for what is actually displayed
		Logs	Viewer log, synchronization log, system info
		Viewer Settings	Edit Viewer Settings
		Fonts	Install Fonts on device
		Proof of play	Show Proof of play information
		Blackbox	If help from NDS Support is required, the blackbox con- tains important information for investigation purposes
	Remarks		
	Colors	Texture and patter	n colors are not supported
Ģ	Transition effects	Horizontal and ver	tical blinds not supported d circle and sliced circle not sup-
	Content file integrity	·	rary file integrity is checked dur- n using MD5
口	Proof of play	the HTML5 Viewer	ation of max. 50.000 records on during offline period. s hit, the oldest value will be

4. Troubleshooting

Problem	Solution
Block remote control, turn off display, shutdown command and other native com-	Make sure sicp over
mand on Philips device are not working.	network is enabled

	and hosted on port 5000.
When the viewer is starting, the browser is not running full screen.	Check your firmware version, probably an incompatible version of the firmware is installed.
Device fails to connect to the network over Ethernet.	Updating the firm- ware might solve this problem.
The navigation bar is visible on the device.	Updating the firm- ware should solve this problem.
Every time the viewer starts, it asks for the permission to permanently store content on the device.	Check your firmware version, probably an incompatible version of the firmware is installed.
Device not starting on WOL command.	Check if the WOL is enabled on the device and that a power save mode is selected, that allows WOL.
Used valid certificate is not accepted by the PADS4Philips app.	Check if the date and time are configured correctly on the device.



PADS4 Installation Manual

PADS4 Viewer on Philips series (<size>BDL505xP)

Contents

- 1. First time use
- 1.1. Configuring the device
- 1.2. Resetting the device
- 2. Installing PADS4 Viewer
- 2.1. Checking device firmware
- 2.2. Updating device firmware
- 2.3. Install PADS4Philips from USB stick
- 2.4. Configuring the device for PADS4Philips
- 2.4.1. Validate Date Time configuration
- 2.4.2. Optional: Shutdown and Wake on LAN support
- 2.4.3. Optional: Enable TeamViewer
- 2.5. Connecting to PADS4 Server
- 2.6. Adjust PADS4 Viewer settings using the options screen
- 2.7. Updating PADS4 Viewer and PADS4Philips app
- 2.8. Accessing Android menu when PADS4 Viewer is running
- 3. Supported features & limitations
- 4. Troubleshooting

1. First time use

During the installation, you will need to configure the PADS4 Server location. Best approach is to complete the installation of the PADS4 Server first, before continuing the configuration of the device.

The minimum PADS4 Server version required for the PADS4Philips app is version PADS4 Foundation 2020.3.

When you turn the device on for the first time, it will open a configuration wizard. Follow the steps and specify the settings, as mentioned below. (If the configuration wizard does not start, then please first factory reset your device, as described in '1.2 resetting the device'.)

1.1. Configuring the device

Step	Description
01	In the Welcome screen select your preferred language and click start.
02	On the Security Setting screen, make sure that 'SICP Network Port' is enabled. Optionally you can enable or disable the other settings. Press next to continue.
03	On the Network Setting screen, select your preferred network type, press next and configure this accordingly.
04	On the Signage Display Settings screen, press the skip button.
05	On the Clone Media Files screen, also press the skip button.
06	Setup Complete press the finish button.

The device will show CMND & Deploy, an app supplied by Philips, you do not need to configure this app.


1.2. Resetting the device

If your device was used before, we recommend that you factory reset your device, so that all storage is freed and no other software interferes with the PADS4 Viewer software.

Step	Description
101	Enter the android menu by pressing the Home button followed by the numbers 1 8 8 8 on the remote control.
02	Open the settings.
03	Select System Tools -> Factory Reset.
04	Click on Factory Reset and confirm by pressing OK.

The device will factory reset and afterwards you will see the welcome screen, please follow the steps as described in '1.1 configuring the device'.

2. Installing PADS4 Viewer



To install the PADS4 Viewer on the Philips display, you first need to get in the android menu of this

device. To open the android menu, press the home button followed by numbers 1 8 8 8 on the Philips remote control.

2.1. Checking device firmware

To run the PADS4 viewer properly on the xxBDL505xP and make sure that all functionality works, you need to have firmware version FB07.7 installed on the device. Please check using the following steps.

Step	Description
01	Enter the android menu by pressing home 1 8 8 8.
02	Open the settings.
03	Select about.
04	The build number should match FB07.7

2.2. Updating device firmware

To update the firmware please follow the instructions in the document provided by Philips: https://www.dropbox.com/s/srqgx37qimlifo0/XXBDL505xP_Android-%20FB07.07%20%26%20scaler%201_315.pdf?dl=0

2.3. Install PADS4Philips from USB stick

The PADS4Philips.apk can be found on the PADS4 Server in the apps folder of the PADS4 installation directory. The default PADS4 installation directory is 'C:\Program Files\Net Display Systems\PADS4'.

You can also download the latest version of PADS4Philips from http://go.pads4.com/?fwlink=1006. If you download the latest version, make sure that you will also place it in the apps directory on the PADS4 Server, because if the server is containing a different version, it will install that version of the PADS4Philips app, once connected to the PADS4 Server.

Step	Description
01	Copy the PADS4Philips.apk on a USB stick.
02	Insert the USB stick into the device.
03	Enter the android menu by pressing home 1 8 8 8.
04	Select Apps and open the File Manager app.
05	Open folders mnt -> usb_storage and open the PADS4Philips.apk.
06	Select install and after installation open the app.

2.4. Configuring the device for PADS4Philips

Next we are going to change the device setting to make sure it automatically start the PADS4 Viewer on device startup.

Step	Description
01	In the PADS4Philips app open Android settings by clicking on System Settings.
02	Select Signage Display -> Custom App.
03	Click Select App, then select PADS4Philips and press save.
04	Enable force restart custom app.
05	Press 3x back until you reached PADS4Philips app.
06	Then open the Philips OSD Menu pressing the home button.
07	Open the configuration 1 sub menu and select Boot on source.
08	Select input custom and press back.
09	Close OSD menu.

2.4.1. Validate Date Time configuration

Validate if the date and time are setup correctly on the device, otherwise it is possible that you will get certificate errors or other connection issues.

Step	Description
01	Open the Philips OSD menu by pressing the Home button on the remote.
02	Go to Advanced option sub menu and select date and time.
03	In the date and time menu configure the date $\&$ time correctly and if the network allows it you can enable auto sync date and time.
04	Go back to the PADS4Philips app.

2.4.2. Optional: Shutdown and Wake on LAN support.

If you want to be able to power off and start the device with the PADS4 Agent. You need to change power state to last status and enable Wake on LAN (WOL). The default power option Force On, mean the device will always be turned on when connected to a power socket.

Step	Description
01	Open the Philips OSD menu by pressing the Home button on the remote.
02	Open the configuration 1 sub menu.
03	Select Switch on state and change to Last status.
04	Select WOL and turn On.
05	Close OSD menu.

2.4.3. Optional: Enable TeamViewer

If you have a TeamViewer account, you can connect your Philips device to TeamViewer to manage the device remotely.

Step	Description
01	Enter the android menu by pressing home 1 8 8 8.
02	Select Settings and go to Signage Display.
03	Enable TeamViewer Support, if not already enabled.
04	Go back to the android menu.
05	Select Apps and open the Host app. (TeamViewer Host)
06	Specify your TeamViewer account, click assign device.
07	Follow the instructions from the email that you will receive from TeamViewer.
80	Click on assign again.
09	Go back to the PADS4Philips App.

2.5. Connecting to PADS4 Server

Now the device is ready to run the PADS4 Viewer and we only need to connect to the PADS4 Server. To do this, you only need to specify the PADS4 Server Address and press the start button. The PADS4 Server Address format looks like this:

col>://<host>:<port>/<hostpath>/

- Protocol: should either be http or https, depending if you are hosting with a valid public signed ssl certificate
- Host: DNS name or ip address of the PADS4 Server
- Port: is optional, if the PADS4 server not using the default ports for http or https, you should specify the port number.
- The configured hostpath in system management, the default value is PADS4.

Example: http://localhost/pads4

Connecting to the PADS4 Server:

Step	Description
01	Specify the correct PADS4 Server Location.
02	Optionally specify a viewer name, if not specified the PADS4 Server will generate one.
03	Press the start button.
04	Wait until the viewer download is finished, then the viewer will start.
05	The first time it will ask for the permission to permanently store content on the device, grant this permission.

Now the viewer should start and connect to the PADS4 Server. After that, you can configure the other settings like screen orientation or block remote control with the PADS4 Agent or in the Viewer Settings.

2.6. Adjust PADS4 Viewer settings using the options screen

You can adjust the PADS4 Viewer settings directly on the display. To enter the options screen on the device itself, hold the left mouse button down or touch the screen for 3 seconds. In the options screen you can also return to the PADS4Philips app by pressing the Launcher Settings button.

2.7. Updating PADS4 Viewer and PADS4Philips app

After the initial installation of the PADS4 Viewer and PADS4Philips app, if you update the PADS4 Server the PADS4 Viewer and PADS4Philips app will automatically update to the version available on the PADS4 Server.

2.8. Accessing Android menu when PADS4 Viewer is running

If you open the Android menu by pressing home 1 8 8 8, on the remote control, when the PADS4 Viewer is running, it will probably restart the device in about 30 seconds. This is because the viewer monitor service detects that the viewer is no longer running and because of this the device will reboot. To access the menu properly, you first need to open the PADS4Philips App as described in '2.6 Adjust PADS4 Viewer settings using the options screen'. Then you can press home 1 8 8 8 without the device rebooting.

3. Supported features and limitations xxBDL505xP

Support	Category	Description
		After the initial installation of the PADS4 Viewer
		and PADS4Philips app, if you update the PADS4
\mathbf{M}		Server the PADS4 Viewer and PADS4Philips app
		will automatically update to the version available
		on the PADS4 Server.
	Offline mode of device	While offline from the network, the device will still
		continue to play PADS4 presentations and change
\triangle		planned schedules for 7 days.
		Scheduled presentations, content and data is
		cached local.
	Device	

\subseteq	Portrait mode	Supported. Device will adjust t matically.	the rotation auto-	
\subseteq	Block remote control	Option to prevent usage of remote control to operate the screen		
\subseteq	Transfer protocols	HTTP, HTTPS		
\square	Turn off display	Turn off display when no presentation scheduled. Device still active but backlight is turned off for less power consumption		
\subseteq	Cluster Viewer	This device is able to be used	as Cluster Viewer	
	Elements			
	Video element	Maximum number of videos	2 videos on each page. Check out the supplier documentation for more info	
	Trade clement	Video rotation	Not supported	
		Seamless videos	In landscape mode only	
		Reflection, skew, flip Streaming	Not supported HTTP	
\subseteq	lmage element	Support for JPG, PNG, BMP, G	IF	
\subseteq	Text element	Supported		
Ŋ	Line element	Supported		
\subseteq	Shape element	Supported		
\subseteq	Scrolling text element	Supported		
\subseteq	Formatted text element	Supported		
	Flash element	Not supported		
\subseteq	Table element	Supported		
M	Interactive button element	Supported Mouse cursor options not sup Interactive Data filter & sort di supported	alog window not	
\subseteq	Web element	Usage of the interactive Addre	ess Bar not sup-	

	Data connections		nake it possible to show inform- I sources inside presentations
\subseteq	Data providers	of (realtime) data fi	64 data providers for retrieval rom external sources and the ge and join the data to fit your
	Viewer Variables	Usage of Viewer Variables can simplify your presentations and data connections. It also gives the opportunity to centrally manage the content without changing presentations or data providers.	
\subseteq	Property bindings	Apply element prop sources	perties by using external data
	Rules	1	ossible to interact on certain ime data and change the beha- on automatically
\subseteq	Presentation rules	Supported	
\subseteq	Page rules	Supported	
\subseteq	Element rules	Supported	
	Device Management	Device management which can be performed from a remote location	
		Connection state	Device connection state information
		Alerts	Automatically send out alerts when network failures occur for this device
		Reboot	Reboot device
	Remote device management	Restart Viewer	Restart PADS4 Viewer
ت	Web based and Windows	Shutdown	Shutdown device
		Wake On Lan	Remotely start device
		Screenshot	Retrieve screenshots for what is actually displayed
		Logs	Viewer log, synchronization log, system info
		Viewer Settings	Edit Viewer Settings

	·		
		Fonts	Install Fonts on device
		Proof of play	Show Proof of play information
		Blackbox	If help from NDS Support is required, the blackbox con- tains important information for investigation purposes
	Remarks		
	Remarks		
	Colors	Texture and pattern colors are not supported	
\Box	Transition effects	Horizontal and vertical blinds not supported Splitters, increased circle and sliced circle not supported	
	Content file integrity	PADS4 Content Libring synchronization	rary file integrity is checked dur- nusing MD5
Image: section of the content of the	Proof of play	the HTML5 Viewer	ation of max. 50.000 records on during offline period. hit, the oldest value will be

4. Troubleshooting

Problem	Solution
Block remote control, turn off display, shutdown command and other native command on Philips device are not working.	Make sure sicp over network is enabled and hosted on port 5000.
When the viewer is starting, the browser is not running full screen.	Check your firmware version, probably an incompatible version of the firmware is installed.
Device fails to connect to the network over Ethernet.	Updating the firm- ware might solve this problem.
The navigation bar is visible on the device.	Updating the firm- ware should solve this problem.
Every time the viewer starts, it asks for the permission to permanently store content on the device.	Check your firmware version, probably an

	incompatible ver- sion of the firmware
	is installed.
	Check if the WOL is
	enabled on the
Device not starting on WOL command.	device and that a
g a same g a same a	power save mode is
	selected, that allows
	WOL.
	Check if the date and
Used valid certificate is not accepted by the PADS4Philips app.	time are configured
osed valid certificate is not accepted by the LADS41 fillips app.	correctly on the
	device.



PADS4 Installation Manual

PADS4 Viewer on Philips Multi-Touch series (10BDL3051T)

Contents

- 1. First time use
- 1.1. Configuring the device
- 1.2. Resetting the device
- 2. Installing PADS4 Viewer
- 2.1. Checking device firmware
- 2.2. Updating device firmware
- 2.3. Install PADS4Philips from USB stick
- 2.4. Configuring the device for PADS4Philips

- 2.4.1. Validate Date Time configuration
- 2.4.2. Optional: Enable TeamViewer
- 2.5. Connecting to PADS4 Server
- 2.6. Adjust PADS4 Viewer settings using the options screen
- 2.7. Updating PADS4 Viewer and PADS4Philips app
- 2.8. Accessing Android menu when PADS4 Viewer is running
- 3. Supported features & limitations
- 4. Troubleshooting

1. First time use

During the installation, you will need to configure the PADS4 Server location. Best approach is to complete the installation of the PADS4 Server first, before continuing the configuration of the device.

The minimum PADS4 Server version required for the PADS4Philips app is version PADS4 Foundation 2020.3.

When you turn the device on for the first time, it will open a configuration wizard. Follow the steps and specify the settings, as mentioned below. (If the configuration wizard does not start, then please first factory reset your device, as described in '1.2 resetting the device'.)

1.1. Configuring the device

Step	Description	
01	In the Welcome screen select your preferred language and click start.	
02	On the Security Setting screen, make sure that 'SICP Network Port' is enabled. Optionally you can enable or disable the other settings. Press next to continue.	
03	On the Signage Display Settings screen, press the skip button.	
04	On the Network Setting screen, select your preferred network type, press next and configure this accordingly.	
05	On the Clone Media Files screen, also press the skip button.	
06	Setup Complete press the finish button.	

The device will show the Philips Media Player app.

1.2. Resetting the device

If your device was used before, we recommend that you factory reset your device, so that all storage is freed and no other software interferes with the PADS4 Viewer software.

Step	Description
()1	Enter the android menu by pressing in sequence the home button and the volume button behind the display.
02	Enter the password, the default password is 1234
03	Open the settings.
04	Select System Tools -> Factory Reset.
05	Click on Factory Reset and confirm by pressing OK.

The device will factory reset and afterwards you will see the welcome screen, please follow the steps as described in '1.1 configuring the device'.

2. Installing PADS4 Viewer

To install the PADS4 Viewer on the Philips display, you first need to **get in the android menu of this device**. To open the android menu, press in sequence the home button and the volume down button behind the display. Then it will ask for the admin password, **the default password is 1234**.

2.1. Checking device firmware

To run the PADS4 viewer properly on the 10BDL3051T and make sure that all functionality works, you need to have firmware version FB04.06T4_chrom74.007 installed on the 10BDL3051T. Please check using the following steps.

Step	Description
01	Enter the android menu by pressing home and volume down button in sequence.
02	Specify the admin password (default: 1234).
03	Open the settings.
04	Select about.
05	The build number should match FB04.06T4_chrom74.007

2.2. Updating device firmware

To update the firmware please follow the instructions in the document provided by Philips: https://www.dropbox.com/s/qlbprc1m423cn87/10inches_Update_FB04.06T4.docx?dl=0

2.3. Install PADS4Philips from USB stick

The PADS4Philips.apk can be found on the PADS4 Server in the apps folder of the PADS4 installation directory. The default PADS4 installation directory is 'C:\Program Files\Net Display Systems\PADS4'.

You can also download the latest version of PADS4Philips from http://go.pads4.com/?fwlink=1006.

If you download the latest version, make sure that you will also place it in the apps directory on the PADS4 Server, because if the server is containing a different version, it will install that version of the PADS4Philips app, once connected to the PADS4 Server.

Step	Description
01	Copy the PADS4Philips.apk on a USB stick.
02	Insert the USB stick into the device.
03	Enter the android menu by pressing home and volume down button in sequence.
04	Specify the admin password (default: 1234).
05	Select Apps and open the File Manager app.
06	Open folders mnt -> usb_storage.
07	Open the folder of the USB port with the USB stick and open the PADS4Philips.apk.
80	Select install and after installation open the app.

2.4. Configuring the device for PADS4Philips

Next we are going to change the device setting to make sure it automatically start the PADS4 Viewer on device startup.

Step	Description
01	In the PADS4Philips app open Android settings by clicking on System Settings.
02	Select Signage Display -> Source settings -> Custom app.
03	Click Select App, then select PADS4Philips and press save.
04	Enable force restart custom app.
05	Press back to view the Signage Display settings again.
06	Now select General setting -> Boot on source.
07	Select input custom app and press back until you see the PADS4Philips app again

2.4.1. Validate Date Time configuration

Validate if the date and time are setup correctly on the device, otherwise it is possible that you will get certificate errors or other connection issues.

Step	Description
01	In the PADS4Philips app open Android settings by clicking on System Settings.

02	Go to date & time Menu.	
103	Configure the date & time correctly and if the network allows it you can enable auto sync date and time.	
04	Go back to the PADS4Philips app.	

2.4.2. Optional: Enable TeamViewer

If you have a TeamViewer account, you can connect your Philips device to TeamViewer to manage the device remotely.

Step	Description
01	Enter the android menu by pressing home button and volume down button in sequence.
02	Specify the admin password (default: 1234).
03	Select Settings and go to Signage Display -> Other.
04	Enable TeamViewer Support, if not already enabled.
05	Go back to the android menu.
06	Select Apps and open the Host app. (TeamViewer Host)
07	Specify your TeamViewer account, click assign device.
80	Follow the instructions from the email that you will receive from TeamViewer.
09	Click on assign again.
10	Go back to the PADS4Philips App.

2.5. Connecting to PADS4 Server

Now the device is ready to run the PADS4 Viewer and we only need to connect to the PADS4 Server. To do this, you only need to specify the PADS4 Server Address and press the start button. The PADS4 Server Address format looks like this:

/<hostpath>/

- Protocol: should either be http or https, depending if you are hosting with a valid public signed ssl certificate
- Host: DNS name or ip address of the PADS4 Server
- Port: is optional, if the PADS4 server not using the default ports for http or https, you should specify the port number.
- The configured hostpath in system management, the default value is PADS4.

Example: http://localhost/pads4

Connecting to the PADS4 Server:

Step	Description

01	Specify the correct PADS4 Server Location.	
02	Optionally specify a viewer name, if not specified the PADS4 Server will generate one.	
03	Press the start button.	
04	Allow PADS4Philips to have access to the device storage.	
05	Wait until the viewer download is finished, then the viewer will start.	
06	The first time it will ask for the permission to permanently store content on the device, grant this	
	permission.	

Now the viewer should start and connect to the PADS4 Server. After that, you can configure the other settings like screen orientation or block remote control with the PADS4 Agent or in the Viewer Settings.

2.6. Adjust PADS4 Viewer settings using the options screen

You can adjust the PADS4 Viewer settings directly on the display. To enter the options screen on the device itself, hold the left mouse button down or touch the screen for 3 seconds. In the options screen you can also return to the PADS4Philips app by pressing the Launcher Settings button.

2.7. Updating PADS4 Viewer and PADS4Philips app

After the initial installation of the PADS4 Viewer and PADS4Philips app, if you update the PADS4 Server the PADS4 Viewer and PADS4Philips app will automatically update to the version available on the PADS4 Server.

2.8. Accessing Android menu when PADS4 Viewer is running

If you open the Android menu by pressing the home button and volume down button in sequence, when the PADS4 Viewer is running, it will probably restart the device in about 30 seconds. This is because the viewer monitor service detects that the viewer is no longer running and because of this the device will reboot. To access the menu properly, you first need to open the PADS4Philips App as described in '2.6 Adjust PADS4 Viewer settings using the options screen'. Then you can access the android menu without the device rebooting, using the home button and volume down button in sequence.

3. Supported features and limitations 10BDL3051T

Support	Category	Description
\square	Automatic PADS4 Software updates	After the initial installation of the PADS4 Viewer and PADS4Philips app, if you update the PADS4 Server the PADS4 Viewer and PADS4Philips app

		will automatically update to thon the PADS4 Server.	e version available	
M	Offline mode of device	While offline from the network, the device will still continue to play PADS4 presentations and change planned schedules for 7 days. Scheduled presentations, content and data is cached local.		
	Device			
\square	Portrait mode	Supported. Device will adjust matically.	the rotation auto-	
Ý	Block remote control	Option to prevent usage of remote control to operate the screen		
\subseteq	Transfer protocols	HTTP, HTTPS		
\square	Turn off display	Turn off display when no presentation scheduled. Device still active but backlight is turned off for less power consumption		
	Cluster Viewer	This device is able to be used	as Cluster Viewer	
	Elements			
		Maximum number of videos	1 video on each page. Check out the supplier documentation for more info	
Y	Video element	Video rotation	Not supported	
		Seamless videos	In landscape mode only	
		Reflection, skew, flip Streaming	Not supported HTTP	
\subseteq	lmage element	Support for JPG, PNG, BMP, G	IF	
\subseteq	Text element	Supported		
\subseteq	Line element	Supported		
	†			
\triangle	Shape element	Supported		


\subseteq	Formatted text element	Supported	
	Flash element	Not supported	
\subseteq	Table element	Supported	
\subseteq	Interactive button element	Supported Mouse cursor options not supported Interactive Data filter & sort dialog window not supported	
\subseteq	Web element	Usage of the interactive Address Bar not supported	
	Data connections	Data connections make it possible to show information from external sources inside presentations	
Ý	Data providers	More than 70 PADS4 data providers for retrieval of (realtime) data from external sources and the possibility to change and join the data to fit your purpose	
	Viewer Variables	Usage of Viewer Variables can simplify your presentations and data connections. It also gives the opportunity to centrally manage the content without changing presentations or data providers.	
\square	Property bindings	Apply element properties by using external data sources	
	Rules	Rules will make it possible to interact on certain situations like realtime data and change the behavior of a presentation automatically	
\subseteq	Presentation rules	Supported	
Y	Page rules	Supported	
\subseteq	Element rules	Supported	
	Device Management	Device management which can be performed from a remote location	
	Remote device management	Connection state Device connection state information Automatically send out alerts	
	Web based and Windows	Alerts when network failures occur for this device	

		D 1 .	5.1
		Reboot	Reboot device
		Restart Viewer	Restart PADS4 Viewer
		Shutdown	Not supported
		Wake On Lan	Not supported
		Screenshot	Retrieve screenshots for what is actually displayed
		Logs	Viewer log, synchronization log, system info
		Viewer Settings	Edit Viewer Settings
		Fonts	Install Fonts on device
		Proof of play	Show Proof of play inform- ation
		Blackbox	If help from NDS Support is required, the blackbox contains important information for investigation purposes
	Remarks		
	Colors	Texture and patter	rn colors are not supported
口	Transition effects		rtical blinds not supported d circle and sliced circle not sup-
	Content file integrity	PADS4 Content Lib ing synchronizatio	orary file integrity is checked dur- n using MD5
Ģ	Proof of play	the HTML5 Viewer	cation of max. 50.000 records on during offline period. s hit, the oldest value will be

4. Troubleshooting

Problem	Solution
Block remote control, turn off display, shutdown command and other native com-	Make sure sicp over network is enabled and hosted on port 5000.
When the viewer is starting, the browser is not running full screen.	Check your firmware version, probably an incompatible ver-

	sion of the firmware is installed.
Device fails to connect to the network over Ethernet.	Updating the firm- ware might solve this problem.
The navigation bar is visible on the device.	Updating the firm- ware should solve this problem.
Every time the viewer starts, it asks for the permission to permanently store content on the device.	Check your firmware version, probably an incompatible version of the firmware is installed.



PADS4 Installation Manual

PADS4 Viewer on Philips Multi-Touch series (24BDL4151T)

Contents

- 1. First time use
- 1.1. Configuring the device
- 1.2. Resetting the device
- 2. Installing PADS4 Viewer
- 2.1. Checking device firmware
- 2.2. Updating device firmware
- 2.3. Install PADS4Philips from USB stick
- 2.4. Configuring the device for PADS4Philips

- 2.4.1 Validate Date Time configuration
- 2.4.2. Optional: Enable TeamViewer
- 2.5. Connecting to PADS4 Server
- 2.6. Adjust PADS4 Viewer settings using the options screen
- 2.7. Updating PADS4 Viewer and PADS4Philips app
- 2.8. Accessing Android menu when PADS4 Viewer is running
- 3. Supported features & limitations
- 4. Troubleshooting

1. First time use

During the installation, you will need to configure the PADS4 Server location. Best approach is to complete the installation of the PADS4 Server first, before continuing the configuration of the device.

The minimum PADS4 Server version required for the PADS4Philips app is version PADS4 Foundation 2020.3.

When you turn the device on for the first time, it will open a configuration wizard. Follow the steps and specify the settings, as mentioned below. (If the configuration wizard does not start, then please first factory reset your device, as described in '1.2 resetting the device'.)

1.1. Configuring the device

Step	Description	
01	In the Welcome screen select your preferred language and click start.	
02	On the Security Setting screen, make sure that 'SICP Network Port' is enabled. Optionally you can enable or disable the other settings. Press next to continue.	
03	On the Signage Display Settings screen, press the skip button.	
04	On the Network Setting screen, select your preferred network type, press next and configure this accordingly.	
05	On the Clone Media Files screen, also press the skip button.	
06	Setup Complete press the finish button.	

The device will show the Philips Media Player app.

1.2. Resetting the device

If your device was used before, we recommend that you factory reset your device, so that all storage is freed and no other software interferes with the PADS4 Viewer software.

Step	Description
I() I	Enter the android menu by pressing in sequence the home button and the volume button behind the display.
02	Enter the password, the default password is 1234
03	Open the settings.
04	Select Signage Display -> System Tools -> Factory Reset.
05	Click on Factory Reset and confirm by pressing OK.

The device will factory reset and afterwards you will see the welcome screen, please follow the steps as described in '1.1 configuring the device'.

2. Installing PADS4 Viewer

To install the PADS4 Viewer on the Philips display, you first need to **get in the android menu of this device**. To open the android menu, press in sequence the home button and the volume down button behind the display. Then it will ask for the admin password, **the default password is 1234**.

2.1. Checking device firmware

To run the PADS4 viewer properly on the 24BDL4151T and make sure that all functionality works, you need to have firmware version FB04.04 installed on the 24BDL4151T. Please check using the following steps.

Step	Description			
01	Enter the android menu by pressing home and volume down button in sequence.			
02	Specify the admin password (default: 1234).			
03	Open the settings.			
04	Select about.			
05	The build number should match FB04.4			

2.2. Updating device firmware

To update the firmware please follow the instructions in the document provided by Philips: https://www.drop-

box.com/s/55frshq5063qryt/24BDL4151T%20firmware%20%20FB04.04%20%26%201.010.docx?dl=0

2.3. Install PADS4Philips from USB stick

The PADS4Philips.apk can be found on the PADS4 Server in the apps folder of the PADS4 installation directory. The default PADS4 installation directory is 'C:\Program Files\Net Display Systems\PADS4'.

You can also download the latest version of PADS4Philips from http://go.pads4.com/?fwlink=1006.

If you download the latest version, make sure that you will also place it in the apps directory on the PADS4 Server, because if the server is containing a different version, it will install that version of the PADS4Philips app, once connected to the PADS4 Server.

Step	Description
01	Copy the PADS4Philips.apk on a USB stick.
02	Insert the USB stick into the device.
03	Enter the android menu by pressing home and volume down button in sequence.
04	Specify the admin password (default: 1234).
05	Select Storage -> your USB drive and open the PADS4Philips.apk.
06	Select install and after installation open the app.

2.4. Configuring the device for PADS4Philips

Next we are going to change the device setting to make sure it automatically start the PADS4 Viewer on device startup.

Step	Description			
01	In the PADS4Philips app open Android settings by clicking on System Settings.			
02	Select Signage Display -> Source settings -> Custom app.			
03	Click Select App, then select PADS4Philips and press save.			
04	Enable force restart custom app.			
05	Press 2x back until you reached Signage Display again.			
06	Now select General setting -> Boot on source.			
07	Select input custom app and press back.			
80	Until you reach the PADS4Philips app.			

2.4.1. Validate Date Time configuration

Validate if the date and time are setup correctly on the device, otherwise it is possible that you will get certificate errors or other connection issues.

Step	Description
01	In the PADS4Philips app open Android settings by clicking on System Settings.
02	Go to date & time Menu.

03	Configure the date & time correctly and if the network allows it you can enable auto sync date and time.	
04	Go back to the PADS4Philips app.	

2.4.1. Optional: Enable TeamViewer

If you have a TeamViewer account, you can connect your Philips device to TeamViewer to manage the device remotely.

Step	Description			
01	Enter the android menu by pressing home button and volume down button in sequence.			
02	Specify the admin password (default: 1234).			
03	Select Settings and go to Signage Display -> Misc.			
04	Enable TeamViewer Support, if not already enabled.			
05	Go back to the android menu.			
06	Select Apps and open the Host app. (TeamViewer Host)			
07	Specify your TeamViewer account, click assign device.			
08	Follow the instructions from the email that you will receive from TeamViewer.			
09	Click on assign again.			
10	Go back to the PADS4Philips App.			

2.5. Connecting to PADS4 Server

Now the device is ready to run the PADS4 Viewer and we only need to connect to the PADS4 Server. To do this, you only need to specify the PADS4 Server Address and press the start button. The PADS4 Server Address format looks like this:

col>://<host>:<port>/<hostpath>/

- Protocol: should either be http or https, depending if you are hosting with a valid public signed ssl certificate
- Host: DNS name or ip address of the PADS4 Server
- Port: is optional, if the PADS4 server not using the default ports for http or https, you should specify the port number.
- The configured hostpath in system management, the default value is PADS4.

Example: http://localhost/pads4

Connecting to the PADS4 Server:

Step	Description
01	Specify the correct PADS4 Server Location.

02	Optionally specify a viewer name, if not specified the PADS4 Server will generate one.			
03	Press the start button.			
04	Allow PADS4Philips to have access to the device storage.			
05	Wait until the viewer download is finished, then the viewer will start.			
06	The first time it will ask for the permission to permanently store content on the device, grant this permission.			

Now the viewer should start and connect to the PADS4 Server. After that, you can configure the other settings like screen orientation or block remote control with the PADS4 Agent or in the Viewer Settings.

2.6. Adjust PADS4 Viewer settings using the options screen

You can adjust the PADS4 Viewer settings directly on the display. To enter the options screen on the device itself, hold the left mouse button down or touch the screen for 3 seconds. In the options screen you can also return to the PADS4Philips app by pressing the Launcher Settings button.

2.7. Updating PADS4 Viewer and PADS4Philips app

After the initial installation of the PADS4 Viewer and PADS4Philips app, if you update the PADS4 Server the PADS4 Viewer and PADS4Philips app will automatically update to the version available on the PADS4 Server.

2.8. Accessing Android menu when PADS4 Viewer is running

If you open the Android menu by pressing the home button and volume down button in sequence, when the PADS4 Viewer is running, it will probably restart the device in about 30 seconds. This is because the viewer monitor service detects that the viewer is no longer running and because of this the device will reboot. To access the menu properly, you first need to open the PADS4Philips App as described in '2.6 Adjust PADS4 Viewer settings using the options screen'. Then you can access the android menu without the device rebooting, using the home button and volume down button in sequence.

3. Supported features and limitations 24BDL4151T

Support	Category	Description
	Automatic PADS4 Software updates	After the initial installation of the PADS4 Viewer
		and PADS4Philips app, if you update the PADS4
Ľ		Server the PADS4 Viewer and PADS4Philips app
		will automatically update to the version available

		on the PADS4 Server.			
\square	Offline mode of device	continue to play PADS4 prese planned schedules for 7 days	While offline from the network, the device will still continue to play PADS4 presentations and change planned schedules for 7 days. Scheduled presentations, content and data is		
	Device				
\subseteq	Portrait mode	Supported. Device will adjust matically.	Supported. Device will adjust the rotation auto-		
\subseteq	Block remote control		Option to prevent usage of remote control to		
\subseteq	Transfer protocols	HTTP, HTTPS			
	Turn off display		Turn off display when no presentation scheduled. Device still active but backlight is turned off for less power consumption		
\subseteq	Cluster Viewer	This device is able to be used	This device is able to be used as Cluster Viewer		
M	Video element	Maximum number of videos	4 videos on each page. Check out the supplier documentation for more info		
		Video rotation	Not supported		
		Seamless videos	In landscape mode only		
		Reflection, skew, flip	Not supported		
		Streaming	HTTP		
\triangle	Image element	Support for JPG, PNG, BMP, G	Support for JPG, PNG, BMP, GIF		
\subseteq	Text element	Supported	Supported		
	Line element	Supported	Supported		
\square	Shape element	Supported	Supported		
\subseteq	Scrolling text element	Supported	Supported		
	Formatted text element	Supported			

	Flash element	Not supported		
\subseteq	Table element	Supported		
\subseteq	Interactive button element	Supported Mouse cursor options not supported Interactive Data filter & sort dialog window not supported		
\subseteq	Web element	Usage of the interactive Address Bar not supported		
	Data connections	Data connections make it possible to show information from external sources inside presentations		
\subseteq	Data providers	More than 70 PADS4 data providers for retrieval of (realtime) data from external sources and the possibility to change and join the data to fit your purpose		
\subseteq	Viewer Variables	Usage of Viewer Variables can simplify your presentations and data connections. It also gives the opportunity to centrally manage the content without changing presentations or data providers.		
\subseteq	Property bindings	Apply element properties by using external data sources		
	Rules	Rules will make it possible to interact on certain situations like realtime data and change the behavior of a presentation automatically		
\subseteq	Presentation rules	Supported		
\subseteq	Page rules	Supported		
\subseteq	Element rules	Supported		
	Device Management	Device management which can be performed from a remote location		
 ✓	Remote device management Web based and Windows	Connection state Device connection state information Automatically send out alerts Alerts when network failures occur for this device Reboot Reboot device		

		5	D DADCANE
		Restart Viewer	Restart PADS4 Viewer
			Not supported
			The default 'Switch on state' option on the 24BDL4151T is
		Shutdown	Force On. Therefore, when
		Silataowii	the device is turned off, a
			couple of seconds later, it
			will turn on again.
		Wake On Lan	Not supported
		Screenshot	Retrieve screenshots for what is actually displayed
		Logs	Viewer log, synchronization log, system info
		Viewer Settings	Edit Viewer Settings
		Fonts	Install Fonts on device
		Proof of play	Show Proof of play information
			If help from NDS Support is
		Blackbox	required, the blackbox con-
			tains important information
			for investigation purposes
	Remarks		
-	Colors	-	n colors are not supported
		Horizontal and vertical blinds not supported	
7	Transition effects	Splitters, increased circle and sliced circle not supported	
	Content file integrity	PADS4 Content Library file integrity is checked dur-	
	3,	ing synchronization using MD5	
		Local storage limitation of max. 50.000 records on	
Ļ	Proof of play	the HTML5 Viewer during offline period. When the 50.000 is hit, the oldest value will be	
		removed first.	
		removed mst.	

4. Troubleshooting

Problem	Solution
Block remote control, turn off display, shutdown command and other namand on Philips device are not working.	tive com- Make sure sicp over network is enabled and hosted on port

	5000.
When the viewer is starting, the browser is not running full screen.	Check your firmware version, probably an incompatible version of the firmware is installed.
Device fails to connect to the network over Ethernet.	Updating the firm- ware might solve this problem.
The navigation bar is visible on the device.	Updating the firm- ware should solve this problem.
Every time the viewer starts, it asks for the permission to permanently store content on the device.	Check your firmware version, probably an incompatible version of the firmware is installed.



Certified Viewer devices

This section shows the certified Viewer devices from ProDVX.



Configuring ProDVX DSK/DSQ Series

This page explains how to configure the SOC player to run the PADS4 HTML5 Viewer.

When you turn the device on for the first time it will automatically show the configuration wizard. Follow the steps and specify settings.

Configuring the device for PADS4 HTML5 Launcher

By default, the network settings are disabled on the device. Also because it is a touch device you want to disable the system status bar, so you cannot close the viewer app. To configure these settings.

- Open the settings on Android
- Make sure that either Wi fi and/or Ethernet is enabled
- To disable the status bar, select Display and check the hide status bar option
- To disable the physical button on the device, select Physical Button Manager and uncheck the Enable Physical Buttons option

Installation of the PADS4 HTML5 Viewer Android Launcher

PADS4 requires an Android Launcher to be installed.

This launcher can be downloaded from http://go.pads4.com/?fwlink=1004.

Step Step Description

- 1 Store the PADS HTML5 Launcher apk on a USB stick
- 2 Insert the USB stick into the device
- 3 On the device select the Apk Installer app
- 4 Select install and browse the USB for the apk
- The message "Do you want to install this application" is displayed. Press the next button until the button "install" appears
- 6 Press the install button
- 7 After installation press the open button
- The PADS4 HTML5 Launcher app will be started. Enter the location of the PADS4 Server, by specifying a domain name, IP address or pc name of the server where the PADS4 Server is running.
- (Optional) If you changed the default server html server settings of the PADS server, open the advanced settings and specify the correct port number and host/root path.
- Press start, the first time the app will prompt to select your home app. Select PADS4 HTML5 Launcher and select always, if you don't it will prompt the message again.

If a problem occurs open the viewer settings and have a look at the log which may contain important (error) information.

The first time the device is configured, a valid server connection is required to download the PADS4 HTML5 Viewer software.

Upgrading PADS4 Launcher from USB stick

When a new PADS4 Launcher is available follow the next steps to upgrade.

Step Step Description

- 1 Store the new PADS HTML5 Launcher apk on a USB stick
- 2 Insert the USB stick into the device
- 3 Open the PADS4 Viewer settings
- 4 Select Launcher settings from the menu
- 5 Click on the folder icon in the right bottom corner
- Navigate to the newer apk on the usb stick, by selecting the storage folder and then the usb_storage folder
- 7 Select the apk
- 8 The message "Do you want to install an update to this existing application" is displayed.
- 9 Press the install button. The PADS4 HTML5 Launcher should automatically start when installed.

Adjust PADS4 Viewer options

PADS4 Viewer options can be changed directly on the device using a mouse.

Click on the left button of the mouse and hold this down until the menu appears. It is also possible to change options remotely using PADS4 CTRL Center or PADS4 Agent.

- Open Viewer menu
- Click on the Launcher Settings button
- Click on the gear icon in right bottom corner
- The Android settings open
 If the Hide Status Bar option is turned on, the only way to leave the Android setting is to restart
 the device, by disconnecting the power.

To perform a factory reset of the device follow the next steps:

Step Description

- Open the settings on Android
- Select Backup & Reset
- Select Factory data reset
- Select Reset tablet
- Select Erase everything

Support	Category	Description	
\subseteq	Automatic PADS4 Software updates	Supported. HTML5 Viewer is automatically updated.	
☑	Offline mode of device	While offline from the network, the device will still continue to play PADS4 presentations and change planned schedules for 7 days. Scheduled presentations, content and data is cached local.	
	Device		
\subseteq	Portrait mode	Supported. Device will adjust the rotation automatically.	
Ň	Block remote control	Option to prevent usage of remote control to operate the screen	
\subseteq	Transfer protocols	HTTP, HTTPS	
	Turn off display	Not supported	
\subseteq	Cluster Viewer	This device is able to be used as Cluster Viewer	
Ĭ	LED Light bar	Supported. RG color spectrum only. Blue is not supported The alpha color defines the brightness of the color. The RGB values specify the color. Alpha value of 0: the light is off. Alpha value of 255: the light is at its brightest value.	
	Elements		
\square	Video element	2 HD videos (max- Maximum number of videos imum 60fps) Check out the sup-	

		Video rotation	plier doc- umentation for more info Not supported	
		Seamless videos	Not supported	
		Reflection, skew, flip	Not supported	
		Streaming	НТТР	
\subseteq	Image element	Support for JPG, PNG, BM	P, GIF	
\subseteq	Text element	Supported		
\subseteq	Line element	Supported		
M	Shape element	Supported		
\subseteq	Scrolling text element	Supported		
\subseteq	Formatted text element	Supported		
	Flash element	Not supported		
\subseteq	Table element	Supported		
\subseteq	Interactive button element	Not Supported		
\square	Web element	Usage of the interactive A ported	ddress Bar not sup-	
	Data connections	Data connections make it ation from external source		
\square	Data providers	of (realtime) data from ex	More than 70 PADS4 data providers for retrieval of (realtime) data from external sources and the possibility to change and join the data to fit your purpose	
\subseteq	Viewer Variables	Usage of Viewer Variables presentations and data content without chang data providers.	onnections. ity to centrally manage	
\square	Property bindings	Apply element properties sources	by using external data	
	Rules	Rules will make it possible situations like realtime dat vior of a presentation auto	ta and change the beha-	

\subseteq	Presentation rules	Supported	
\subseteq	Page rules	Supported	
\subseteq	Element rules	Supported	
	Device Management	Device management from a remote loca	nt which can be performed ation
		Connection state	Device connection state information
		Alerts	Automatically send out alerts when network failures occur for this device
		Reboot	Not supported
		Restart Viewer	Restart PADS4 Viewer
		Shutdown	Not supported
		Wake On Lan	Not supported
\subseteq	Remote device management	Screenshot	Retrieve screenshots for what is actually displayed
	Web based and Windows	Logs	Viewer log, synchronization log, system info
		Viewer Settings	Edit Viewer Settings
		Fonts	Install Fonts on device
		Proof of play	Show Proof of play information
		Blackbox	If help from NDS Support is required, the blackbox con- tains important information for investigation purposes
	Remarks		
4	Colors	Texture and pattern colors are not supported	
口	Transition effects	Horizontal and vertical blinds not supported Splitters, increased circle and sliced circle not sup ported	
\Box	Content file integrity	PADS4 Content Libi	rary file integrity is checked dur- n using MD5
\Box	Proof of play	the HTML5 Viewer	ation of max. 50.000 records on during offline period. hit, the oldest value will be

removed first.



Configuring ProDVX DSK/DSQ Series

This page explains how to configure the SOC player to run the PADS4 HTML5 Viewer.

When you turn the device on for the first time it will automatically show the configuration wizard. Follow the steps and specify settings.

Configuring the device for PADS4 HTML5 Launcher

By default, the network settings are disabled on the device. Also because it is a touch device you want to disable the system status bar, so you cannot close the viewer app. To configure these settings.

- Open the settings on Android
- Make sure that either Wi fi and/or Ethernet is enabled
- To disable the status bar, select Display and check the hide status bar option
- To disable the physical button on the device, select Physical Button Manager and uncheck the Enable Physical Buttons option

Installation of the PADS4 HTML5 Viewer Android Launcher

PADS4 requires an Android Launcher to be installed.

This launcher can be downloaded from http://go.pads4.com/?fwlink=1004.

Step Step Description

- 1 Store the PADS HTML5 Launcher apk on a USB stick
- 2 Insert the USB stick into the device
- 3 On the device select the Apk Installer app
- 4 Select install and browse the USB for the apk
- The message "Do you want to install this application" is displayed. Press the next button until the button "install" appears
- 6 Press the install button
- 7 After installation press the open button
- The PADS4 HTML5 Launcher app will be started. Enter the location of the PADS4 Server, by specifying a domain name, IP address or pc name of the server where the PADS4 Server is running.
- (Optional) If you changed the default server html server settings of the PADS server, open the advanced settings and specify the correct port number and host/root path.
- Press start, the first time the app will prompt to select your home app. Select PADS4 HTML5 Launcher and select always, if you don't it will prompt the message again.

If a problem occurs open the viewer settings and have a look at the log which may contain important (error) information.

The first time the device is configured, a valid server connection is required to download the PADS4 HTML5 Viewer software.

Upgrading PADS4 Launcher from USB stick

When a new PADS4 Launcher is available follow the next steps to upgrade.

Step Step Description

- 1 Store the new PADS HTML5 Launcher apk on a USB stick
- 2 Insert the USB stick into the device
- 3 Open the PADS4 Viewer settings
- 4 Select Launcher settings from the menu
- 5 Click on the folder icon in the right bottom corner
- Navigate to the newer apk on the usb stick, by selecting the storage folder and then the usb_storage folder
- 7 Select the apk
- 8 The message "Do you want to install an update to this existing application" is displayed.
- 9 Press the install button. The PADS4 HTML5 Launcher should automatically start when installed.

Adjust PADS4 Viewer options

PADS4 Viewer options can be changed directly on the device using a mouse.

Click on the left button of the mouse and hold this down until the menu appears. It is also possible to change options remotely using PADS4 CTRL Center or PADS4 Agent.

- Open Viewer menu
- Click on the Launcher Settings button
- Click on the gear icon in right bottom corner
- The Android settings open
 If the Hide Status Bar option is turned on, the only way to leave the Android setting is to restart
 the device, by disconnecting the power.

To perform a factory reset of the device follow the next steps:

Step Description

- Open the settings on Android
- Select Backup & Reset
- Select Factory data reset
- Select Reset tablet
- Select Erase everything

Support	Category	Description	
\subseteq	Automatic PADS4 Software updates	Supported. HTML5 Viewer is automatically updated.	
☑	Offline mode of device	While offline from the network, the device will still continue to play PADS4 presentations and change planned schedules for 7 days. Scheduled presentations, content and data is cached local.	
	Device		
\subseteq	Portrait mode	Supported. Device will adjust the rotation automatically.	
Ň	Block remote control	Option to prevent usage of remote control to operate the screen	
\subseteq	Transfer protocols	HTTP, HTTPS	
	Turn off display	Not supported	
\subseteq	Cluster Viewer	This device is able to be used as Cluster Viewer	
Ĭ	LED Light bar	Supported. RG color spectrum only. Blue is not supported The alpha color defines the brightness of the color. The RGB values specify the color. Alpha value of 0: the light is off. Alpha value of 255: the light is at its brightest value.	
	Elements		
\square	Video element	2 HD videos (max- Maximum number of videos imum 60fps) Check out the sup-	

		Video rotation	plier doc- umentation for more info Not supported	
		Seamless videos	Not supported	
		Reflection, skew, flip	Not supported	
		Streaming	НТТР	
\subseteq	Image element	Support for JPG, PNG, BM	P, GIF	
\subseteq	Text element	Supported		
\subseteq	Line element	Supported		
M	Shape element	Supported		
\subseteq	Scrolling text element	Supported		
\subseteq	Formatted text element	Supported		
	Flash element	Not supported		
\subseteq	Table element	Supported		
\subseteq	Interactive button element	Not Supported		
\square	Web element	Usage of the interactive A ported	ddress Bar not sup-	
	Data connections	Data connections make it ation from external source		
\square	Data providers	of (realtime) data from ex	More than 70 PADS4 data providers for retrieval of (realtime) data from external sources and the possibility to change and join the data to fit your purpose	
\subseteq	Viewer Variables	Usage of Viewer Variables presentations and data content without chang data providers.	onnections. ity to centrally manage	
\square	Property bindings	Apply element properties sources	by using external data	
	Rules	Rules will make it possible situations like realtime dat vior of a presentation auto	ta and change the beha-	

\subseteq	Presentation rules	Supported	
\subseteq	Page rules	Supported	
\subseteq	Element rules	Supported	
	Device Management	Device management from a remote loca	nt which can be performed ation
		Connection state	Device connection state information
		Alerts	Automatically send out alerts when network failures occur for this device
		Reboot	Not supported
		Restart Viewer	Restart PADS4 Viewer
		Shutdown	Not supported
		Wake On Lan	Not supported
\subseteq	Remote device management	Screenshot	Retrieve screenshots for what is actually displayed
	Web based and Windows	Logs	Viewer log, synchronization log, system info
		Viewer Settings	Edit Viewer Settings
		Fonts	Install Fonts on device
		Proof of play	Show Proof of play information
		Blackbox	If help from NDS Support is required, the blackbox con- tains important information for investigation purposes
	Remarks		
4	Colors	Texture and pattern colors are not supported	
口	Transition effects	Horizontal and vertical blinds not supported Splitters, increased circle and sliced circle not sup ported	
\Box	Content file integrity	PADS4 Content Libi	rary file integrity is checked dur- n using MD5
\Box	Proof of play	the HTML5 Viewer	ation of max. 50.000 records on during offline period. hit, the oldest value will be

removed first.



Configuring ProDVX ABPC-543 Series

This page explains how to configure the SOC player to run the PADS4 HTML5 Viewer.

When you turn the device on for the first time it will automatically show the configuration wizard. Follow the steps and specify settings.

Configuring the device for PADS4 HTML5 Launcher

By default, the network settings are disabled on the device. Also because it is a touch device you want to disable the system status bar, so you cannot close the viewer app. To configure these settings.

- Open the settings on Android
- Make sure that either Wi fi and/or Ethernet is enabled
- To disable the status bar, select Display and check the hide status bar option
- To disable the physical button on the device, select Physical Button Manager and uncheck the Enable Physical Buttons option

Installation of the PADS4 HTML5 Viewer Android Launcher

PADS4 requires an Android Launcher to be installed.

This launcher can be downloaded from http://go.pads4.com/?fwlink=1004.

Step Step Description

- 1 Store the PADS HTML5 Launcher apk on a USB stick
- 2 Insert the USB stick into the device
- 3 On the device select the Apk Installer app
- 4 Select install and browse the USB for the apk
- The message "Do you want to install this application" is displayed. Press the next button until the button "install" appears
- 6 Press the install button
- 7 After installation press the open button
- The PADS4 HTML5 Launcher app will be started. Enter the location of the PADS4 Server, by specifying a domain name, IP address or pc name of the server where the PADS4 Server is running.
- (Optional) If you changed the default server html server settings of the PADS server, open the advanced settings and specify the correct port number and host/root path.
- Press start, the first time the app will prompt to select your home app. Select PADS4 HTML5 Launcher and select always, if you don't it will prompt the message again.

If a problem occurs open the viewer settings and have a look at the log which may contain important (error) information.

The first time the device is configured, a valid server connection is required to download the PADS4 HTML5 Viewer software.

Upgrading PADS4 Launcher from USB stick

When a new PADS4 Launcher is available follow the next steps to upgrade.

Step Step Description

- 1 Store the new PADS HTML5 Launcher apk on a USB stick
- 2 Insert the USB stick into the device
- 3 Open the PADS4 Viewer settings
- 4 Select Launcher settings from the menu
- 5 Click on the folder icon in the right bottom corner
- Navigate to the newer apk on the usb stick, by selecting the storage folder and then the usb_storage folder
- 7 Select the apk
- 8 The message "Do you want to install an update to this existing application" is displayed.
- 9 Press the install button. The PADS4 HTML5 Launcher should automatically start when installed.

Adjust PADS4 Viewer options

PADS4 Viewer options can be changed directly on the device using a mouse.

Click on the left button of the mouse and hold this down until the menu appears. It is also possible to change options remotely using PADS4 CTRL Center or PADS4 Agent.

- Open Viewer menu
- Click on the Launcher Settings button
- Click on the gear icon in right bottom corner
- The Android settings open
 If the Hide Status Bar option is turned on, the only way to leave the Android setting is to restart
 the device, by disconnecting the power.

To perform a factory reset of the device follow the next steps:

Step Description

- Open the settings on Android
- Select Backup & Reset
- Select Factory data reset
- Select Reset tablet
- Select Erase everything

Required firmware

PADS4 requires Android 5.1.1 and kernel 3.10 Build LMY49F

Support	Category	Description		
	Automotic DADC4 Coftugue un dates	Supported.		
¥	Automatic PADS4 Software updates	HTML5 Viewer is automaticall	y updated.	
		While offline from the network	k, the device will still	
		continue to play PADS4 prese	ntations and change	
\leq	Offline mode of device	planned schedules for 7 days.		
		Scheduled presentations, con	tent and data is	
		cached local.		
	Device			
M	Portrait mode	Supported. Device will adjust	the rotation auto-	
		matically.		
N.	Block remote control	Option to prevent usage of re	emote control to	
Distribute control		operate the screen		
\leq	Transfer protocols	HTTP, HTTPS		
	Turn off display	Not supported		
\subseteq	Cluster Viewer	This device is able to be used as Cluster Viewer		
	-1			
	Elements			
\square	Video element	Maximum number of videos	4 videos Check out the sup- plier doc- umentation for more info	
		Video rotation	Not supported	

		Seamless videos	Not supported
			Not supported Not supported
		•	НТТР
		-	
	Image element	Support for JPG, PNG, BMP, GIF	
\leq	Text element	Supported	
Y	Line element	Supported	
Ŋ	Shape element	Supported	
\leq	Scrolling text element	Supported	
\subseteq	Formatted text element	Supported	
	Flash element	Not supported	
\subseteq	Table element	Supported	
N	Interactive button element	Not Supported	
\subseteq	Web element	Usage of the interactive Addres ported	s Bar not sup-
	Data connections	Data connections make it possib ation from external sources insi	
M	Data providers	More than 70 PADS4 data providers for retrieval of (realtime) data from external sources and the possibility to change and join the data to fit your purpose	
Ý	Viewer Variables	Usage of Viewer Variables can simplify your presentations and data connections. It also gives the opportunity to centrally manage the content without changing presentations or data providers.	
\square	Property bindings	Apply element properties by using external data sources	
	Rules	Rules will make it possible to int situations like realtime data and vior of a presentation automatic	change the beha-
\subseteq	Presentation rules	Supported	
\subseteq	Page rules	Supported	

\subseteq	Element rules	Supported	
	Device Management	Device manageme	ent which can be performed ation
		Connection state	Device connection state information
		Alerts	Automatically send out alerts when network failures occur for this device
		Reboot	Not supported
		Restart Viewer	Restart PADS4 Viewer
		Shutdown	Not supported
		Wake On Lan	Not supported
Remote device management Web based and Windows	Screenshot	Retrieve screenshots for what is actually displayed	
	Logs	Viewer log, synchronization log, system info	
		Viewer Settings	Edit Viewer Settings
		Fonts	Install Fonts on device
		Proof of play	Show Proof of play information
		Blackbox	If help from NDS Support is required, the blackbox contains important information for investigation purposes
	Remarks		
	Colors	Texture and patter	n colors are not supported
口	Transition effects	Horizontal and vertical blinds not supported Splitters, increased circle and sliced circle not supported	
	Content file integrity	PADS4 Content Lib	rary file integrity is checked dur- n using MD5
Ç	Proof of play	Local storage limitation of max. 50.000 records on the HTML5 Viewer during offline period. When the 50.000 is hit, the oldest value will be removed first.	



Configuring ProDVX ABPC-545 Series

This page explains how to configure the SOC player to run the PADS4 HTML5 Viewer.

When you turn the device on for the first time it will automatically show the configuration wizard. Follow the steps and specify settings.

Configuring the device for PADS4 HTML5 Launcher

By default, the network settings are disabled on the device. Also because it is a touch device you want to disable the system status bar, so you cannot close the viewer app. To configure these settings.

- Open the settings on Android
- Make sure that either Wi fi and/or Ethernet is enabled
- To disable the status bar, select Display and check the hide status bar option
- To disable the physical button on the device, select Physical Button Manager and uncheck the Enable Physical Buttons option

Installation of the PADS4 HTML5 Viewer Android Launcher

PADS4 requires an PADS4 Android Launcher to be installed.

This launcher can be downloaded from http://go.pads4.com/?fwlink=1004.

Step	Description
01	Start device
02	In the Google search bar on top type in the URL: http://go.pads4.com/?fwlink=1004
03	Open with lightning
04	Select download
05	Allow lightning to access photo media and files. Select Allow.
06	Do you want to download this file (select Yes)
07	Click with the left mousebutton on the datetime in the left top corner above the browser tab (noti-
	fications)
80	Click on NDS.Droid launcher
09	Click on Settings
10	Enable allow from this source
11	Specify IP Address and portnumber of the PADS4 server
12	Select PADS4 HTML5 Launcher as home app and select Always option
13	Click on Start
14	Click Allow to modify system settings.

15	Press the right mousebutton to return to the settings
16	Click again on Start
17	Click on Allow access to photos, media and file on your device
18	the Viewer will start and connect to the server

If a problem occurs open the viewer settings and have a look at the log which may contain important (error) information.

The first time the device is configured, a valid server connection is required to download the PADS4 HTML5 Viewer software.

Adjust PADS4 Viewer options

PADS4 Viewer options can be changed directly on the device using a mouse.

Click on the left button of the mouse and hold this down until the menu appears. It is also possible to change options remotely using PADS4 CTRL Center or PADS4 Agent.

Open launcher menu from PADS4 HTML5 Viewer

- Open Viewer menu
- Click on the Launcher Settings button
- Click on the gear icon in right bottom corner
- The Android settings open
 If the Hide Status Bar option is turned on, the only way to leave the Android setting is to restart
 the device, by disconnecting the power.

To perform a factory reset of the device follow the next steps:

Step Description

- Open the settings on Android
- Select Backup & Reset
- Select Factory data reset
- Select Reset tablet
- Select Erase everything

Required firmware

PADS4 requires version Kernel 4.4.167 Build V-C02001120200598

Support	Category	Description		
\square	Automatic PADS4 Software updates	Supported. HTML5 Viewer is automatically updated.		
<u> </u>	Offline mode of device	While offline from the network, the device will still continue to play PADS4 presentations and change planned schedules for 7 days. Scheduled presentations, content and data is cached local.		
	Device			
\subseteq	Portrait mode	Supported. Device will adjust the rotation automatically.		
\subseteq	Block remote control	Option to prevent usage of remote control to operate the screen		
\subseteq	Transfer protocols	HTTP, HTTPS		
	Turn off display	Not supported		
\square	Cluster Viewer	This device is able to be used	as Cluster Viewer	
	Elements			
	Video olomont	Maximum number of videos	4 videos Check out the sup- plier doc- umentation for more info	
Ľ	Video element	Video rotation	Not supported	
		Seamless videos	Not supported	
		Reflection, skew, flip	Not supported	
		Streaming	HTTP	
\square	lmage element	Support for JPG, PNG, BMP, GIF		
\subseteq	Text element	Supported		
\subseteq	Line element	Supported		
\subseteq	Shape element	Supported		
\subseteq	Scrolling text element	Supported		

\subseteq	Formatted text element	Supported	
	Flash element	Not supported	
\subseteq	Table element	Supported	
\subseteq	Interactive button element	Not Supported	
\subseteq	Web element	Usage of the interactive Address Bar not supported	
	Data connections	Data connections make it possible to show information from external sources inside presentations	
区	Data providers	More than 70 PADS4 data providers for retrieval of (realtime) data from external sources and the possibility to change and join the data to fit your purpose	
\subseteq	Viewer Variables	Usage of Viewer Variables can simplify your presentations and data connections. It also gives the opportunity to centrally manage the content without changing presentations or data providers.	
\subseteq	Property bindings	Apply element properties by using external data sources	
	Rules	Rules will make it possible to interact on certain situations like realtime data and change the behavior of a presentation automatically	
\subseteq	Presentation rules	Supported	
\subseteq	Page rules	Supported	
	Element rules	Supported	
	Device Management	Device management which can be performed from a remote location	
	Remote device management	Connection state	Device connection state information Automatically send out alerts
\subseteq	Web based and Windows	Alerts	when network failures occur for this device
		Reboot Restart Viewer	Not supported Restart PADS4 Viewer

		Chutdown	Notering
		Shutdown	Not supported
		Wake On Lan	Not supported
		Screenshot	Retrieve screenshots for what is actually displayed
		Logs	Viewer log, synchronization log, system info
		Viewer Settings	Edit Viewer Settings
		Fonts	Install Fonts on device
		Proof of play	Show Proof of play information
		Blackbox	If help from NDS Support is required, the blackbox contains important information for investigation purposes
	Remarks		
L	Colors	Texture and patter	n colors are not supported
Ģ	Transition effects	Horizontal and vertical blinds not supported Splitters, increased circle and sliced circle not supported	
	Content file integrity	PADS4 Content Library file integrity is checked during synchronization using MD5	
口	Proof of play	Local storage limitation of max. 50.000 records on the HTML5 Viewer during offline period. When the 50.000 is hit, the oldest value will be removed first.	



Configuring ProDVX APPC-10SLB Series

This page explains how to configure the SOC player to run the PADS4 HTML5 Viewer.

When you turn the device on for the first time it will automatically show the configuration wizard. Follow the steps and specify settings.

Configuring the device for PADS4 HTML5 Launcher

By default, the network settings are disabled on the device. Also because it is a touch device you want to disable the system status bar, so you cannot close the viewer app. To configure these settings.

- Open the settings on Android
- Make sure that either Wi fi and/or Ethernet is enabled
- To disable the status bar, select Display and check the hide status bar option
- To disable the physical button on the device, select Physical Button Manager and uncheck the Enable Physical Buttons option

Installation of the PADS4 HTML5 Viewer Android Launcher

PADS4 requires an Android Launcher to be installed.

This launcher can be downloaded from http://go.pads4.com/?fwlink=1004.

Step Step Description

- 1 Store the PADS HTML5 Launcher apk on a USB stick
- 2 Insert the USB stick into the device
- 3 On the device select the Apk Installer app
- 4 Select install and browse the USB for the apk
- The message "Do you want to install this application" is displayed. Press the next button until the button "install" appears
- 6 Press the install button
- 7 After installation press the open button
- The PADS4 HTML5 Launcher app will be started. Enter the location of the PADS4 Server, by specifying a domain name, IP address or pc name of the server where the PADS4 Server is running.
- (Optional) If you changed the default server html server settings of the PADS server, open the advanced settings and specify the correct port number and host/root path.
- Press start, the first time the app will prompt to select your home app. Select PADS4 HTML5 Launcher and select always, if you don't it will prompt the message again.

If a problem occurs open the viewer settings and have a look at the log which may contain important (error) information.

The first time the device is configured, a valid server connection is required to download the PADS4 HTML5 Viewer software.

Upgrading PADS4 Launcher from USB stick

When a new PADS4 Launcher is available follow the next steps to upgrade.

Step Step Description

- 1 Store the new PADS HTML5 Launcher apk on a USB stick
- 2 Insert the USB stick into the device
- 3 Open the PADS4 Viewer settings
- 4 Select Launcher settings from the menu
- 5 Click on the folder icon in the right bottom corner
- Navigate to the newer apk on the usb stick, by selecting the storage folder and then the usb storage folder
- 7 Select the apk
- 8 The message "Do you want to install an update to this existing application" is displayed.
- 9 Press the install button. The PADS4 HTML5 Launcher should automatically start when installed.

Adjust PADS4 Viewer options

PADS4 Viewer options can be changed directly on the device using a mouse.

Click on the left button of the mouse and hold this down until the menu appears. It is also possible to change options remotely using PADS4 CTRL Center or PADS4 Agent.

- Open Viewer menu
- Click on the Launcher Settings button
- Click on the gear icon in right bottom corner
- The Android settings open
 If the Hide Status Bar option is turned on, the only way to leave the Android setting is to restart
 the device, by disconnecting the power.

To perform a factory reset of the device follow the next steps:

Step Description

- Open the settings on Android
- Select Backup & Reset
- Select Factory data reset
- Select Reset tablet
- Select Erase everything


Required firmware

PADS4 requires version kernel 3.10.0 Build MXC89K

Support	Category	Description
	Automatic PADS4 Software updates	Supported.
Ľ		HTML5 Viewer is automatically updated.
		While offline from the network, the device will still
		continue to play PADS4 presentations and change
\triangle	Offline mode of device	planned schedules for 7 days.
		Scheduled presentations, content and data is
		cached local.
	Device	
	Portrait mode	Supported. Device will adjust the rotation auto-
	Torumode	matically.
	Block remote control	Option to prevent usage of remote control to
	Block remote control	operate the screen
\subseteq	Transfer protocols	HTTP, HTTPS
	Turn off display	Not supported
\subseteq	Cluster Viewer	This device is able to be used as Cluster Viewer
		Supported. Full color spectrum.
	LED light bar	The alpha color defines the brightness of the
		color.
Ľ		The RGB values specify the color.
		Alpha value of 0: the light is off. Alpha value of
		255: the light is at its brightest value.

	Elements			
		Maximum number of videos	4 videos Check out the supplier documentation for more info	
\triangle	Video element	Video rotation	Not supported	
		Seamless videos	Not supported	
		Reflection, skew, flip	Not supported	
		Streaming	HTTP	
\subseteq	Image element	Support for JPG, PNG, BMP, G	ilF	
\subseteq	Text element	Supported		
\subseteq	Line element	Supported		
\subseteq	Shape element	Supported		
\subseteq	Scrolling text element	Supported		
\subseteq	Formatted text element	Supported		
	Flash element	Not supported		
\subseteq	Table element	Supported		
	Interactive button element	Not Supported		
\square	Web element	Usage of the interactive Address Bar not supported		
	Data connections	Data connections make it possible to show information from external sources inside presentations		
\subseteq	Data providers	More than 70 PADS4 data providers for retrieval of (realtime) data from external sources and the possibility to change and join the data to fit your purpose		
\subseteq	Viewer Variables	Usage of Viewer Variables can simplify your presentations and data connections. It also gives the opportunity to centrally manage the content without changing presentations or data providers.		
	Property bindings	Apply element properties by using external data sources		

	Rules	situations like real	Rules will make it possible to interact on certain situations like realtime data and change the behavior of a presentation automatically		
\subseteq	Presentation rules	Supported	Supported		
\subseteq	Page rules	Supported	Supported		
\subseteq	Element rules	Supported	Supported		
	Device Management		Device management which can be performed from a remote location		
		Connection state	Device connection state information		
	Remote device management Web based and Windows	Alerts	Automatically send out alerts when network failures occur for this device		
		Reboot	Not supported		
		Restart Viewer	Restart PADS4 Viewer		
		Shutdown	Not supported		
		Wake On Lan	Not supported		
M		Screenshot	Retrieve screenshots for what is actually displayed		
		Logs	Viewer log, synchronization log, system info		
		Viewer Settings	Edit Viewer Settings		
		Fonts	Install Fonts on device		
		Proof of play	Show Proof of play information		
		Blackbox	If help from NDS Support is required, the blackbox con- tains important information for investigation purposes		
	Remarks				
		Tanking			
7	Colors	<u> </u>	rn colors are not supported		
\Box	Transition effects		Horizontal and vertical blinds not supported Splitters, increased circle and sliced circle not supported		
	Content file integrity	PADS4 Content Library file integrity is checked dur- ing synchronization using MD5			





Certified Viewer devices

This section shows the certified Viewer devices from Qbic.



Configuring Qbic BXP-321

This page explains how to configure the SOC player to run the PADS4 HTML5 Viewer.

When you turn the device on for the first time it will open a configuration wizard. Follow the steps and specify the settings, as mentioned below.

Installation of the PADS4 HTML5 Viewer Android Launcher

PADS4 requires an Android Launcher to be installed.

This launcher can be downloaded from http://go.pads4.com/?fwlink=1004.

Step Step Description

- 1 Click on settings
- 2 Click on player settings
- 3 Go to Android system section and enable Switch to Android native mode
- 4 Go to Android apps
- Run the internet browser app (for example Lightning or Browser) and type in the URL: http://go.pads4.com/?fwlink=1004
- 6 Click on download
- 7 Click on allow
- 8 Wait about 1 minute (loading screen will not disappear when finished downloading)
- 9 Go to Android apps and click on files > Downloads
- 10 Double click on the NDS Android HTML5 Launcher
- 11 Allow unknown apps to be installed if prompted click on settings > Allow from this source
- 12 Click on the back arrow and then click on install in the lower right corner
- 13 After installing click on open in the lower right corner
- 14 Type in the location of the PADS4 Server
- 15 Click on start and select the PADS4 HTML5 Viewer as Home app and select 'Always'
- 16 Click on Start again
- 17 Allow to modify system settings
- 18 Click on the back arrow
- 19 Click on Allow to access media files
- 20 You can now start the HTML5 Viewer

When finished the launcher will download the PADS4 HTML5 Viewer software and start. At the left bottom location a connection indicator icon will appear. It will turn green if a valid connection is made to the Server.

If a problem occurs open the viewer settings and have a look at the log which may contain important (error) information.

The first time the device is configured, a valid server connection is required to download the PADS4 HTML5 Viewer software.

Upgrading PADS4 Launcher from USB stick

When a new PADS4 Launcher is available follow the next steps to upgrade.

Step Step Description

- 1 Select launcher settings
- 2 Click on the folder icon in the right bottom corner
- 3 Click on Open Link
- 4 Click on the internet browser app (for example Lightning or Browser)
- 5 Select Just once
- 6 Click on download
- 7 Wait about 1 minute (loading screen will not disappear when finished downloading)
- 8 Go to Android apps and click on Files > Downloads
- 9 Double click on the NDS Android HTML5 Launcher
- The PADS4 HTML5 Viewer forces itself to the foreground so you need to minimize the app with the square in the standard Android menu in the bottom
- It is a little tricky to do this. Best is the drag down the upper Android menu below by holding the left mouse button and then quickly click on the Square
- 12 Allow unknown apps to be installed if prompted click on settings > Allow from this source
- 13 Click on the back arrow and then click on install in the lower right corner
- 14 After installing click on Open in the lower right corner

Adjust PADS4 Viewer options

PADS4 Viewer options can be changed directly on the device using a mouse.

Click on the left button of the mouse and hold this down until the menu appears. It is also possible to change options remotely using PADS4 CTRL Center or PADS4 Agent.

- Open Viewer menu
- Click on the Launcher Settings button
- Click on the gear icon in right bottom corner

• The Android settings open
If the Hide Status Bar option is turned on, the only way to leave the Android setting is to restart
the device, by disconnecting the power.

Disable Android navigation bar

Optionally you can disable the navigation bar of the device, it can be used to change the volume on the device. To disable it, follow the next steps:

- Open the Viewer options
- Click on Launcher Settings
- Click on the gear icon in right bottom corner
- Select System Tools
- Click on Disable in the Navigation Bar section
- The only way to leave the Android setting is to restart the device, by disconnecting the power

To perform a factory reset of the device follow the next steps:

Step Description

- Open the settings on Android
- Select Backup & Reset
- Select Factory data reset
- (Optional) Select Erase SD card
- Select Reset tablet
- Select Erase everything

Required firmware

PADS4 requires version kernel kernel 4.4.167 Build v1.0.1

Support	Category	Description
	Automatic PADS4 Software updates	Supported.
Ľ		HTML5 Viewer is automatically updated.
M	Offline mode of device	While offline from the network, the device will still
		continue to play PADS4 presentations and change
		planned schedules for 7 days.
		Scheduled presentations, content and data is
		cached local.

	Device				
\subseteq	Portrait mode	Supported. Device will adjust the rotation automatically.			
\subseteq	Block remote control	Option to prevent usage of remote control to operate the screen			
Ŋ	Transfer protocols	HTTP, HTTPS			
	Turn off display	Not supported			
\subseteq	Cluster Viewer	This device is able to be used	This device is able to be used as Cluster Viewer		
	Elements				
□	Video element	Maximum number of videos	4 videos Check out the sup- plier doc- umentation for more info		
	video element	Video rotation	Not supported		
		Seamless videos	Not supported		
		Reflection, skew, flip	Not supported		
		Streaming	HTTP		
\subseteq	Image element	Support for JPG, PNG, BMP, GIF			
	Text element	Supported			
\subseteq	Line element	Supported			
\subseteq	Shape element	Supported			
\subseteq	Scrolling text element	Supported			
\triangle	Formatted text element	Supported			
	Flash element	Not supported			
\subseteq	Table element	Supported			
\subseteq	Interactive button element	Not Supported			
\square	Web element	Usage of the interactive Address Bar not supported			
	Data connections	Data connections make it possible to show inform ation from external sources inside presentations			
	Data providers	More than 70 PADS4 data pro	oviders for retrieval		

			from external sources and the ge and join the data to fit your
Ĭ	Viewer Variables	Usage of Viewer Variables can simplify your presentations and data connections. It also gives the opportunity to centrally manage the content without changing presentations or data providers.	
\square	Property bindings	Apply element properties by using external data sources	
	Rules	-	possible to interact on certain time data and change the beha- tion automatically
\subseteq	Presentation rules	Supported	
\subseteq	Page rules	Supported	
Ŋ	Element rules	Supported	
	Device Management	Device management which can be performed from a remote location	
		Connection state	Device connection state information
		Alerts	Automatically send out alerts when network failures occur for this device
		Reboot	Not supported
		Restart Viewer	Restart PADS4 Viewer
_	Remote device management	Shutdown Wake On Lan	Not supported Not supported
M	Web based and Windows	Screenshot	Retrieve screenshots for what is actually displayed
		Logs	Viewer log, synchronization log, system info
		Viewer Settings	Edit Viewer Settings
		Fonts	Install Fonts on device
		Proof of play	Show Proof of play information
		Blackbox	If help from NDS Support is

		-
		required, the blackbox con-
		tains important information
		for investigation purposes
	Remarks	
	Colors	Texture and pattern colors are not supported
	Transition effects	Horizontal and vertical blinds not supported
4		Splitters, increased circle and sliced circle not sup-
		ported
	Content file integrity	PADS4 Content Library file integrity is checked dur-
	Content file integrity	ing synchronization using MD5
		Local storage limitation of max. 50.000 records on
\Box	Proof of play	the HTML5 Viewer during offline period.
		When the 50.000 is hit, the oldest value will be
		removed first.



PADS4 Installation Manual

Configuring Qbic TD-0350

This page explains how to configure the SOC player to run the PADS4 HTML5 Viewer.

When you turn the device on for the first time it will open a configuration wizard. Follow the steps and specify the settings, as mentioned below.

Installation of the PADS4 HTML5 Viewer Android Launcher

PADS4 requires an Android Launcher to be installed.

This launcher can be downloaded from http://go.pads4.com/?fwlink=1004.

Step Step Description

- 1 Click on settings
- 2 Click on player settings
- 3 Go to Android system section and enable Switch to Android native mode
- 4 Go to Android apps
- Run the internet browser app (for example Lightning or Browser) and type in the URL: http://go.pads4.com/?fwlink=1004
- 6 Click on download
- 7 Click on allow
- 8 Wait about 1 minute (loading screen will not disappear when finished downloading)
- 9 Go to Android apps and click on files > Downloads
- 10 Double click on the NDS Android HTML5 Launcher
- 11 Allow unknown apps to be installed if prompted click on settings > Allow from this source
- 12 Click on the back arrow and then click on install in the lower right corner
- 13 After installing click on open in the lower right corner
- 14 Type in the location of the PADS4 Server
- 15 Click on start and select the PADS4 HTML5 Viewer as Home app and select 'Always'
- 16 Click on Start again
- 17 Allow to modify system settings
- 18 Click on the back arrow
- 19 Click on Allow to access media files
- 20 You can now start the HTML5 Viewer

When finished the launcher will download the PADS4 HTML5 Viewer software and start. At the left bottom location a connection indicator icon will appear. It will turn green if a valid connection is made to the Server.

If a problem occurs open the viewer settings and have a look at the log which may contain important (error) information.

The first time the device is configured, a valid server connection is required to download the PADS4 HTML5 Viewer software.

Upgrading PADS4 Launcher from USB stick

When a new PADS4 Launcher is available follow the next steps to upgrade.

Step Step Description

- 1 Select launcher settings
- 2 Click on the folder icon in the right bottom corner
- 3 Click on Open Link
- 4 Click on the internet browser app (for example Lightning or Browser)
- 5 Select Just once
- 6 Click on download
- 7 Wait about 1 minute (loading screen will not disappear when finished downloading)
- 8 Go to Android apps and click on Files > Downloads
- 9 Double click on the NDS Android HTML5 Launcher
- The PADS4 HTML5 Viewer forces itself to the foreground so you need to minimize the app with the square in the standard Android menu in the bottom
- It is a little tricky to do this. Best is the drag down the upper Android menu below by holding the left mouse button and then quickly click on the Square
- 12 Allow unknown apps to be installed if prompted click on settings > Allow from this source
- 13 Click on the back arrow and then click on install in the lower right corner
- 14 After installing click on Open in the lower right corner

Adjust PADS4 Viewer options

PADS4 Viewer options can be changed directly on the device using a mouse.

Click on the left button of the mouse and hold this down until the menu appears. It is also possible to change options remotely using PADS4 CTRL Center or PADS4 Agent.

Open launcher menu from PADS4 HTML5 Viewer

- Open Viewer menu
- Click on the Launcher Settings button
- Click on the gear icon in right bottom corner

• The Android settings open
If the Hide Status Bar option is turned on, the only way to leave the Android setting is to restart
the device, by disconnecting the power.

Disable Android navigation bar

Optionally you can disable the navigation bar of the device, it can be used to change the volume on the device. To disable it, follow the next steps:

- Open the Viewer options
- Click on Launcher Settings
- Click on the gear icon in right bottom corner
- Select System Tools
- Click on Disable in the Navigation Bar section
- The only way to leave the Android setting is to restart the device, by disconnecting the power

To perform a factory reset of the device follow the next steps:

Step Description

- Open the settings on Android
- Select Backup & Reset
- Select Factory data reset
- (Optional) Select Erase SD card
- Select Reset tablet
- Select Erase everything

Required firmware

PADS4 requires version kernel 3.0.101+ Build v1.1.0

Supported features and limitations

Support	Category	Description
	Automatic PADS4 Software updates	Supported.
	Automatic PAD34 Software updates	HTML5 Viewer is automatically updated.
	Offline mode of device	While offline from the network, the device will still
		continue to play PADS4 presentations and change
		planned schedules for 7 days.
		Scheduled presentations, content and data is
		cached local.

	Device		
\subseteq	Portrait mode	Supported. Device will adjust the rotation automatically.	
\subseteq	Block remote control	Option to prevent usage of remote control to operate the screen	
\subseteq	Transfer protocols	HTTP, HTTPS	
	Turn off display	Not supported	
\subseteq	Cluster Viewer	This device is able to be used	as Cluster Viewer
\subseteq	LED light bar	Supported. Full color spectrui	m.
	Elements		
\subseteq	Video element	Maximum number of videos Video rotation	1 video Check out the supplier documentation for more info
		Seamless videos Reflection, skew, flip Streaming	Not supported Not supported Not supported HTTP
\subseteq	Image element	Support for JPG, PNG, BMP, G	ilF
\triangle	Text element	Supported	
\subseteq	Line element	Supported	
\subseteq	Shape element	Supported	
\subseteq	Scrolling text element	Supported	
\leq	Formatted text element	Supported	
	Flash element	Not supported	
\leq	Table element	Supported	
\subseteq	Interactive button element	Not Supported	
\subseteq	Web element	Usage of the interactive Address Bar not supported	
	Data connections	Data connections make it pos ation from external sources in	

Ý	Data providers	More than 70 PADS4 data providers for retrieval of (realtime) data from external sources and the possibility to change and join the data to fit your purpose	
	Viewer Variables	Usage of Viewer Variables can simplify your presentations and data connections. It also gives the opportunity to centrally manage the content without changing presentations or data providers. Apply element properties by using external data	
	Property bindings	sources	. , ,
	Rules	Rules will make it possible to interact on certain situations like realtime data and change the behavior of a presentation automatically	
\triangle	Presentation rules	Supported	
\subseteq	Page rules	Supported	
\subseteq	Element rules	Supported	
∑	Remote device management Web based and Windows	Device management from a remote local Connection state Alerts Reboot Restart Viewer Shutdown Wake On Lan Screenshot Logs Viewer Settings Fonts	nt which can be performed ation Device connection state information Automatically send out alerts when network failures occur for this device Not supported Restart PADS4 Viewer Not supported Not supported Retrieve screenshots for what is actually displayed Viewer log, synchronization log, system info Edit Viewer Settings Install Fonts on device
		Proof of play	Show Proof of play information

		Blackbox require	from NDS Support is ed, the blackbox con- nportant information estigation purposes	
	Remarks		<u> </u>	
	Colors	Texture and pattern colors a	are not supported	
口	Transition effects		Horizontal and vertical blinds not supported Splitters, increased circle and sliced circle not supported	
Q	Content file integrity		PADS4 Content Library file integrity is checked dur- ing synchronization using MD5	
Q	Proof of play	the HTML5 Viewer during o	Local storage limitation of max. 50.000 records or the HTML5 Viewer during offline period. When the 50.000 is hit, the oldest value will be removed first.	



PADS4 Installation Manual

Configuring Qbic TD-1050 PRO

This page explains how to configure the SOC player to run the PADS4 HTML5 Viewer.

When you turn the device on for the first time it will open a configuration wizard. Follow the steps and specify the settings, as mentioned below.

Installation of the PADS4 HTML5 Viewer Android Launcher

PADS4 requires an Android Launcher to be installed.

This launcher can be downloaded from http://go.pads4.com/?fwlink=1004.

Step Step Description

- 1 Click on settings
- 2 Click on player settings
- 3 Go to Android system section and enable Switch to Android native mode
- 4 Go to Android apps
- Run the internet browser app (for example Lightning or Browser) and type in the URL: http://go.pads4.com/?fwlink=1004
- 6 Click on download
- 7 Click on allow
- 8 Wait about 1 minute (loading screen will not disappear when finished downloading)
- 9 Go to Android apps and click on files > Downloads
- 10 Double click on the NDS Android HTML5 Launcher
- 11 Allow unknown apps to be installed if prompted click on settings > Allow from this source
- 12 Click on the back arrow and then click on install in the lower right corner
- 13 After installing click on open in the lower right corner
- 14 Type in the location of the PADS4 Server
- 15 Click on start and select the PADS4 HTML5 Viewer as Home app and select 'Always'
- 16 Click on Start again
- 17 Allow to modify system settings
- 18 Click on the back arrow
- 19 Click on Allow to access media files
- 20 You can now start the HTML5 Viewer

When finished the launcher will download the PADS4 HTML5 Viewer software and start. At the left bottom location a connection indicator icon will appear. It will turn green if a valid connection is made to the Server.

If a problem occurs open the viewer settings and have a look at the log which may contain important (error) information.

The first time the device is configured, a valid server connection is required to download the PADS4 HTML5 Viewer software.

Upgrading PADS4 Launcher from USB stick

When a new PADS4 Launcher is available follow the next steps to upgrade.

Step Step Description

- 1 Select launcher settings
- 2 Click on the folder icon in the right bottom corner
- 3 Click on Open Link
- 4 Click on the internet browser app (for example Lightning or Browser)
- 5 Select Just once
- 6 Click on download
- 7 Wait about 1 minute (loading screen will not disappear when finished downloading)
- 8 Go to Android apps and click on Files > Downloads
- 9 Double click on the NDS Android HTML5 Launcher
- The PADS4 HTML5 Viewer forces itself to the foreground so you need to minimize the app with the square in the standard Android menu in the bottom
- It is a little tricky to do this. Best is the drag down the upper Android menu below by holding the left mouse button and then quickly click on the Square
- 12 Allow unknown apps to be installed if prompted click on settings > Allow from this source
- 13 Click on the back arrow and then click on install in the lower right corner
- 14 After installing click on Open in the lower right corner

Adjust PADS4 Viewer options

PADS4 Viewer options can be changed directly on the device using a mouse.

Click on the left button of the mouse and hold this down until the menu appears. It is also possible to change options remotely using PADS4 CTRL Center or PADS4 Agent.

Open launcher menu from PADS4 HTML5 Viewer

- Open Viewer menu
- Click on the Launcher Settings button
- Click on the gear icon in right bottom corner

• The Android settings open
If the Hide Status Bar option is turned on, the only way to leave the Android setting is to restart
the device, by disconnecting the power.

Disable Android navigation bar

Optionally you can disable the navigation bar of the device, it can be used to change the volume on the device. To disable it, follow the next steps:

- Open the Viewer options
- Click on Launcher Settings
- Click on the gear icon in right bottom corner
- Select System Tools
- Click on Disable in the Navigation Bar section
- The only way to leave the Android setting is to restart the device, by disconnecting the power

To perform a factory reset of the device follow the next steps:

Step Description

- Open the settings on Android
- Select Backup & Reset
- Select Factory data reset
- (Optional) Select Erase SD card
- Select Reset tablet
- Select Erase everything

Required firmware

PADS4 requires version kernel kernel 4.4.103 Build v1.0.1

Supported features and limitations

Support	Category	Description
	Automatic PADS4 Software updates	Supported.
Ľ	Automatic PAD34 Software updates	HTML5 Viewer is automatically updated.
	Offline mode of device	While offline from the network, the device will still
		continue to play PADS4 presentations and change
		planned schedules for 7 days.
		Scheduled presentations, content and data is
		cached local.

	Device			
\leq	Portrait mode	Supported. Device will adjust the rotation automatically.		
\leq	Block remote control	Option to prevent usage of re operate the screen	Option to prevent usage of remote control to operate the screen	
\leq	Transfer protocols	HTTP, HTTPS		
~	Turn off display	Not supported		
\leq	Cluster Viewer	This device is able to be used	as Cluster Viewer	
\leq	LED light bar	Supported. Full color spectrui	m.	
	Elements			
\leq	Video element	Maximum number of videos Video rotation Seamless videos Reflection, skew, flip	4 videos Check out the supplier documentation for more info Not supported Not supported Not supported HTTP	
7	Image element	Streaming Support for JPG, PNG, BMP, G		
\leq	Text element	Supported		
\leq	Line element	Supported		
\leq	Shape element	Supported		
\leq	Scrolling text element	Supported		
\leq	Formatted text element	Supported		
	Flash element	Not supported		
\leq	Table element	Supported		
\leq	Interactive button element	Not Supported		
\leq	Web element	Usage of the interactive Addre	ess Bar not sup-	
	Data connections	Data connections make it pos ation from external sources in		

Ý	Data providers	More than 70 PADS4 data providers for retrieval of (realtime) data from external sources and the possibility to change and join the data to fit your purpose	
	Viewer Variables	Usage of Viewer Variables can simplify your presentations and data connections. It also gives the opportunity to centrally manage the content without changing presentations or data providers. Apply element properties by using external data	
	Property bindings	sources	. , ,
	Rules	Rules will make it possible to interact on certain situations like realtime data and change the behavior of a presentation automatically	
\triangle	Presentation rules	Supported	
\subseteq	Page rules	Supported	
\subseteq	Element rules	Supported	
∑	Remote device management Web based and Windows	Device management from a remote local Connection state Alerts Reboot Restart Viewer Shutdown Wake On Lan Screenshot Logs Viewer Settings Fonts	nt which can be performed ation Device connection state information Automatically send out alerts when network failures occur for this device Not supported Restart PADS4 Viewer Not supported Not supported Retrieve screenshots for what is actually displayed Viewer log, synchronization log, system info Edit Viewer Settings Install Fonts on device
		Proof of play	Show Proof of play information

		Blackbox	If help from NDS Support is required, the blackbox con- tains important information for investigation purposes
	Remarks		
	Colors	Texture and pattern colors are not supported	
Ç	Transition effects	Horizontal and vertical blinds not supported Splitters, increased circle and sliced circle not supported	
	Content file integrity	PADS4 Content Library file integrity is checked dur ing synchronization using MD5	
	Proof of play	Local storage limitation of max. 50.000 records or the HTML5 Viewer during offline period. When the 50.000 is hit, the oldest value will be removed first.	



Certified Viewer devices

This section shows the certified Viewer devices from Samsung.



PADS4 Installation Manual

Viewer on Samsung SSP2

Contents

- 1. First time use
- 1.1. Configuring the device
- 1.2. Resetting the device
- 2. Installing PADS4 Viewer
- 2.1. Checking device firmware
- 2.2. Updating firmware
- 2.3. Adjust PADS4 Viewer settings using the options screen
- 3. Supported features and limitations
- 4. Troubleshooting

1. First time use

This document is related to the SSSP2.

When you turn the device on for the first time, it will open a configuration wizard. Follow the steps and specify the settings, as mentioned below. (If the configuration wizard does not start, then please first factory reset your device, as described in '1.2 resetting the device'.)

1.1. Configuring the device

Please read the installing section to setup the Viewer. There are no changes that need to be performed before installing the Viewer.

1.2. Resetting the device

If your device was used before, we recommend that you factory reset your device, so that all storage is freed and no other software interferes with the PADS4 Viewer software.

Step	Description
01	Turn the screen off
02	Press on the remote control: <button>Mute + 1 + 8 + 2 + <button>ON</button></button>
03	Select option => Factory reset => factory reset

The device will factory reset and afterwards you will see the welcome screen, please follow the steps as described in '1.1 configuring the device'.

2. Installing PADS4 Viewer

Step	Description
01	Select language and press Next
02	Display Orientation. Select Landscape
03	Auto power off. Select off
04	Network settings. Connect to your network
05	Clock set. Configure current date and time
	Play via. Select URL Launcher. Specify PADS4 Server url
	Hosting PADS4 on HTTP (default)
06	http:// <server>/pads4/native/samsung</server>
	https:// <server>/pads4/native/samsung (second option, secured using https)</server>
	where <server> is the IP address or domain name of your PADS4 Server.</server>
07	Setup complete. Select OK
08	In Home menu select URL launcher

If the wizard does not show up on startup, change the input to HDMI, next press the menu button on the remote control and select Setup under System menu (Default pin is 0000).

When finished the device will download the PADS4 HTML5 Viewer software and start. At the left bottom location a connection indicator icon will appear. It will turn green if a valid connection is made to the Server.

If a problem occurs open the viewer settings and have a look at the log which may contain important (error) information.

The first time the device is configured, a valid server connection is required to download the PADS4 HTML5 Viewer software.

2.1. Checking device firmware

To run the PADS4 viewer properly on the SSSP2 and make sure that all functionality works, you need to have firmware version as mentioned in step 4 installed on the device. Please check using the following steps.

Step	Description	
01	Power on the screen and press the Home button on the remote control	
02	Select more options	
03	Select support	
04	Select Contact Samsung Software version shows the version number installed. Version 1032.7 is required by PADS4 (version 1018 for DB10D)	

2.2 Updating firmware

Step	Description
01	Insert the USB Stick into the device
02	Press menu button
03	Select support
04	Select Software update
05	Select Update now and follow the instructions

2.3. Adjust PADS4 Viewer settings using the options screen

You can adjust the PADS4 Viewer settings directly on the display. To enter the options screen on the device itself, hold the left mouse button down or touch the screen for 3 seconds.

3. Supported features and limitations

Support	Category	Description
	Automatic PADS4 Software updates	Supported.
Ľ		HTML5 Viewer is automatically updated.
\square	Offline mode of device	While offline from the network, the device will still continue to play PADS4 presentations and change planned schedules for 7 days. Scheduled presentations, content and data is

		cached local.	
		If the device does not have po 72 hours, the internal clock wil default factory date time. Whe ted again and there is no netw the PADS4 Server, you schedu ible due to the factory date tim	I reset back to in this device is star- fork connection to les may not be vis-
	Device		
	Portrait mode	Supported. Set the PADS4 rotation option the Viewer settings to set the smode. Do NOT use the screen	creen in portrait
\square	Block remote control	Option to prevent usage of remote control to operate the screen	
\subseteq	Transfer protocols	HTTP, HTTPS	
	Turn off display	Not supported	
K	Cluster Viewer	This device is able to be used as Cluster Viewer	
	Elements		
		Maximum number of videos	1 video on each page. Check out the supplier documentation for more info
		Video rotation	Not supported
N.			Only 16:9 aspect
	Video element	Video size Topmost position	ratio videos are fully supported. 4:3 (or other aspect ratio's) videos have a lower calculated height Video is always on
	Video element		fully supported. 4:3 (or other aspect ratio's) videos have a lower calculated height

		Streaming HTTP	
\subseteq	Image element	Support for JPG, PNG, BMP, GIF	
\subseteq	Text element	Supported	
\subseteq	Line element	Supported	
\subseteq	Shape element	Supported	
\subseteq	Scrolling text element	Supported	
\subseteq	Formatted text element	Supported	
	Flash element	Not supported	
\subseteq	Table element	Supported	
\subseteq	Interactive button element	Supported Mouse cursor options not supported Interactive Data filter & sort dialog window not supported	
\square	Web element	Usage of the interactive Address Bar not supported	
	Data connections	Data connections make it possible to show information from external sources inside presentations	
\square	Data providers	More than 70 PADS4 data providers for retrieval of (realtime) data from external sources and the possibility to change and join the data to fit your purpose	
\subseteq	Viewer Variables	Usage of Viewer Variables can simplify your presentations and data connections. It also gives the opportunity to centrally manage the content without changing presentations or data providers.	
\subseteq	Property bindings	Apply element properties by using external data sources	
	Rules	Rules will make it possible to interact on certain situations like realtime data and change the behavior of a presentation automatically	
\subseteq	Presentation rules	Supported	
\subseteq	Page rules	Supported	

\subseteq	Element rules	Supported	
	Device Management	Device manageme	ent which can be performed ation
		Connection state	Device connection state information
		Alerts	Automatically send out alerts when network failures occur for this device
		Reboot	Supported
		Restart Viewer	Restart PADS4 Viewer
		Shutdown	Not supported
		Wake On Lan	Not supported
\subseteq	Remote device management Web based and Windows	Screenshot	Retrieve screenshots for what is actually displayed
		Logs	Viewer log, synchronization log, system info
		Viewer Settings	Edit Viewer Settings
		Fonts	Install Fonts on device
		Proof of play	Show Proof of play information
		Blackbox	If help from NDS Support is required, the blackbox contains important information for investigation purposes
	Remarks		
	Colors	Texture and patter	n colors are not supported
口	Transition effects	Horizontal and vertical blinds not supported Splitters, increased circle and sliced circle not supported	
	Content file integrity	<u>'</u>	rary file integrity is checked dur- n using MD5
口	Proof of play	Local storage limitation of max. 50.000 records on the HTML5 Viewer during offline period. When the 50.000 is hit, the oldest value will be removed first.	

4. Troubleshooting

Problem	Solution	



PADS4 Installation Manual

Viewer on Samsung SSP3 (E serie)

Contents

- 1. First time use
- 1.1. Configuring the device
- 1.2. Resetting the device
- 2. Installing PADS4 Viewer
- 2.1. Checking device firmware
- 2.2. Updating firmware
- 2.3. Adjust PADS4 Viewer settings using the options screen
- 3. Supported features & limitations
- 4. Troubleshooting

Appendix 1

1. First time use

This document is related to the SSSP3.

When you turn the device on for the first time, it will open a configuration wizard. Follow the steps and specify the settings, as mentioned below. (If the configuration wizard does not start, then please first factory reset your device, as described in '1.2 resetting the device'.)

1.1. Configuring the device

Please read the installing section to setup the Viewer. There are no changes that need to be performed before installing the Viewer.

1.2. Resetting the device

If your device was used before, we recommend that you factory reset your device, so that all storage is freed and no other software interferes with the PADS4 Viewer software.

Step	Description
01	Turn the screen off
02	Press on the remote control: <button>Mute + 1 + 8 + 2 + <button>ON</button></button>
03	Select option => Factory reset => factory reset

The device will factory reset and afterwards you will see the welcome screen, please follow the steps as described in '1.1 configuring the device'.

2. Installing PADS4 Viewer

Step	Description		
01	Select language and press Next		
02	Display Orientation. Select Landscape		
03	Auto power off. Select off		
04	Network settings. Connect to your network		
05	Clock set. Configure current date and time		
	Play via. Select URL Launcher. Specify PADS4 Server url		
	Hosting PADS4 on HTTP (default)		
06	http:// <server>/pads4/native/samsung</server>		
	https:// <server>/pads4/native/samsung (second option, secured using https)</server>		
	where <server> is the IP address or domain name of your PADS4 Server.</server>		
07	Device name (optional)		

80	Setup complete. Select OK
80	In Home menu select URL launcher

If the wizard does not show up on startup, change the input to HDMI, next press the menu button on the remote control and select Setup under System menu (Default pin is 0000).

When finished the device will download the PADS4 HTML5 Viewer software and start. At the left bottom location a connection indicator icon will appear. It will turn green if a valid connection is made to the Server.

If a problem occurs open the viewer settings and have a look at the log which may contain important (error) information.

The first time the device is configured, a valid server connection is required to download the PADS4 HTML5 Viewer software.

2.1. Checking device firmware

To run the PADS4 viewer properly on the SSSP3 and make sure that all functionality works, you need to have firmware version as mentioned in step 4 installed on the device. Please check using the following steps.

Step	Description	
01	Power on the screen and press the Home button on the remote control	
02	Select more options	
03	Select support	
04	Select Contact Samsung Software version shows the version number installed. Version 1029 is required by PADS4 (1011 for DB10E)	

2.2 Updating firmware

Step	Description
01	Insert the USB Stick into the device
02	Press menu button
03	Select support
04	Select Software update
05	Select Update now and follow the instructions

2.3. Adjust PADS4 Viewer settings using the options screen

You can adjust the PADS4 Viewer settings directly on the display. To enter the options screen on the device itself, hold the left mouse button down or touch the screen for 3 seconds.

3. Supported features and limitations

Support	Category	Description	
\subseteq	Automatic PADS4 Software updates	After updating PADS4 Server, matically update the PADS4 so	
\square	Offline mode of device	While offline from the network continue to play PADS4 present planned schedules for 7 days. Scheduled presentations, contached local.	ntations and change
	Device		
区	Portrait mode	Set the PADS4 rotation option the Viewer settings to set the s mode. Do NOT use the screen	screen in portrait
\subseteq	Block remote control	Option to prevent usage of a roperate the screen	remote control to
\subseteq	Transfer protocols	HTTP, HTTPS	
M	Turn off display	Turn off display when no preso Device still active but backlight less power consumption	
\subseteq	Cluster Viewer	This device is able to be used	as Cluster Viewer
	Elements		
□ ⁄	Niela a alamant	Maximum number of videos	1 video on each page. Check out the supplier documentation for more info
<u> </u>	Video element	Video rotation	Not supported
		Seamless videos	In landscape mode only
		Reflection, skew, flip	Not supported
		Streaming	HTTP, HLS and

		Lynk DRM Select TV Input channels	RTP(multicast) streaming. Deliver secured, premium HDTV content to Samsung devices. Check appendix 1 for more information about using Lynk DRM Show HDMI & DVI
$\overline{\mathbf{Y}}$	lmage element	Support for JPG, PNG, BMP, (as video input GIF
$\overline{\underline{\mathbf{S}}}$	Text element	Supported	
\subseteq	Line element	Supported	
\subseteq	Shape element	Supported	
\subseteq	Scrolling text element	Supported	
\subseteq	Formatted text element	Supported	
\subseteq	Flash element	There is no support to detect ation when playing. Functions next page and detect end of supported	s such as play once
\subseteq	Table element	Supported	
区	Interactive button element	Mouse cursor options not su Interactive Data filter & sort of supported	• •
\square	Web element	Usage of the interactive Add ported	ress Bar not sup-
\square	Property bindings	Apply element properties by sources	using external data
	Data connections	Data connections make it po- ation from external sources i	nside presentations
	Data providers	More than 70 PADS4 data pr of (realtime) data from exter possibility to change and joir purpose	nal sources and the

\square	Viewer Variables	presentations and It also gives the op	dariables can simplify your data connections. Sportunity to centrally manage the changing presentations or
	Rules	•	possible to interact on certain time data and change the beha- tion automatically
\subseteq	Presentation rules	Supported	
\subseteq	Page rules	Supported	
\subseteq	Element rules	Supported	
	Device Management		ent which can be performed
		from a remote loca	ation
		Connection state	Device connection state information
		Alerts	Automatically send out alerts when network failures occur for this device
		Reboot	Reboot device
		Restart Viewer	Restart PADS4 Viewer
		Wake On Lan	WOL
	Remote device management	Screenshot	Retrieve screenshots for what is actually displayed
٠	Web based and Windows	Logs	Viewer log, synchronization log, system info
		Viewer Settings	Edit Viewer Settings
		Fonts	Install Fonts on device
		Proof of play	Show Proof of play inform- ation
		Blackbox	If help from NDS Support is required, the blackbox contains important information for investigation purposes
	Remarks		
_	Device Power	If the device does	not have power for more than

		72 hours, the internal clock will reset back to default factory date time. When this device is started again and there is no network connection to the PADS4 Server, you schedules may not be visible due to the factory date time.
	Colors	Texture and pattern colors are not supported
\Box	Transition effects	Horizontal and vertical blinds not supported Splitters, increased circle and sliced circle not sup- ported
	Content file integrity	PADS4 Content Library file integrity is checked during synchronization using MD5

4. Troubleshooting

Problem	Solution

Appendix 1 Lynk-DRM streaming

The Samsung LYNK Digital Rights Management (DRM) encryption. It enables hospitality service providers and integrators to easily deliver secured, premium HDTV content to Samsung devices.

Video streaming on Samsung SSP3

If you are running the HTML5 Viewer on a Samsung SSP3 screen than there is support for video streaming. The protocols that are supported are HTTP, HLS and RTP and also content that is encrypted by Samsung Lynk DRM can be played.

We have tested all three streaming protocols on a DM32E with firmware 1029.7 and a DB10E with firmware 1010.4, the video format of the streams was H.264 mpeg4. Theoretically it should be able to play all video formats that are supported by Samsung.

There is a side note for HLS Streams, if the stream Url doesn't end with the extension .m3u8, then we cannot detect that you want to make use a HLS Stream and it will try to play it as a normal http stream. If this is the case, you need to manually enter the Samsung notation of for playing HLS stream, which is to add '|COMPONENT=HLS' to the end of stream Url. So the Url looks like: http://<server>:<port>/<path>|COMPONENT=HLS.

When streaming IPTV through a Samsung SOC player, you can optionally add the HW option to the Url of the stream. Based on the documentation of Samsung this will improve the performance of the stream, for example:

rtp://239.0.0.4:6004|HW

Playing streams from Lynk DRM

The PADS4 HTML5 Viewer supports streams encrypted by a Samsung Lynk DRM Server. You can use the video/sound element in PADS4 and add a Lynk Url to the playlist. So in the element, select the Video Stream content type and specify the Lynk Url. Something like:

rtp://239.0.0.1:6004|HW|COMPONENT=LYNK|TYPE=1

To play type 2 or 3 Lynk encrypted stream, you need to specify a LynkDRM Server, so for these streams you will need to add the lynk_server query option to the Lynk Url. Something like:

http://<server>/videofile.mp4|COMPONENT=LYNK|TYPE=2?lynk_server=lynkserver.local:8080

Please contact Samsung for more information about Lynk DRM.



PADS4 Installation Manual

Viewer on Samsung SSP4 (F serie)

Contents

- 1. First time use
- 1.1. Configuring the device
- 1.2. Resetting the device
- 1.3. Uninstall an app
- 2. Installing PADS4 Viewer
- 2.1. Checking device firmware
- 2.2. Updating firmware

- 2.3. Adjust PADS4 Viewer settings using the options screen
- 3. Supported features & limitations
- 4. Troubleshooting

1. First time use

This document is related to the SSSP4.

When you turn the device on for the first time, it will open a configuration wizard. Follow the steps and specify the settings, as mentioned below. (If the configuration wizard does not start, then please first factory reset your device, as described in '1.2 resetting the device'.)

1.1. Configuring the device

Please read the installing section to setup the Viewer. There are no changes that need to be performed before installing the Viewer.

1.2. Resetting the device

If your device was used before, we recommend that you factory reset your device, so that all storage is freed and no other software interferes with the PADS4 Viewer software.

Step	Description
01	Turn the screen off
02	Press on the remote control: <button>Mute + 1 + 8 + 2 + <button>ON</button></button>
03	Select option => Factory reset => factory reset

The device will factory reset and afterwards you will see the welcome screen, please follow the steps as described in '1.1 configuring the device'.

1.3 Uninstall an app

When you fail to open the device menu by pressing the key combination, it is possible that the installed app blocks this option. Then you need to uninstall the app first before you can open the device menu.

Step	Description
01	Open Home menu
02	Select URL launcher settings

03	Select the uninstall option
04	Confirm to uninstall the app

2. Installing PADS4 Viewer

Step	Description
01	Select language and press Next
02	Display Orientation. Select Landscape
03	Auto power off. Select off
04	Network settings. Connect to your network
05	Clock set. Configure current date and time
	Play via. Select URL Launcher. Specify PADS4 Server url
06	Hosting PADS4 on HTTP (default) http:// <server>/PADS4/apps/tizen https://<server>/PADS4/apps/tizen where <server> is the IP address or domain name of your PADS4 Server. (second option, secured using https) Be aware that PADS4 must be specified in capitals, otherwise Tizen will not be able to connect due to case sensitivity. If you are using PADS4 version 2020.1 or earlier please use the old link: http://<server>/pads4/native/samsung</server></server></server></server>
07	https:// <server>/pads4/native/samsung (second option, secured using https)</server>
07	Device name (optional)
80	Setup complete. Select OK
80	In Home menu select URL launcher

If the wizard does not show up on startup, change the input to HDMI, next press the menu button on the remote control and select Setup under System menu (Default pin is 0000).

When finished the device will download the PADS4 HTML5 Viewer software and start. At the left bottom location a connection indicator icon will appear. It will turn green if a valid connection is made to the Server.

If a problem occurs open the viewer settings and have a look at the log which may contain important (error) information.

The first time the device is configured, a valid server connection is required to download the PADS4 HTML5 Viewer software.

2.1. Checking device firmware

To run the PADS4 viewer properly on the SSSP4 and make sure that all functionality works, you need to have firmware as mentioned in step 4 installed on the device. Please check using the following steps.

Step	Description
01	Power on the screen and press the Home button on the remote control
02	Select more options
03	Select support
04	Select Contact Samsung Software version shows the version number installed.
	Version 2070.6 is required by PADS4 Minimum PADS4 version required is 2020.1

2.2 Updating firmware

Step	Description
01	Insert the USB Stick into the device
02	Press menu button
03	Select support
04	Select Software update
05	Select Update now and follow the instructions

2.3. Adjust PADS4 Viewer settings using the options screen

You can adjust the PADS4 Viewer settings directly on the display. To enter the options screen on the device itself, hold the left mouse button down or touch the screen for 3 seconds.

3. Supported features and limitations

Support	Category	Description
	Automatic PADS4 Software updates	Supported.
¥		HTML5 Viewer is automatically updated.
	Offline mode of device	While offline from the network, the device will still
_		continue to play PADS4 presentations and change
\mathbf{M}		planned schedules for 7 days.
		Scheduled presentations, content and data is
		cached local.

	Device		
M	Portrait mode	Supported. Set the PADS4 rotation option the Viewer settings to set the mode. Do NOT use the screen	screen in portrait n SSP rotate option
\subseteq	Block remote control	Option to prevent usage of re operate the screen	mote control to
\subseteq	Transfer protocols	HTTP, HTTPS	
	Turn off display	Not supported	
\subseteq	Cluster Viewer	This device is able to be used	as Cluster Viewer
	Elements		
Ý	Video element	Maximum number of videos Video rotation Seamless videos Maximum framerate Playback speed adjustment Reflection, skew, flip Streaming	2 seamless videos on each page. Check out the supplier documentation for more info Not supported Supported 30 fps Not supported Not supported HTTP, HLS,RTP, UDP Simultaneous playing video from stream and file is not supported.
Ŋ	lmage element	Support for JPG, PNG, BMP, G	IF
\subseteq	Text element	Supported	
	Line element	Supported	
\subseteq	Shape element	Supported	
Y	Scrolling text element	Supported	

\subseteq	Formatted text element	Supported	
	Flash element	Not supported	
\subseteq	Table element	Supported	
Ý	Interactive button element	Supported Mouse cursor options not supported Interactive Data filter & sort dialog window not supported	
\subseteq	Web element	Usage of the interactive Address Bar not supported	
	Data connections	Data connections make it possible to show information from external sources inside presentations	
Ý	Data providers	More than 70 PADS4 data providers for retrieval of (realtime) data from external sources and the possibility to change and join the data to fit your purpose	
	Viewer Variables	Usage of Viewer Variables can simplify your presentations and data connections. It also gives the opportunity to centrally manage the content without changing presentations or data providers.	
\square	Property bindings	Apply element properties by using external data sources	
	Rules	Rules will make it possible to interact on certain situations like realtime data and change the behavior of a presentation automatically	
\subseteq	Presentation rules	Supported	
Y	Page rules	Supported	
\subseteq	Element rules	Supported	
	Device Management	Device management which can be performed from a remote location	
	Remote device management	Connection state Device connection state information Automatically send out alerts	
	Web based and Windows	Alerts when network failures occur for this device	

		Reboot	Supported
		Restart Viewer	Restart PADS4 Viewer
		Shutdown	Not supported
		Wake On Lan	Supported
			Retrieve screenshots for
		Screenshot	what is actually displayed
		Logs	Viewer log, synchronization log, system info
		Viewer Settings	Edit Viewer Settings
		Fonts	Install Fonts on device
		Proof of play	Show Proof of play information
		Blackbox	If help from NDS Support is required, the blackbox contains important information
			for investigation purposes
	Remarks		
 	Colors	Texture and patter	n colors are not supported
Ģ	Transition effects		rtical blinds not supported d circle and sliced circle not sup-
	Content file integrity	PADS4 Content Library file integrity is checked during synchronization using MD5	
Q	Proof of play	the HTML5 Viewer	tation of max. 50.000 records on during offline period. s hit, the oldest value will be

4. Troubleshooting

Problem	Solution
	Viewer will restart
	twice and update to
Update system to PADS4 2020.2	the new Tizen
	launcher auto-
	matically.



PADS4 Installation Manual

Viewer on Samsung SSP5 (H & J serie, Tizen 3)

Contents

- 1. First time use
- 1.1. Configuring the device
- 1.2. Resetting the device
- 1.3. Uninstall an app
- 2. Installing PADS4 Viewer
- 2.1. Checking device firmware
- 2.2. Updating firmware
- 2.3. Adjust PADS4 Viewer settings using the options screen
- 3. Supported features & limitations
- 4. Troubleshooting

1. First time use

This document is related to the SSSP5.

When you turn the device on for the first time, it will open a configuration wizard. Follow the steps and specify the settings, as mentioned below. (If the configuration wizard does not start, then please first factory reset your device, as described in '1.2 resetting the device'.)

1.1. Configuring the device

Please read the installing section to setup the Viewer. There are no changes that need to be performed before installing the Viewer.

1.2. Resetting the device

If your device was used before, we recommend that you factory reset your device, so that all storage is freed and no other software interferes with the PADS4 Viewer software.

Step	Description
01	Turn the screen off
02	Press on the remote control: <button>Mute + 1 + 8 + 2 + <button>ON</button></button>
03	Select option => Factory reset => factory reset

The device will factory reset and afterwards you will see the welcome screen, please follow the steps as described in '1.1 configuring the device'.

1.3 Uninstall an app

When you fail to open the device menu by pressing the key combination, it is possible that the installed app blocks this option. Then you need to uninstall the app first before you can open the device menu.

Step	Description
01	Open Home menu
02	Select URL launcher settings
03	Select the uninstall option
04	Confirm to uninstall the app

2. Installing PADS4 Viewer

Step	Description
01	Select language and press Next
02	Display Orientation. Select Landscape
03	Auto power off. Select off

04	Network settings. Connect to your network	
05	Clock set. Configure current date and time	
	Play via. Select URL Launcher. Specify PADS4 Server url	
	Hosting PADS4 on HTTP (default)	
	http:// <server>/PADS4/apps/tizen</server>	
	https:// <server>/PADS4/apps/tizen</server>	
	where <server> is the IP address or domain name of your PADS4 Server.</server>	
06	(second option, secured using https)	
	Be aware that PADS4 must be specified in capitals, otherwise Tizen will not be able to connect due to case sensitivity.	
	, and the second	
	If you are using PADS4 version 2020.1 or earlier please use the old link:	
	http:// <server>/pads4/native/samsung</server>	
	https:// <server>/pads4/native/samsung (second option, secured using https)</server>	
07	Device name (optional)	
08	Setup complete. Select OK	
08	In Home menu select URL launcher	

If the wizard does not show up on startup, change the input to HDMI, next press the menu button on the remote control and select Setup under System menu (Default pin is 0000).

When finished the device will download the PADS4 HTML5 Viewer software and start. At the left bottom location a connection indicator icon will appear. It will turn green if a valid connection is made to the Server.

If a problem occurs open the viewer settings and have a look at the log which may contain important (error) information.

The first time the device is configured, a valid server connection is required to download the PADS4 HTML5 Viewer software.

2.1. Checking device firmware

To run the PADS4 viewer properly on the SSSP5 and make sure that all functionality works, you need to have firmware as mentioned in step 4 installed on the device. Please check using the following steps.

Step	Description
01	Power on the screen and press the Home button on the remote control
02	Select more options
03	Select support

	Select Contact Samsung
	Software version shows the version number installed.
04	
	Version 2060.7 is required by PADS4
	Minimum PADS4 version required is 2020.1

2.2 Updating firmware

Step	Description
01	Insert the USB Stick into the device
02	Press menu button
03	Select support
04	Select Software update
05	Select Update now and follow the instructions

2.3. Adjust PADS4 Viewer settings using the options screen

You can adjust the PADS4 Viewer settings directly on the display. To enter the options screen on the device itself, hold the left mouse button down or touch the screen for 3 seconds.

3. Supported features and limitations

Support	Category	Description	
\subseteq	Automatic PADS4 Software updates	Supported. HTML5 Viewer is automatically updated.	
Ý	Offline mode of device	While offline from the network, the device will still continue to play PADS4 presentations and change planned schedules for 7 days. Scheduled presentations, content and data is cached local.	
	Device		
M	Portrait mode	Supported. Set the PADS4 rotation option to 270 degrees in the Viewer settings to set the screen in portrait mode. Do NOT use the screen SSP rotate option	
\subseteq	Block remote control	Option to prevent usage of remote control to operate the screen	

\subseteq	Transfer protocols	HTTP, HTTPS		
	Turn off display	Not supported		
\subseteq	Cluster Viewer	This device is able to be used	as Cluster Viewer	
	Elements			
		Maximum number of videos	2 seamless videos on each page. Maximum of one 4K video on each page. Check out the sup- plier doc- umentation for more info	
		Video rotation	Not supported	
\leq	Video element	Seamless videos	Supported	
		Maximum framerate	30 fps	
		Playback speed adjustment	Not supported	
		Reflection, skew, flip	Not supported	
		Streaming	HTTP, HLS,RTP, UDP Simultaneous play- ing video from stream and file is not supported.	
\subseteq	Image element	Support for JPG, PNG, BMP, G	IF	
\subseteq	Text element	Supported		
M	Line element	Supported		
Ŋ	Shape element	Supported		
\subseteq	Scrolling text element	Supported		
\subseteq	Formatted text element	Supported		
	Flash element	Not supported		
	Table element	Supported		
\subseteq	Interactive button element	Supported Mouse cursor options not sup	pported	

		Interactive Data filt	er & sort dialog window not
		supported	
	Web element	Usage of the intera	ctive Address Bar not sup-
	web element	ported	
	Data connections	Data connections make it possible to show inform-	
		ation from external sources inside presentations	
			64 data providers for retrieval rom external sources and the
\triangle	Data providers	· ·	ge and join the data to fit your
		purpose	,
		Usage of Viewer Va	ariables can simplify your
		presentations and	
$\mathbf{\Sigma}$	Viewer Variables	-	portunity to centrally manage
			t changing presentations or
		data providers.	
$\mathbf{\Sigma}$	Property bindings	Apply element properties by using external data sources	
		3001003	
		Rules will make it p	ossible to interact on certain
	Rules	-	ime data and change the beha-
vior of a presentation automa		on automatically	
\subseteq	Presentation rules	Supported	
\subseteq	Page rules	Supported	
\subseteq	Element rules	Supported	
	Device Management		nt which can be performed
	- Corac management	from a remote location	
		Connection state	Device connection state information
			Automatically send out alerts
		Alerts	when network failures occur
	Remote device management		for this device
\mathbf{M}		Reboot	Supported
	Web based and Windows	Restart Viewer	Restart PADS4 Viewer
		Shutdown	Not supported
		Wake On Lan	Supported
		Screenshot	Retrieve screenshots for what is actually displayed
			mat is actually displayed

			
		Logs	Viewer log, synchronization log, system info
		Viewer Settings	Edit Viewer Settings
		Fonts	Install Fonts on device
		Proof of play	Show Proof of play inform- ation
		Blackbox	If help from NDS Support is required, the blackbox contains important information for investigation purposes
	Remarks		
_	Colors	Texture and pattern colors are not supported	
\Box	Transition effects		rtical blinds not supported d circle and sliced circle not sup-
Q	Content file integrity	PADS4 Content Library file integrity is checked during synchronization using MD5	
口	Proof of play	Local storage limitation of max. 50.000 records on the HTML5 Viewer during offline period. When the 50.000 is hit, the oldest value will be removed first.	

4. Troubleshooting

Problem	Solution
	Viewer will restart
	twice and update to
Update system to PADS4 2020.2	the new Tizen
	launcher auto-
	matically.



PADS4 Installation Manual

Viewer on Samsung SSP6 (Tizen 4)

Contents

- 1. First time use
- 1.1. Configuring the device
- 1.2. Resetting the device
- 1.3. Uninstall an app
- 2. Installing PADS4 Viewer
- 2.1. Checking device firmware
- 2.2. Updating firmware
- 2.3. Adjust PADS4 Viewer settings using the options screen
- 3. Supported features & limitations
- 4. Troubleshooting

1. First time use

This document is related to the SSSP6.

When you turn the device on for the first time, it will open a configuration wizard. Follow the steps and specify the settings, as mentioned below. (If the configuration wizard does not start, then please first factory reset your device, as described in '1.2 resetting the device'.)

1.1. Configuring the device

Please read the installing section to setup the Viewer. There are no changes that need to be performed before installing the Viewer.

1.2. Resetting the device

If your device was used before, we recommend that you factory reset your device, so that all storage is freed and no other software interferes with the PADS4 Viewer software.

Step	Description
01	Turn the screen off
02	Press on the remote control: <button>Mute + 1 + 8 + 2 + <button>ON</button></button>
03	Select option => Factory reset => factory reset

The device will factory reset and afterwards you will see the welcome screen, please follow the steps as described in '1.1 configuring the device'.

1.3 Uninstall an app

When you fail to open the device menu by pressing the key combination, it is possible that the installed app blocks this option. Then you need to uninstall the app first before you can open the device menu.

Step	Description
01	Open Home menu
02	Select URL launcher settings
03	Select the uninstall option
04	Confirm to uninstall the app

2. Installing PADS4 Viewer

Step	Description			
01	Select language and press Next			
02	Display Orientation. Select Landscape			
03	Auto power off. Select off			
04	Network settings. Connect to your network			
05	Clock set. Configure current date and time			
	Play via. Select URL Launcher. Specify PADS4 Server url			
06	Hosting PADS4 on HTTP (default) http:// <server>/PADS4/apps/tizen https://<server>/PADS4/apps/tizen where <server> is the IP address or domain name of your PADS4 Server. (second option, secured using https)</server></server></server>			

	Be aware that PADS4 must be specified in capitals, otherwise Tizen will not be able to connect due to case sensitivity.
	If you are using PADS4 version 2020.1 or earlier please use the old link:
	http:// <server>/pads4/native/samsung https://<server>/pads4/native/samsung (second option, secured using https)</server></server>
07	Device name (optional)
80	Setup complete. Select OK
80	In Home menu select URL launcher

If the wizard does not show up on startup, change the input to HDMI, next press the menu button on the remote control and select Setup under System menu (Default pin is 0000).

When finished the device will download the PADS4 HTML5 Viewer software and start. At the left bottom location a connection indicator icon will appear. It will turn green if a valid connection is made to the Server.

If a problem occurs open the viewer settings and have a look at the log which may contain important (error) information.

The first time the device is configured, a valid server connection is required to download the PADS4 HTML5 Viewer software.

2.1. Checking device firmware

To run the PADS4 viewer properly on the SSSP6 and make sure that all functionality works, you need to have firmware as mentioned in step 4 installed on the device. Please check using the following steps.

Step	Description
01	Power on the screen and press the Home button on the remote control
02	Select more options
03	Select support
04	Select Contact Samsung Software version shows the version number installed.
	Version 1060.7 is required by PADS4 Minimum PADS4 version required is 2020.1

2.2 Updating firmware

Step	Description

01	Insert the USB Stick into the device
02	Press menu button
03	Select support
04	Select Software update
05	Select Update now and follow the instructions

2.3. Adjust PADS4 Viewer settings using the options screen

You can adjust the PADS4 Viewer settings directly on the display. To enter the options screen on the device itself, hold the left mouse button down or touch the screen for 3 seconds.

3. Supported features and limitations

Support	Category	Description		
\subseteq	Automatic PADS4 Software updates	Supported. HTML5 Viewer is automatically updated.		
\subseteq	Offline mode of device	While offline from the network, the device will still continue to play PADS4 presentations and change planned schedules for 7 days. Scheduled presentations, content and data is cached local.		
	Device			
\square	Portrait mode	Supported. Set the PADS4 rotation option to 270 degrees in the Viewer settings to set the screen in portrait mode. Do NOT use the screen SSP rotate option		
\subseteq	Block remote control	Option to prevent usage of remote control to operate the screen		
\subseteq	Transfer protocols	HTTP, HTTPS		
	Turn off display	Not supported		
\square	Cluster Viewer	This device is able to be used as Cluster Viewer		
	Elements			
Ý	Video element	2 seamless videos on each page. Maximum number of videos Maximum of one 4K video on each		


		Video rotation Seamless videos Maximum framerate Playback speed adjustment Reflection, skew, flip Streaming	page. Check out the supplier documentation for more info Possible using portrait mode only Supported in landscape orientation only 30 fps Not supported Not supported HTTP, HLS,RTP, UDP Simultaneous playing video from stream and file is not supported.
\subseteq	lmage element	Support for JPG, PNG, BMP, G	GIF
\leq	Text element	Supported	
\subseteq	Line element	Supported	
\subseteq	Shape element	Supported	
\subseteq	Scrolling text element	Supported	
\leq	Formatted text element	Supported	
	Flash element	Not supported	
\subseteq	Table element	Supported	
\subseteq	Interactive button element	Supported Mouse cursor options not sul Interactive Data filter & sort d supported	· ·
\subseteq	Web element	Usage of the interactive Addr ported	ess Bar not sup-
	Data connections	Data connections make it pos ation from external sources ir	

\subseteq	Data providers	of (realtime) data f	S4 data providers for retrieval from external sources and the ge and join the data to fit your
	Viewer Variables Property bindings	Usage of Viewer Variables can simplify your presentations and data connections. It also gives the opportunity to centrally manage the content without changing presentations or data providers. Apply element properties by using external data sources	
	Rules	=	ossible to interact on certain ime data and change the beha- ion automatically
\subseteq	Presentation rules	Supported	
\subseteq	Page rules	Supported	
\subseteq	Element rules	Supported	
	Device Management	Device manageme	nt which can be performed ation
		Connection state	Device connection state information
		Alerts	Automatically send out alerts when network failures occur for this device
		Reboot	Supported
		Restart Viewer	Restart PADS4 Viewer
	Remote device management	Shutdown	Not supported
\mathbf{r}	Web board and World	Wake On Lan	Supported
	Web based and Windows	Screenshot	Retrieve screenshots for what is actually displayed
		Logs	Viewer log, synchronization log, system info
		Viewer Settings	Edit Viewer Settings
		Fonts	Install Fonts on device
		Proof of play	Show Proof of play information

		Blackbox	If help from NDS Support is required, the blackbox con- tains important information for investigation purposes
	Remarks		
	Colors	Texture and patter	n colors are not supported
Ç	Transition effects	Horizontal and vertical blinds not supported Splitters, increased circle and sliced circle not supported	
	Content file integrity	PADS4 Content Lib ing synchronization	rary file integrity is checked dur- n using MD5
Ç	Proof of play	the HTML5 Viewer	ation of max. 50.000 records on during offline period. hit, the oldest value will be

4. Troubleshooting

Problem	Solution
	Viewer will restart
	twice and update to
Update system to PADS4 2020.2	the new Tizen
	launcher auto-
	matically.



Viewer on Samsung SSP6 SHF stretch (Tizen 4)

Contents

- 1. First time use
- 1.1. Configuring the device
- 1.2. Resetting the device
- 1.3. Uninstall an app
- 2. Installing PADS4 Viewer
- 2.1. Checking device firmware
- 2.2. Updating firmware
- 2.3. Adjust PADS4 Viewer settings using the options screen
- 3. Supported features & limitations
- 4. Troubleshooting

1. First time use

This document is related to the SSSP6.

When you turn the device on for the first time, it will open a configuration wizard. Follow the steps and specify the settings, as mentioned below. (If the configuration wizard does not start, then please first factory reset your device, as described in '1.2 resetting the device'.)

1.1. Configuring the device

Please read the installing section to setup the Viewer. There are no changes that need to be performed before installing the Viewer.

1.2. Resetting the device

If your device was used before, we recommend that you factory reset your device, so that all storage is freed and no other software interferes with the PADS4 Viewer software.

_	_	
Step	Descri	iption

01	Turn the screen off
02	Press on the remote control: <button>Mute + 1 + 8 + 2 + <button>ON</button></button>
03	Select option => Factory reset => factory reset

The device will factory reset and afterwards you will see the welcome screen, please follow the steps as described in '1.1 configuring the device'.

1.3 Uninstall an app

When you fail to open the device menu by pressing the key combination, it is possible that the installed app blocks this option. Then you need to uninstall the app first before you can open the device menu.

Step	Description
01	Open Home menu
02	Select URL launcher settings
03	Select the uninstall option
04	Confirm to uninstall the app

2. Installing PADS4 Viewer

Step	Description
01	Select language and press Next
02	Display Orientation. Select Landscape
03	Auto power off. Select off
04	Network settings. Connect to your network
05	Clock set. Configure current date and time
	Play via. Select URL Launcher. Specify PADS4 Server url
06	Hosting PADS4 on HTTP (default) http:// <server>/PADS4/apps/tizen https://<server>/PADS4/apps/tizen where <server> is the IP address or domain name of your PADS4 Server. (second option, secured using https)</server></server></server>
	Be aware that PADS4 must be specified in capitals, otherwise Tizen will not be able to connect due to case sensitivity.
	If you are using PADS4 version 2020.1 or earlier please use the old link:
	http:// <server>/pads4/native/samsung</server>

	https:// <server>/pads4/native/samsung (second option, secured using https)</server>
07	Device name (optional)
80	Setup complete. Select OK
08	In Home menu select URL launcher

If the wizard does not show up on startup, change the input to HDMI, next press the menu button on the remote control and select Setup under System menu (Default pin is 0000).

When finished the device will download the PADS4 HTML5 Viewer software and start. At the left bottom location a connection indicator icon will appear. It will turn green if a valid connection is made to the Server.

If a problem occurs open the viewer settings and have a look at the log which may contain important (error) information.

The first time the device is configured, a valid server connection is required to download the PADS4 HTML5 Viewer software.

2.1. Checking device firmware

To run the PADS4 viewer properly on the SSSP6 and make sure that all functionality works, you need to have firmware as mentioned in step 4 installed on the device. Please check using the following steps.

Step	Description
01	Power on the screen and press the Home button on the remote control
02	Select more options
03	Select support
04	Select Contact Samsung Software version shows the version number installed.
	Version 21.61 is required by PADS4 Minimum PADS4 version required is 2020.1

2.2 Updating firmware

Step	Description
01	Insert the USB Stick into the device
02	Press menu button
03	Select support
04	Select Software update
05	Select Update now and follow the instructions

2.3. Adjust PADS4 Viewer settings using the options screen

You can adjust the PADS4 Viewer settings directly on the display. To enter the options screen on the device itself, hold the left mouse button down or touch the screen for 3 seconds.

3. Supported features and limitations

Support	Category	Description		
	Automatic PADS4 Software updates	Supported.		
	nationation 7.55 i 50 itware apartes	HTML5 Viewer is automatically updated.		
		While offline from the network	•	
1.2		continue to play PADS4 presentations and change		
\triangle	Offline mode of device	planned schedules for 7 days.		
		Scheduled presentations, content and data is		
		cached local.		
	Device			
		Supported.		
		Set the PADS4 rotation option	to 270 degrees in	
\triangle	Portrait mode	the Viewer settings to set the s	•	
		mode. Do NOT use the screen SSP rotate option		
	Block remote control	Option to prevent usage of re	event usage of remote control to	
Ľ	block remote control	operate the screen		
\subseteq	Transfer protocols	HTTP, HTTPS		
	Turn off display	Not supported		
\subseteq	Cluster Viewer	This device is able to be used	as Cluster Viewer	
	Elements			
	Video element		2 seamless videos	
			on each page.	
			Maximum of one	
		Maximum number of videos	4K video on each	
			page.	
$\mathbf{\Sigma}$			Check out the sup-	
			plier doc- umentation for	
			more info	
			Possible using	
		Video rotation	portrait mode	
			1	

			only
			Supported in land-
		Seamless videos	scape orientation only
		Maximum framerate	30 fps
		Playback speed adjustment	Not supported
		Reflection, skew, flip	Not supported
			HTTP, HLS,RTP, UDP
		Streaming	Simultaneous play- ing video from stream and file is not supported.
Y	lmage element	Support for JPG, PNG, BMP, G	IF
Ŋ	Text element	Supported	
Ŋ	Line element	Supported	
\subseteq	Shape element	Supported	
\subseteq	Scrolling text element	Supported	
\subseteq	Formatted text element	Supported	
	Flash element	Not supported	
	Table element	Supported	
⊴	Interactive button element	Supported Mouse cursor options not sup Interactive Data filter & sort d supported	•
\subseteq	Web element	Usage of the interactive Addre	ess Bar not sup-
		Data connections make it pos	sible to show inform
	Data connections	ation from external sources in	
		More than 70 PADS4 data providers for retrieval of (realtime) data from external sources and the	
\triangle	Data providers	possibility to change and join purpose	
\square	Viewer Variables	Usage of Viewer Variables can presentations and data conne	

			pportunity to centrally manage it changing presentations or
\subseteq	Property bindings	-	perties by using external data
	Rules		oossible to interact on certain time data and change the beha- iion automatically
\subseteq	Presentation rules	Supported	
Ŋ	Page rules	Supported	
Ŋ	Element rules	Supported	
	Device Management	Device manageme from a remote local	ent which can be performed ation
		Connection state	Device connection state information
		Alerts	Automatically send out alerts when network failures occur for this device
		Reboot	Supported
		Restart Viewer	Restart PADS4 Viewer
		Shutdown	Not supported
		Wake On Lan	Supported
\subseteq	Remote device management	Screenshot	Retrieve screenshots for what is actually displayed
	Web based and Windows	Logs	Viewer log, synchronization log, system info
		Viewer Settings	Edit Viewer Settings
		Fonts	Install Fonts on device
		Proof of play	Show Proof of play information
		Blackbox	If help from NDS Support is required, the blackbox contains important information for investigation purposes
	Remarks		

	Colors	Texture and pattern colors are not supported
口	Transition effects	Horizontal and vertical blinds not supported Splitters, increased circle and sliced circle not sup- ported
	Content file integrity	PADS4 Content Library file integrity is checked during synchronization using MD5
Q	Proof of play	Local storage limitation of max. 50.000 records on the HTML5 Viewer during offline period. When the 50.000 is hit, the oldest value will be removed first.

4. Troubleshooting

Problem	Solution
	Viewer will restart
	twice and update to
Update system to PADS4 2020.2	the new Tizen
	launcher auto-
	matically.



How to install PADS4 Windows Client applications

Important: This installation applies to a new system to install the latest PADS4 Client 2020.1 build. It is of vital importance that **you do not install the PADS4 Foundation 2020.1 build on a work-station / Viewer PC**. This will corrupt the functionality of your workstation / Viewer PC, as this would result in setting up the configuration as a Server PC.

Download


Download the PADS4 Client setup software from *http://go.pads4.com/?fwlink=1011

Note: check the properties of the executable as Windows tends to block the file, you can unblock it by checking the unlock checkbox and confirm with OK.

Start setup

Execute the PADS4 Clients.exe installation file as an Administrator and choose one of the available languages.

Verify that **Version 2020.1** is to be installed and press Next.



Please make sure to read the License Agreement, if agreed check the check box and press Next.

User selection

Determine for which users PADS4 Clients needs to be installed and press Next.


Component selection

Select **Custom Installation** from the drop down menu, and select the following applications to perform a PADS4 Clients installation.





Select Installation Components



Press Next after the selection is made

Help

Determine whether you wish to install the online help file, reachable by pressing F1 in any of the applications. It will take you directly to the section you are currently working in and we highly recommend installing it.

Shortcuts

Determine whether you want PADS4 to generate shortcuts in Desktop, Start Menu and StartUp Folder. Optionally you can change the installation folder of PADS4 Clients.

Installation starts

You should now see that PADS4 Clients is being installed.

When successfully installed, PADS4 Clients should show the "PADS4 Clients has been successfully installed" message.

Network ports used by PADS4

Check out the Network Ports Configurations page for more information about network ports used by PADS4.



How to silent install PADS4 Windows Client applications using commandline parameters

Software

Check out the how to install PADS4 Windows Client applications page for more information about installation and downloads.

PADS4 installation commandline parameters

Command line parameters for silent installation of PADS4 client applications.

Parameter	Description
-q	Silent mode
-S	Silent mode (same as -q)
-m:uninstall	Uninstall
Config:CompleteConfig:ViewerConfig:SchedulerConfig:DesktopViewer	Install complete package Install Viewer only Install Scheduler only Install Desktop Viewer only Custom mode. All features can be specified separately. Valid names are:
Config:Custom	 Designer Scheduler Messenger ContentOrganizer LicenseWizard Viewer DesktopViewer SystemManagement Agent
SettingsFiles:	Copy after the installation is finished the specified settings files to the destination ProgramData folder. The specified file can be adjusted so that for example each Viewer has a server specified by default.

Examples:

PADS4 Clients.exe --SettingsFiles:C:\Settings\PADSViewerSettings.xml

PADS4 Clients.exe --Set-

tingsFiles:\\<Server>\Settings\PADSViewerSettings.xml

PADS4 Clients.exe --Set-

tingsFiles:http://Settings.nds.eu/Settings/PADSViewerSettings.xml

PADS4 Clients.exe --SettingsFiles:file1.xml --SettingsFiles:file2.xml

PADS4 Clients.exe --SettingsFiles:file1.xml;file2.xml

PADS4 Clients.exe --SettingsFiles:"C:\Path with spaces\file1.xml"

Examples

PADS4 Clients.exe -s --Config:Complete

PADS4 Clients.exe -s --Config:Viewer

PADS4 Clients.exe -s -- Config: Custom = Designer, Scheduler, Content Organizer, Agent




How to update PADS4 Server

Download the PADS4 Foundation Setup

Download PADS4 Foundation from http://go.pads4.com/?fwlink=1010

Execute the installation file (as an Administrator)

Right click with the mouse on the installation file and select run as administrator.



Make sure to read the installation document and license agreement before checking the boxes and installing the software.

Installation folders

Change the installation folders if required.

PADS4 Foundation contains all the files required to run PADS4 on the Server.

NDS Package Manager is required and is used to maintain the components of PADS4 which have


been divided into so called packages.

If the NDS Package Manager is not yet available on you PC, it will also be installed. You may change the installation folder.

If the NDS Package Manager is already installed, the installation folder destination folder option will be hidden.

Optionally change the installation folder if required.

Check the boxes to confirm and press Install to start the installation process.




The installation process will start and show the progress as in the picture above.

Error during installation


In case an error occurs a pop up window will occur. This pop up contains a click HERE link to the log file created.

If you encounter any problems this log file can be of help to investigate the cause of the problem. Every step of the installation process is written to this log.

Error information:



Installation finished



When the installation is finished, you should see the PADS4 Foundation installed successfully message as in the picture above.

Start PADS4 Foundation configuration tool

Check the box if you would like to specify configurations settings. If you start the PADS4 Foundation setup the first time, please check the settings.

Check out the "PADS4 Foundation Configuration" on page 356 which contains details about the settings

Start PADS4 Clients setup

If you would like to install additional Windows based PADS4 programs on this PC such as PADS4 Scheduler, PADS4 Designer etc. check the box to start the setup after the PADS4 Foundation installation has been completed. This setup allows you to select which Windows based client components need to be installed.

Check out the "How to install PADS4 Windows Client applications" on page 343 which contains details about the settings

Once you press the Close button, you will be presented with the PADS4 CTRL Center Configuration tool and/or the PADS4 Clients installation wizard.

Important

It is of vital importance that you do not install the PADS4 Foundation on a workstation / Viewer PC (that is only configured for Designer/Scheduler/Content Organizer/Messenger etc.). This will install PADS4 Server functionality on your workstation / Viewer PC, as this would result in setting up the configuration as a Server PC. It is however possible to install the PADS4 Clients software after installing the PADS4 Foundation installation as the machine is then already classified as a Server PC.



How to upgrade PADS4 Sub Server

Once PADS4 Foundation has been installed or upgraded on the PADS4 (Main) Server, the updates need to be downloaded and installed on the PADS4 Sub Servers also.

Upgrade Sub Server


Follow the steps written on the "How to update PADS4 Server" on page 349 page to upgrade the Sub Server.

Upgrade Viewers

After the Sub Server upgrade is finished, you need to upgrade the Viewers to the latest version also.

Follow the steps written on the "How to upgrade PADS4 Viewer" on page 358 to perform an automatic or manual upgrade.

Be aware that upgrading the Servers is required prior to upgrading the Viewer automatically because the Viewer will retrieve the PADS4 software from the Server where it is connected to. If this Server still has an old version it will upgrade to that version.



How to upgrade PADS4 Backup Server

Once PADS4 Foundation has been installed or upgraded on the PADS4 (Main) Server, the updates need to be downloaded and installed on the PADS4 Backup Servers also.

Upgrade Backup Server

Follow the steps written on the "How to update PADS4 Server" on page 349 page to upgrade the Backup Server.

Upgrade Viewers

After the Backup Server upgrade is finished, you need to upgrade the Viewers to the latest version also.


Follow the steps written on the "How to upgrade PADS4 Viewer" on page 358 to perform an automatic or manual update.

Be aware that upgrading the Servers is required prior to upgrading the Viewer automatically because the Viewer will retrieve the PADS4 software from the Server where it is connected to. If this Server still has an old version it will update to that version.



PADS4 Foundation Configuration

PADS4 Foundation Configuration allows you to specify configuration settings.



Here you are able to specify the ports that PADS4 should be operating on and the IP address of your PADS4 Server PC and press apply when configuration is as desired.

PADS4 Server

- HTTP Port
 - The port used to communicate with the PADS4 Server (default is 9005)
- IP adress
 - By default the IP address of PADS4 Server is localhost (127.0.0.1). Normally PADS4 Foundation and PADS4 Server are located on the same PC.

PADS4 Foundation

- HTTP Port
 - The HTTP port used to host the PADS4 CTRL Center (default is 80)
- HTTPS Port (SSL)

The security certificate for using the PADS4 CTRL Center with SSL

- DNS Host Name Domain which is registered
- · Certificate file .certificate file
- Private Key file .private file

When all settings are successfully applied after click apply, PADS4 Foundation will restart all processes with the new settings.

Tip: Default username and password after installation is for both "user1"

Please change this after the first logon using the account icon on the right top of the webportal.

Be aware that it may take up to 30 seconds based on your hardware specs to restart all processes.

Sensor database type selection

Click here to show the Sensor database type selection page.

Check out if the server is running

If you want to verify that the PADS4 server is running, perform the following check.

Open a webbrowser and specify "http(s)://localhost:<port>. Use https or http based on you settings. Specify the right port number as specified.

The logon page of PADS4 CTRL Center should occur.

PADS4 Clients installation help

Check out the "How to upgrade PADS4 Windows Client applications" on page 363 page for installation instructions on.



How to upgrade PADS4 Viewer

In this section

Automatic upgrade

Describes the steps to have your PADS4 Viewers perform upgrade automatically.

Manual upgrade using PADS4 Client setup

Describes the steps to perform the upgrade to your PADS4 Viewers manually.

Other manual upgrade

Be aware that PADS4 needs admin rights and when the update is installed in a different folder as the first installation has taken place, this can cause the Viewer to malfunction because of insufficient permissions.

We do not provide other upgrade steps than using the PADS4 Client setup to install Viewers.

*Please note that this applies to Windows based PADS4 Viewers only. HTML5 based PADS4 Viewers will automatically upgrade when the PADS4 Servers are upgraded.

Check out the Install PADS4 HTML5 Viewers section for more information about installation on HTML5 devices.

Automatic upgrade

PADS4 Viewers can be automatically upgraded via the PADS4 Agent that is installed on the upgraded PADS4 Main Server and or PADS4 Sub Server.

Be aware that you have to upgrade the PADS4 Server first before you are able to upgrade a Viewer using the PADS4 Agent.


The upgrade process uses the version of the installed PADS4 Server and installs the same version on the Viewer.

NOTE: If you are planning to use a script to update Viewers and not use the automatic upgrade using the PADS4 Agent, be aware that the Viewers were installed using Admin rights. Updates where the destination folder specified is different from the original installation folder will malfunction due to insufficient permissions. Please update the PADS4 Viewer using the same folder as used during the first installation.


To upgrade PADS4 Viewers automatically

You need to use the PADS4 Agent application installed on the PADS4 Main Server or PADS4 Sub Server to upgrade the PADS4 Viewers to the same version as the PADS4 Main server and or PADS4 Sub Servers.

- Click the Start button on the Windows task bar
- Select (All) Programs, PADS4 and then Agent
- After having logged on successfully, the Agent's main window is shown
- Select the Scheduled Tasks window and click New Task in the ribbon bar




• A new window will be displayed. Scroll down the list and select Viewer Tasks and the Update Software option



Click Next

• Select the Download and Install Update option from the Action drop down list



- Click Next
- Select the PADS4 Viewers that you would like to update.
 Select the Select All checkbox to update all the Viewers in your PADS4 system.
- Click Next
- Select when the update tasks should be executed. You can specify that the update will need to run now or a later time and date.
 - If you specify that the update takes place at this moment, be aware that this will be visible to the audience in front of the Viewer.
- Click Finish

The scheduled task will be forwarded to all selected Viewers and the Viewers will update on the selected date/time you have chosen.

You can view the progress of the scheduled task in the PADS4 Agent.

If the scheduled task has been successful, the PADS4 Viewers have been upgraded.

Manual upgrade

Follow the instructions as described in "How to install PADS4 Viewer" on page 71



PADS4 Installation Manual

How to upgrade PADS4 Windows Client applications

Important: This installation applies to a new system to install the latest PADS4 Client 2020.1 build. It is of vital importance that **you do not install the PADS4 Foundation 2020.1 build on a work-station / Viewer PC**. This will corrupt the functionality of your workstation / Viewer PC, as this would result in setting up the configuration as a Server PC.

If you want to install or upgrade PADS4 Server, please check the "How to install PADS4 Server" on page 49 **or** "How to update PADS4 Server" on page 349 **page.**With PADS4 version 2020.1 the installation process has changed. Please check out this page for more information about the changes.

Download PADS4 Client setup


Download the PADS4 Client setup software from *http://go.pads4.com/?fwlink=1011

Note: check the properties of the executable as Windows tends to block the file, you can unblock it by checking the unlock checkbox and confirm with OK.

Start setup

Execute the PADS4 Clients.exe installation file as an Administrator and choose one of the available languages.

Verify that **Version 2020.1 or higher** is to be updated/installed and press Next.



The system is now ready to update. Click **Update** to start the upgrade process.

Once the upgrade is finished, you will receive a message stating that the PADS4 Clients has been successfully upgraded.

When successfully upgraded, PADS4 Clients should show the "PADS4 Clients has been successfully installed" message.



PADS4 Installation Manual

PADS4 Active Directory Synchronization Installation

Using PADS4 Active Directory Synchronization package will allow you to synchronize one ore more Active Directory groups with PADS4.

This way a user who is removed from Active Directory will automatically be removed from PADS4 instantly. The moment the user is removed, an event is raised to tell PADS4 to prevent the user from logging onto the system and when already logged on, the user will be logged out.

Prepare the Active Directory package installation

We recommend that you create a user account without any licenses but that is part of the administrator group in PADS4. Because the PADS4 Active Directory Synchronization service has an active connection to the PADS4 Server and if you use an existing user account, it will be blocked when connection to PADS4 System Management.

Also, make sure that you configured your active directory connection in PADS4 before configuring the Active Directory Synchronization service, because it will use these connections for the synchronization.


You can **configure** the **Active Directory connection in the main server properties in PADS4 System Management**.

Installing PADS4 Active Directory Synchronization package.

You can install the PADS4 Active Directory Synchronization service by running the supplied installer package. Currently this package is not yet public. Please ask our Sales & Marketing department for the package.

Start Installer package

You need to accept the terms of the license agreement and then you can press the install button. Optionally you can change the installation folder.



After installation, it will automatically start the PADS4 Active Directory Synchronization configuration tool, if the option is checked.



Configuring Active Directory Synchronization

To configure the PADS4 Active Directory Synchronization service, you need to run the PADS4 Active Directory Synchronization Configuration tool. First, you need to specify the PADS4 connection settings to connect to an existing PADS4 Server with a user account that has system management rights. Preferably, the one created especially for this service, as mentioned before.

When all connection settings are specified, you need to press the connect button and it will try to connect to the PADS4 Server. If successful, it will retrieve the Active Directory settings from the PADS4 Server.

Now you need to add the Active Directory groups from which the members needs to be synchronized to the PADS4 Server. You can do this by pressing the plus button and it will open an active directory browser, which allows you to select a single active directory group.

After that, you can repeat this process to add multiple groups.



Fig 1: empty settings after installation

For each member of the Active Directory groups a user account is created on the PADS4 server, this user account will be assigned to the specified PADS4 user groups and will be given the licenses specified in the configuration tool (if enough licenses are available).

The PADS4 Active Directory Synchronization service will register for member changes of the specified Active Directory groups, so when a member is added or removed it will capture the event and synchronize this change to the PADS4 Server.

However, if this fails there is a default synchronization interval, which will always trigger the synchronization between Active Directory and PADS4.

When the configuration is complete, you only need to press the apply button, it will store the settings, start the PADS4 Active Directory Synchronization service and close the configuration application.

If you do not want to store the changes you made and decide to cancel the configuration, it will not start the PADS4 Active Directory Synchronization service.





Fig 2: Example of possible settings

Troubleshooting

If you are experiencing problems with the PADS4 Active Directory Synchronization, you can open the Windows Event Viewer and access the PADS4 AD Synchronization log. It is located in Applications and Services Logs container.





PADS4 Installation Manual

PADS4FIDS Introduction

Manage and display flight information at your airport with our FIDS (Flight Information Display System).

With FIDS software you typically manage centrally what you want to display on the FIDS screens across your airport. From the FIDS screens at the arrival & departure hall and the check-in area to the screens at the gates and baggage belts, in the business lounge and at all other places where flight information is required.

Click here to find out how to start your PADS4FIDS Operator

Smart FIDS

Each FIDS product is able to display flight information. Most products nowadays also have the ability show flight information in combination with advertising. That's all no big deal. The question is how you can do more for your passengers by making your FIDS smart.

For your FIDS software to be smart it should 'recognize a situation' by itself and dynamically respond to it by displaying contextually relevant content that best suits the needs of your audience.

For example displayed flight information at your airport may include directions and walking distances to the gate. However, to make it really smart it would need to dynamically adjust itself to the waiting times at the security check.

New technologies enable you to go even further. With smart phone analysis tools you have the possibility to detect for instance that the majority of your audience is Spanish. In that case the FIDS software could automatically respond by adding Spanish as an additional language to the flight information on the screens.

PADS4

The PADS4 product contains a dedicated Data Provider which is able to connect to the PADS4FIDS product. This allows the user to make a connection to the FIDS system just by clicking on some options based on what information you would like to show. The wizard guides the designer through the available options which have been prepared for the tasks that commonly are used within the airport such as information for departures, arrivals, check-ins, gates, baggage belts and flight information for the staff.

Besides this feature the information also contains predefined fields that can be used for advanced rules and filters that allow the user to create an even smarter system that is able to respond on certain conditions automatically.

Beyond FIDS

PADS4 is used worldwide in lot's of markets such as corporate, transportation, retail, education, healthcare, government, hospitality, manufacturing and other industries. PADS4 is able to connect to a large number of external data sources and automatically integrate this into the presentation. Information from for instance the companies databases, social media's, weather forecasts or traffic information can be integrated just by following the wizard where the user does not need to have any technical knowledge to get this connection working.

This integration with other sources combined with FIDS information will give you the opportunity to create an even smarter solution.



PADS4 Installation Manual

PADS4FIDS Installation

When PADS4 Foundation is installed, the PADS4FIDS product is also installed on the same server.

Step 1

After the installation of the setup is finished, **Start PADS4 CTRL Center** to enter the product key you retrieved in the Licenses menu.

Click here to open the online PADS4 CTRL Center help which explains how to enter a new product key.

Step 2

Start the PADS4 System Management application and use your credentials to log on. (**Default user after installation is user1 with password: user1**)

Step 3

Specify the SQL Database settings by editing the PADS Server Settings for PADS4FIDS.

PADS4FIDS uses SQL Server for data storage.

These settings can be specified using the PADS4 System Management application.

Step 4

Add a User License for the PADS4FIDS Operator.

To allow a user to start the PADS4FIDS Operator, a license for the PADS4FIDS Operator must be assigned.

Assignment of licenses can be performed using PADS4 CTRL Centerapplication.

Step 5

Start the PADS4FIDS Operator.

Use a web browser such as Internet Explorer or Chrome to start the PADS4FIDS Operator.

Start PADS4FIDS Operator (with your PADS4 account)

Before you can Sign In, you need to enter the start up URL in your browser.

To connect to your PADS4FIDS Operator

Enter the URL in the textbox of your webbrowser:


Http://<Server Name>/PADS4/FIDS/Operator

<Server Name> must be replaced by the name or ip address of the server where PADS4FIDS Operator is installed.

Optionally you may enter the required portnumber: Http://<Server Name>:<port>/PADS4/FIDS/Operator

To Sign In

When the URL specified is correct, the Sign In page will be displayed.



Fill in the **Username** and **Password**. Optionally enable the **Keep me signed in** option which allows you to automatically Sign In the next time.

Press the **Sign in** button to logon.

If you press the **can't access your account**, the help environment will be opened in a separate window.

When valid credentials are entered, the PADS4FIDS Operator main window will be launched.

No credentials?

If you do not have credentials check with your administrator if you have a license for the PADS4FIDS Operator assigned.

Use the PADS4 System Management application to add a license for PADS4FIDS Operator.

No web page found?

If you receive the error message 'page is not found', please check your installation.

PADS4 Server settings for PADS4FIDS

These settings determine the Database settings needed for the PADS4FIDS product.

Start the PADS4 System Management Application, logon and click on **Server Settings** in the left panel.


Next press the **Edit** option under Server Settings in the Ribbonbar.

Finally select the PADS4FIDS option in the list.



NOTE

This option is only available when there is a valid PADS4FIDS product license. If not, the PADS4FIDS options will be hidden.



Microsoft SQL Server

If you need to manually install the PADS4FIDS database there are three possibillities:

- Create the database manually with Microsoft SQL Server Management Studio
- · Create the database manually with SQL statements
- Create the database manually with Powershell

Server Name

Specify the SQL Server.

When the dropdown is opened, it can take some seconds to fill the combobox with the available items.

Authentication

When SQL Server Authentication is selected, specify the User Name and Password.

When the dropdown is opened, it can take some seconds to fill the combobox with the available items.

Database Name

Select the database name that must be used for PADS4FIDS.

If the database does not exist, PADS4 Server will try to create the database after these settings have been saved.

If the selected database is not a PADS4FIDS database, the database it's structure will be adjusted and the original database is removed including data.

Help

Press the help button to open the web help for PADS4FIDS.

Flight Remover Settings

Remove flights after x days

Specify the number of days after which the operational flights must be removed from the operational database.

If the archive database is specified, the flights will be stored in this archive database.

Archive flights on removal

Optionally specify the archive name of the database where flights are stored after they must be removed from the operational database.

If no archive is specified, the removed flights will no longer be available.

Setup a SQL Fail over installation

It is possible to have a PADS4FIDS fail over installation by using two PADS4 Servers and a DNS API switcher with the SQL database being on a central point in the network that is not on a PADS4 Server.

Step 1

Follow the steps to create a SQL database found here on a separate server in the network such as a SQL Server.

Step 2

Setup and install two separate PADS4FIDS servers on two separate VM's or physical servers. These servers will use the same licensing, however you will need to contact our sales team to allow this configuration.

The installation manual can be found here.

Step 3


You will need to install a DNS API Switcher on a machine in the network that is not the PADS4 Servers. This can be the SQL server or any other machine that can communicate to both the PADS4 Servers as well as all the PADS4 Viewers. The DNS API Switcher will need to use the first PADS4 Server as the main server and then switch the DNS to the secondary PADS4 Server when the first becomes unavailable on the network.

Step 4

Once the DNS API Switcher has been configured to point to the main PADS4 Server, you will need to use the DNS address as the IP for the PADS4 Server of the PADS4 Viewers connection information. The ports will not change unless specified. The default ports are port 80 and port 7237.


Users will need to use the DNS address when using the PADS4FIDS Operator to ensure that the system will reflect their changes regardless of which server is currently operational.

A network diagram is displayed below on how this scenario would be deployed:




Create the database manually with Microsoft SQL Server Management Studio

These steps will guide you through the process of creating the PADS4FIDS database using SQL Server Management Studio.




- Open SQL Server Management Studio
- Login to the Database Engine
- Expand the server
- Right-click Databases
- Click New Database...



• Enter the Database Name: PADS4FIDS


Click OK




- Expand Security
- Expand Logins
- Check if NT AUTHORITY\SYSTEM is listed

If it is not listed, continue, else


- o Right-click NT AUTHORITY\SYSTEM
- o Click Properties...
- o Goto step 6



- Right-click Logins
- Click New Login...



- Enter the Login Name: NT AUTHORITY\SYSTEM
- Check Windows authentication



- Select the User Mapping page
- Check the PADS4FIDS database in the Users mapped to the login section
- Check db_owner in de the Database role membership for: PADS4FIDS section
- Click OK

Create the database manually with Powershell

These steps will guide you through the process of creating the PADS4FIDS database using Powershell.

Execute the following PowerShell commands (on the system which has SQL Server installed) with a user account which has system admin permissions on SQL.

```
$sqlConnection = new-object system.data.SqlClient.SQLConnection("Data Source=localhost;
Integrated Security=SSPI;Initial Catalog=master");
$sqlCommand = new-object System.Data.SqlClient.SqlCommand;
$sqlCommand.Connection = $sqlConnection;
$sqlCommand.CommandText = "IF NOT EXISTS (SELECT * FROM [master].[sys].[server_principals]
WHERE name = 'NT AUTHORITY\SYSTEM') CREATE LOGIN [NT Authority\SYSTEM] FROM Windows";
$sqlConnection.Open();
if ($sqlCommand.ExecuteNonQuery() -ne 0)
echo "Failed: Step 1";
$sqlCommand.CommandText = "IF DB_ID('PADS4FIDS') IS NULL CREATE DATABASE [PADS4FIDS];";
if ($sqlCommand.ExecuteNonQuery() -ne 0)
echo "Failed: Step 2";
$sqlCommand.CommandText = "USE PADS4FIDS; EXEC sp_addrolemember 'db_owner', 'NT Author-
ity\SYSTEM'";
if ($sqlCommand.ExecuteNonQuery() -ne 0)
echo "Failed: Step 3";
$sqlConnection.Close();
```

Create the database manually with SQL statements

These steps will guide you through the process of creating the PADS4FIDS database using SQL statements.

Execute the following SQL statements with the preferred SQL client

```
USE [Master];
GO

IF NOT EXISTS (SELECT * FROM [master].[sys].[server_principals] WHERE name = 'NT
AUTHORITY\SYSTEM')
BEGIN
CREATE LOGIN [NT Authority\SYSTEM] FROM Windows
END

IF DB_ID('PADS4FIDS') IS NULL
BEGIN
CREATE DATABASE [PADS4FIDS];
END

IF IS_ROLEMEMBER ( 'db_owner', 'NT Authority\SYSTEM') = 0
BEGIN
GRANT db_owner ON [PADS4FIDS] TO [NT AUTHORITY\SYSTEM]
END
```

Glossary

М

My Term My definition